CK IPTV

Overview and installation

Android TV · Phone / tablet · Samsung · Windows PC

Android 3.11 · PC 1.6.6 · November 2026

CK IPTV at a glance

CK IPTV is an IPTV player: it shows and plays the channels, movies and series of **your** subscription (Xtream Codes, M3U playlist or stream link), with the same look on all your screens. It does not provide any channels itself.

Version	For which devices	File (download page)
Android TV	Android TV / Google TV sets and boxes (Sony, Philips, TCL, Xiaomi, Hisense, Nvidia Shield, Chromecast with Google TV) and Fire TV Stick. With the remote control.	CK_IPTV_TV.apk
Phone / tablet	Android phones and tablets (7 or newer), by touch, in portrait or landscape.	CK_IPTV_Mobile.apk
Samsung	Samsung TVs (Tizen), for example the Neo QLED QN72F. Installed from a PC.	CK-IPTV-Tizen folder
Windows PC	Windows 10 / 11 computers, with mouse and keyboard.	CK_IPTV_PC_Setup.exe (installer) or CK_IPTV_PC_Portable.exe (portable, no installation)

The files are downloaded from **ckiptv-app.github.io**: the page always offers the latest version.

An activation code is required. On first launch, the app asks for an 8-character code. It sets how long you can use the app: a code starting with **2** = 2 days, **7** = 7 days, **31** = 31 days, **366** = 1 year, **00** = unlimited. Each code can only be used once. To get one: WhatsApp button on the download page.

Samsung and LG TVs do not accept APK files. For a Samsung, use the Samsung version; LG TVs are not supported.

These versions contain **no account**: everyone enters their own subscription. Do not share the **old** versions (APK before 3.3, PC 1.0.0 to 1.4.0): they contain your Xtream account.

Installation

Android TV, Google TV and Fire TV

1 **Get the file**

- Easiest: free **Downloader** app (Play Store or Amazon), then type the code **5391565**.
- Otherwise: copy **CK_IPTV_TV.apk** to a USB stick and plug it into the TV.

2 **Allow the installation**

- Settings › Apps › Security & restrictions › Unknown sources: allow Downloader or your file manager (File Commander, X-plore). Fire TV: My Fire TV › Developer options › Install unknown apps.

3 **Install**

- Open the file, then Install. If Play Protect warns you: Install anyway (the app does not come from the Play Store).

4 **Activate, then enter your subscription**

- Launch CK IPTV, type the activation code (Internet required), then Activate.
- The Settings open: choose the source (Xtream Codes, M3U or link), enter server, username and password, then Save and load.

Update: install the new APK over the old one; the activation, lists, settings and favourites are kept.

Android phone and tablet

- Open the download page on the device and tap Download, or send yourself **CK_IPTV_Mobile.apk** (USB cable, Google Drive, WhatsApp…).
- Android asks you to allow the app that opens the file (Chrome, Files…) to install unknown apps: allow it, then Install.
- Then, as on the TV: activation code, then your subscription in the Settings.
- The phone version installs alongside the TV version, without replacing it.

Windows PC

- **CK_IPTV_PC_Setup.exe** installs the app with a desktop shortcut; **CK_IPTV_PC_Portable.exe** runs directly, without installation (for example from a USB stick).
- On first launch, Windows SmartScreen may warn you (unsigned app): More info › Run anyway.
- Activation code, then subscription in the Settings, as everywhere else.
- Recommended: also install VLC (videolan.org) for movies the built-in player cannot play.

Samsung TV (Tizen)

A Samsung TV only installs a home-made app in developer mode, from a PC. The preparation is done once; updates then take a single command.

1 **On the PC: Tizen Studio (once)**

- Install Tizen Studio (developer.samsung.com) in `C:\tizen-studio`.
- In the Package Manager: 9.0 Tizen, Samsung Certificate Extension and TV Extensions-9.0.

2 **On the TV: developer mode (once)**

- Write down the PC's IP address (`ipconfig` command).
- On the TV: Apps, type 1 2 3 4 5, turn on developer mode and enter the PC's IP.
- Switch the TV off completely and on again; write down its IP address (Settings › General › Network).

3 **Connect the TV and create the certificate (once)**

- Tizen Studio › Device Manager: add the TV (its IP, port 26101) and connect it.
- Certificate Manager: create a Samsung TV profile named **CKIPTV**, with your Samsung account.

4 **Install or update**

- In PowerShell, from the Project Claude folder: `powershell -ExecutionPolicy Bypass -File CK-IPTV-Tizen\tools\deploy.ps1 -TvIp TV-IP-address`
- Developer mode must stay on to keep the app.

Features

Sources, lists and licence

- Xtream Codes: channels, movies and series kept apart, in the provider's categories, with ratings and posters. M3U playlist (link or file) or stream link (.m3u8, .ts) for a single channel.
- **Several lists** on all devices NEW: in Settings › Lists and licence, one card per subscription with the active / maximum connections, and the buttons Rename, Edit, Load and Delete (with confirmation).
- **Licence**: days left on the home screen and in the Settings; on the last day, the time left is shown in hours. **Extend the licence** adds a new code to the time left (2 + 2 days = 4 days). With an unlimited licence, there is no code to enter any more. Time is counted with Internet time: changing the device's clock makes no difference.

Home screen

- Large tiles Live TV, Movies, Series with their count, and four small tiles: Favourites, Resume, Search, Speed (TV) or Downloads (tablet, PC). On TV, they have the colours of the remote control keys (red, green, yellow, blue) and open with them.
- Favourites and Search cover Live TV, Movies and Series together.
- At the top: your first name and the list name, the time of the last update and the licence.
- The list is kept for 12 hours to start quickly; ⟳ downloads it again right away.
- Back on the home screen: “Quit CK IPTV?” prevents closing the app by mistake.

Browsing the lists

- TV and PC: categories on the left, cards on the right (adjustable size, ⋮ menu). When going back to the categories, you return to the one you were in.
- Tablet in portrait: two buttons at the top, ★ Favourites (favourites of the open tab) and the current group ▾ (list of groups with search). 🏠 button for the home screen and a **floating bubble** 📺 / 🎬 / 🍿 (can be moved) to switch from Live TV to Movies or Series NEW.
- ★ Top rated (movies, series): the 15 best ratings in a carousel that turns in a circle, from no. 1 to the right. With the remote, Left on no. 1 goes back to the categories.
- Favourites per category (long press, Menu or yellow key), shown first.
- Manage categories: hide (also by language in one press), choose the exact position (number), move up or down 10 places (⇈ ⇊), lock.
- A search left active that empties the list is pointed out (“No channel “cnn” in this category…”).

Programme guide NEW

- Xtream lists: in the channel list (from medium size up), the programme on now, its times and a progress bar, updated every minute.
- In full screen, the banner shows the current programme and the next one. Android TV: OK shows the programme summary.
- No guide for M3U lists.

Playback

- Next channel with Up/Down or P+/P−, or by typing its number.
- Movies and episodes: resume at the minute where you stopped. On the posters, “45 %” with a bar, or “✓ Watched”; for a series, the last episode watched (“S1 E3 · 45 %”) NEW.
- Series: seasons, then episodes; the next episode starts by itself.
- **Poor connection** NEW: if the server does not answer, the app tries again 3 times by itself before showing an error. If the connection is weak (picture keeps stopping), it switches to a lower quality when the channel offers several and shows “ ⚠️ Weak Internet connection”. Without Internet, a message says so.
- Android TV: OK shows the details (summary, year, genre, quality) and the other channels below.

- Phone: player at the top of the list in portrait, full screen in landscape, small window when leaving the app.

Replays and live matches

- Button in the Settings. Replays: laid out like Live TV (categories on the left, channels as cards), then day and programme, for the channels that allow it.
- Matches on now: live football scores, updated every minute.

Settings NEW

- TV, PC and Samsung: menu on the left; tablet: tabs at the top. Four groups: Lists and licence, Display and language, Screensaver, Parental control. The app version is shown at the top (e.g. "V3.11").
- **Display and language**: French, German or English; Midnight blue or Black theme; your first name; text size (Small, Medium, Large); subtitles; maximum video quality (Automatic, 1080p, 720p, 480p).
- **Parental control**: default PIN 0000 (change it); adult categories locked automatically, others by hand; lock a whole tab (Channels, Movies or Series); PIN required when the app starts, if you wish.

TV, Samsung and PC specials

- Screensavers (Android TV, Samsung): digital or analogue clock, posters, or 16:9 pictures of movies and series with title and rating, after 5 to 30 minutes without activity. With a free TMDB key (themoviedb.org › Settings › API): trending, now in cinemas or top rated movies; without a key: the pictures of your subscription.
- Speed test (TV): latency, Internet speed and IPTV server speed, with the possible quality (SD to 4K).
- PC: click = OK, double-click = full screen, right-click = back, mouse wheel = scroll; F11 full screen; V key to open the stream in VLC.

Downloads (phone, tablet and PC)

- A movie: long press on its card (phone), ⬇ button or T key (PC). A series: Download the season, or one episode by long press.
- Downloads continue in the background, one at a time, with a notification at the end. The Downloads tile shows the status with Pause, Resume, Retry, Watch, Delete; an interrupted download resumes where it stopped.
- Downloaded movies can be watched without Internet (PC: Videos\CK IPTV folder).

Clear error messages

If something goes wrong, a card appears on the home screen: red when nothing could be loaded, orange when the lists are still usable. It says what is happening and offers Retry, Settings or Close.

Controls

Action	Remote control (Android TV, Samsung)	Phone	PC
Choose / confirm	Arrows, OK	Tap	Click, arrows + Enter
Go back	Back	Back	Right-click, Esc, ←
Next / previous channel	Up / Down, P+ / P−	Swipe or ◀ ▶	Mouse wheel, Up / Down
Go to a channel	Number keys	—	Number keys
Details and other channels	OK (Android TV)	Tap the picture	Click, I key
Pause (movies)	OK or Play/Pause	Tap the picture	Space, click
Forward / back (movies)	Right / Left	Progress bar	Right / Left
Favourite	Menu (Android TV), yellow key (Samsung)	Long press	Y key
Home screen tiles	Red, green, yellow, blue	Tap	R, G, Y, B
Full screen	—	Turn the device	F11, double-click
Settings: move between groups	Up / Down at the end of a group; Left = menu	Tabs at the top	Click in the menu

Common problems

Message shown	What to do
Invalid code / already used	Check the 8 characters; a code can only be used once: ask for a new one.
Licence expired	Enter a new code (the activation screen comes back by itself).
No connection (activation)	Activation needs Internet: check the Wi-Fi, then try again.
No Internet connection	Check the Wi-Fi, the cable or the router (restart it), then Retry.
⚠️ **Weak Internet connection**	The app has lowered the quality if it could. Move the device closer to the router, use a cable, or choose a lower maximum quality in Display and language.
The IPTV server does not answer	The app has already tried 3 times. Server under maintenance or overloaded: try again later; if it lasts, contact the provider.
Username or password rejected	Check the account in Lists and licence › Edit (capital letters included).
Subscription expired or disabled	Renew with the provider; the list then comes back by itself.
Too many connections	The account is used elsewhere (see active connections on the list's card): close the IPTV app on the other devices.
Category or tab with a padlock	Parental control: enter the PIN (0000 by default).
Video format not supported	Choose another version (HD, SD). On PC: V key for VLC.
No channels although everything seems fine	Clear the current search, then check “Manage categories”: they may all be hidden.
No programme shown	The provider gives no guide for this channel, or the list is M3U.