#### Instructions for Clarity Powertrain\_Report...

#### **Assumptions:**

- 1. You are using a known good ELM327 OBD2 device
  - Click here for specific recommendations
- 2. Your PC is running Linux, Windows, or macOS.
- 3. Your browser is Chrome, Edge, or Opera
  - Does not currently work with Android or iOS (future enhancement possible)
  - Firefox does not work at this time

\*Note - Remember, your PC must be located within range of Bluetooth (mine works up to maybe 30')

### **Operating Procedure:**

- Connect the Vgate Device to the vehicle
- 'Start' the car (Run Mode)
- Configure the device on your computer (see subsequent pages for Linux, Windows, or macOS steps)
- Browse to this page: <a href="https://clarity-phev.github.io/powertrain\_report/">https://clarity-phev.github.io/powertrain\_report/</a>
- Your page will look like this:



- Click on "Load Date from Clarity"
  - Select your device from the menu ('RFCOMM0' for Linux, or "COMx" for Windows)
- When data has been read, you will be prompted to save it on your machine as a log file
  - This is highly recommended as it lets you save a history of measurements
- Now, click on "Generate Report" to display the results.
  - If you want to save the formatted results, just 'print' this page to a .pdf file
- Note: by using the "Choose File" option, you can read a previously saved log file, and regenerate a report at any time.

### **Here is a sample report:** (OK, a little hard to read. Yours will be much nicer!)

# powertrain\_report

Load Data from Clarity Or, Read Existing Log File: Choose File SessJava\_2...13\_03\_11.txt ==> Generate Report Electric Powertrain Report Wed Oct 06 2021 13:03:19 GMT-0400 (Eastern Daylight Time) VIN: JHMZC5F38JC017995 Odometer: 26430 ml. Distance traveled since Battery Connected: 25225 ml. Distance since DTC Cleared: 25236 ml. HV Battery Module 1A Temperature: 22.8C, 73.0F HV Battery Module 2A Temperature: 22.8C, 73.0F HV Battery Module 3A Temperature: 22.6C, 72.7F HV Battery Module 1B Temperature: 22.7C, 72.9F HV Battery Module 2B Temperature: 22.4C, 72.3F HV Battery Module 3B Temperature: 22.6C, 72.7F HV Battery Module 4B Temperature: 22.7C, 72.9F ES Coolant Temperature 1: 22.5C, 72.5F ES Coolant Temperature 2: 22.6C, 72.7F ES Coolant Temperature 3: 22.9C, 73.2F ES Coolant Temperature 4: 22.5C, 72.5F Air Temperature Inside Vehicle: 22.00, 71.6F Air Temperature Outside Vehicle: 22.0C, 71.6F A/C Freon Pressure: 77.0 PSI HV Battery Voltage A: 340.4V HV Cell Max SOC A: 94.36% HV Cell Min SOC A: 93.65% SOC: 98% HV Battery Voltage B: 340.2V HV Cell Max SOC B: 94.21% HV Cell Min SOC B: 93.57% HV Battery Capacity (A+B): 48.02ah HV Battery Capacity A: 23.84ah HV Battery Capacity B: 24.18ah Input Voltage of Normal Charger: 3.4V Output Voltage of Normal Charger: 340.7V Charging Voltage Target: 4093.8mV Current Limit during Plug-in Charging: -201.9A Maintenance Minder A - Oil & Filter: 25 days 0 - General Inspection: 25 days 1 - Rotate Tires : 110 days 2 - Cabin Filter: 318 days 3 - Transmission Fluid: 1123 days 4 - Spark Plugs & Valves: 9999 days 5 - Engine Coolant : 2583 days 7 - Brake Fluid: 28 days 8 - Air Filter: 4262 days

Cell Statistics, mV:				
	min	max	delta	avg
Bank A	4055.4	4064.0	8.60	4058.8
Bank B	4056.2	4062.0	5.80	4058.7



## **Connection to Computer:**

- Connecting to Device in Linux
  - o Identify the Bluetooth ID of your device -
    - Search for Bluetooth devices... You will see something like this:



- The 'Android-Vlink' is what you want, and the Bluetooth ID in this example is DC:0D:30:97:FB:EE. This is unique to your device and will never change.
- From a Linux command window, use this commands:

\$sudo rfcomm bind 0 DC:0D:30:97:FB:EE 1 (replace the ID with your unique ID)

Check the result with this: \$rfcomm

This should report one of these two results, either should work:


rfcomm0: DC:0D:30:97:FB:EE channel 1 clean

or


rfcomm0: DC:0D:30:97:FB:EE channel 1 closed

If you need to manually disconnect the device, use this command: \$ sudo rfcomm release rfcomm0

- Connecting to Device in Windows
  - Go to Settings Bluetooth and Other Devices. You should see something like this:




In your Device Manager, you will see something like this:



- Connecting to Device in macOS
  - Connect to the device in System Settings > Bluetooth like a normal device
  - the vGate iCar Pro BLE 4.0 for iOS/Android's Bluetooth is 1234 (very important, 0000 for others perhaps)
  - Must use Chrome
  - As described above:
    - go to https://clarity-phev.github.io/powertrain\_report/
    - Connect to the device, Load Data, Generate Report

#### **Possible Errors, and Corrective Action:**

Dealing with the Bluetooth Device from a web program is a little tricky. This program is not extremely robust when it come to error detection an handling. Here are a few errors that sometimes occur, and what I have found can possibly help:



The program is written in Javacript. If there are any serious JavaScript programmers who are interested, your inputs are welcome.

This project is maintained in a GitHub repository here: <a href="https://github.com/clarity-phev/powertrain report">https://github.com/clarity-phev/powertrain report</a>

These instructions can be found in the repository as: 'How to Use.pdf'