

The gas release control circuit is designed in a double-lock system, that enables the discharge of gas after 30 seconds when the alarm of two zones are activated. The Gas Release Control Panel is manufactured according to the specifications of MS 1745 pt.2 2004 (equivalent to EN54-2:1996) and local CIFS requirements.

Gas Release Control Panel

Panel Control Description

- Mains & DC On Indicators
- Battery, Charger & Mains Fail Indicators
- Bell Line Open Indicator
- Test LED Switch
- Test Alarm Push-Button Switches
- Test Fault Push-Button Switches
- Zone Disable Toggle Switches
- Bell & Buzzer Silence Switches
- Earth Fault Indicator

- General Indicators (Fire/Fault/Disable)
- Alarm Reset Push-Button Switch
- Zone Alarm/Fault/Disable Indicators
- System's Voltage Indicator
- System's Current Consumption Indicator
- Gas Isolate Switch
- Signal to MFAP Isolate Switch
- Gas Release Indicator
- Abort Switch Indicator

Dimensions		
No. of Zones	Model	Sizes in mm (W x H x D)
2	MG-0200 (Normal)	400 x 370 x 170
2	MG-0200/W (Weatherproof)	400 x 380 x 190
Note: Specifications are subject to change without prior notice		

Specifications -

AC Input Voltage : 240Vac ± 10%, 50Hz, Single Phase

DC Output Voltage : 24 – 26 Vdc

Standby Battery : 24Vdc Rechargeable Type

Charger Output Voltage : 26 – 29 Vdc Adjustable

Max Charging Current : 1.5A

End-of-line Resistor : 22K ohm ,1/4W, 5%, carbon film type

(for Alarm zone)

End-of-line Resistor : 4.7K ohm , 1/4W, 5%, carbon film type

(for bell output)

Bell/Tripping/Output : 24 – 26 Vdc

Standby current per zone: 1.03mA

Input / Output contacts : Normally open voltage free contact
Chassis Colour/Material : Epoxy Signal Red/1.5mm thick mild

steel (16 Gauge)

All parts have a warranty of 12 months againts manufacturing defect

Wiring size : Input zones/indications - 1.5mm² PVC cable

(from field) Input/output contacts - 1.5mm² PVC cable

Output devices - 2.5mm² PVC cable

Curtain Trip : Trips the curtain once both zones in alarm

Bell Intermittent : Any single zone alarm, rings intermittently

Both zones alarm, rings continuously

Flashing Light : Red Flash when any or both zones in alarm (Green/Red) Red ON once gas discharging started

Green ON when normal, OFF otherwise
: ON after 25-30 sec. once both zones alarm

Gas Discharge Output

Abort Switch

Dutput

: Pressed & hold to stop the discharging of gas



CME PYROSHIELD SDN BHD (681836-v)
Lot 19, Jalan Delima 1/1,
Subang Hi-Tech Industrial Park,
Batu Tiga, 40000 Shah Alam,
Selangor Darul Ehsan, MALAYSIA
Tel: +603 5633 1188 Fax: +603 5631 2173

www.puroshieldasia.com

