

(7) Zero Point Setting Mode

	F1	SET	Used to set new data
	F2	ADD	Used to add the input data to the currently stored data
	F3	CAL	Used to start math operation for the input data
	F4	SEARCH	Used for page or number search
	F5	AXIS CHANGE	Used to change display page for the other axes
	F6		
	F7		
	F8	[EXTEND]	Extensive functions

	F1	READ	Used to input zero offset data
	F2	PUNCH	Used to output zero offset data to tape punch
	F3	VERIFY	Used to verify zero offset data
	F4		
	F5		
	F6		
	F7	BACK UP	Used to back up data
	F8	[EXTEND]	Extensive functions