



FRONT PANEL SWITCH INPUT





W K

















PINS 29, 37 ARE FOR SERIAL VCC POWER ENABLE

PINS 34, 36 ARE FOR WAIT STATE CIRCUIT ENABLE

PINS 22, 24 ARE FOR EXTERNAL RESET SWITCH

PINS 26, 28 ARE FOR IM2 CIRCUIT ENABLE

PINS 30, 32 ARE FOR INTERRUPT 0 ENABLE