WORKFLOW

Coal Movement from Railway Siding to Rake Dispatch

STEP 1: COAL RECEIPT AT RAILWAY SIDING (ROAD → SIDING)

- Coal is dispatched from mine by trucks.
- **WB operator** updates:
  - Trips received **shift-wise** (e.g., 100 trips in a shift)
  - Quantity received in siding
- Siding stock keeps increasing continuously.

Decision Point

- If **siding stock becomes sufficient for one rake**, the process moves to indent stage.

STEP 2: INDENT FOR RAKE PLACEMENT

- **Railway Siding In-Charge** checks:
  - Available siding stock
  - Target rake quantity
- Based on stock availability, **indent is raised to Railways** for rake placement.

Important:

- Indent is **stock-driven**, not time-driven.

STEP 3: RAKE AVAILABILITY & PLACEMENT BY RAILWAYS

- After receiving indent:
  - Railways place a rake **based on availability**
  - Placement may be:
    - Immediate
    - Delayed (subject to railway constraints)

System Note:

Delay in rake placement is **railway responsibility**, not siding.

STEP 4: TXR INSPECTION (BEFORE LOADING)

- Once rake is placed:
  - **TXR (Train Examiner) inspection** is carried out
  - Conducted by **Railway staff** in presence of **Railway Guard**

TXR Inspection Includes:

- Checking all wagon doors
- Checking wagon condition (fit / unfit)

Output of TXR:

- **Unfit Wagon Memo** (if any wagons are unfit)

Time Rule

- **Maximum time allowed: 1 hour 40 minutes**
- This time **includes** the loading free time of **3 hours**

STEP 5: MARKING OF UNFIT WAGONS

- If TXR declares wagons as unfit:
  - Our team marks them clearly:
    - **Night:** Radium reflectors / red lights
    - **Day:** Red flags
- These wagons are **excluded from loading**

STEP 6: START OF LOADING TIME (CRITICAL STEP)
Loading time starts from rake placement
Loading Rules:

- **Maximum free loading time: 3 hours**
- Even **5 minutes extra** beyond 3 hours:
    - Railway charges **1 full hour penalty**

Penalty Rate:

- ₹15,440 + GST **per hour**

STEP 7: WAGON LOADING PROCESS

- Loading starts **only after TXR clearance**
- Loader operators:
    - Load wagons **one by one**
    - Ensure:
        - No overloading
        - No underloading
- **Unfit wagons are skipped**

Objective:

- Load within CC limits
- Finish loading within free time

STEP 8: POST-LOADING INSPECTION BY RAILWAY GUARD

- After loading completion:
    - Message given to **Railway Guard**
- Guard inspects:
    - Coal spillage on tracks
    - Coal between wagons

If Spillage Found:

- Spillage is removed and cleared
- Track made safe

STEP 9: CLEARANCE FOR MOVEMENT

- After clearance:
    - Guard informs **Loco Pilot**
    - Permission given to move rake

STEP 10: IN-MOTION WEIGHMENT (VERY SENSITIVE STEP)

- Loco pilot moves rake from:
    - Loading track → **In-motion weighment track**

Time Limit

- **20 minutes** allowed
- This 20 minute is **included in the same 3-hour free time**

Speed Conditions:

- Rake speed must be **5–7 kmph**
- Issues if:
    - Speed is higher
    - Sudden brake applied
    - Jerks during movement

These issues can cause:

- Wrong weighment
- Overloading indication

If Weighment Fails:

- Rake is taken forward
- Brought back again on weighment track
- Re-weighment done

STEP 11: GENERATION OF COMMERCIAL RR (FINAL & BINDING)

- After **successful weighment**:
    - **Commercial Railway Receipt (RR)** is generated

RR Contains:

- Charged weight
- Overloading / underloading
- Time taken
- Demurrage
- Penalties
- Freight & GST

RR is the final authority document

STEP 12: RECEIPT OF RR & DOCUMENTS

At Railway Siding, we receive:

- In-motion weighment slip
- TXR unfit memo
- Forwarding copy

RR Flow:

- Railway sends RR **directly to WBPDCL**
- From WBPDCL, RR comes to us
- **Only after RR receipt**, we know:
    - Exact penalties
    - Charges
    - Overweight details