

上傳工具





上傳工具





將USB上傳工具接入 Type-C 及電腦如果在裝置管理員出現驚嘆號,表示需要安裝驅動程式



驅動程式安裝

開啟網頁:

https://www.silabs.com/developers/usb-to-uart-bridge-vcp-drivers?tab=downloads

驅動程式安裝

Windows 選擇

CP210x Windows Drivers

Mac 選擇

CP210x VCP MAC OSX Driver

	nds	
Software (10)	Software · 10	
	CP210x Universal Windows Driver	v11.3.0 6/24/2023
	CP210x VCP Mac OSX Driver	v6.0.2 10/27/2021
	CP210x Windows Drivers	v6.7.6 9/4/2020
	CP210x Windows Drivers with Serial Enumerator	v6.7.6 9/4/2020
	CP210x_5x_AppNote_Archive	9/4/2020
	CP210x_VCP_Win2K	9/4/2020
	Linux 2.6.x VCP Revision History	9/4/2020
	Linux 3.x.x/4.x.x/5.x.x VCP Driver €	v3.x.x/4.x.x/5.x.x 1/29/2021
	VCP Driver for WinCE60	v2.1 9/4/2020
	VCP Drivers for WinCE50	v2.1 9/4/2020

下載後, 並解壓縮。找到

CP210xVCPInstaller_x64.exe

並執行它



按下一步繼續. 按指示安裝。

CP210x USB to UART Bridge Driver Installer

Welcome to the CP210x USB to UART Bridge Driver Installer

This wizard will help you install the drivers for your CP210x USB to UART Bridge device.

若要繼續,請按[下一步]。

取消

安裝 Arduino IDE

下載點

arduino.cc/en/software



Arduino IDE 2.1.0

The new major release of the Arduino IDE is faster and even more powerful! In addition to a more modern editor and a more responsive interface it features autocompletion, code navigation, and even a live debugger.

For more details, please refer to the **Arduino IDE 2.0** documentation.

Nightly builds with the latest bugfixes are available through the section below.

DOWNLOAD OPTIONS


Windows Win 10 and newer, 64 bits

Windows MSI installer
Windows ZIP file

Linux Applmage 64 bits (X86-64)
Linux ZIP file 64 bits (X86-64)

macOS Intel, 10.14: "Mojave" or newer, 64 bits
macOS Apple Silicon, 11: "Big Sur" or newer, 64 bits

Release Notes



Arduino 設定

複製以下連結

https://github.com/ambiot/ambd arduino/raw/master/Arduino package/package realtek amebad index.json

開啟 File / preferences

在 Additional boards manager URLs 的欄位 貼上 上述網址, 點 OK 結束設定

Additional boards manager URLs:


Arduino 設定

點取左側第二個圖示, Boards Manager

```
sketch_may2a.ino
       void setup() {
         // put your setup code here, to run once:
       void loop() {
         // put your main code here, to run repeatedly:
  10
```

Arduino 設定


輸入 ameba






● Arduino 設定

透過 USB 連接 開發板



選擇 Select other board and port


Board 選擇 Datalogger Series(RTL8720DF)




Arduino 設定

第一個程式


打開 File / Examples / 01.Basics / Blink









- 範例程式及資料(操作手冊及程式庫)
 - https://github.com/cold63/Datalogger_lot/tree/main



● 安裝 Zip 程式庫的方法



Realtek 提供的 Arduino 範例



常用程式庫安裝

- RS-485
 - o ModbusMaster by Doc Walker (Arduino IDE 安裝)
 - Modbus-Master-Slave-for-Arduino (下載安裝)
- SD Card
 - SdFat(下載安裝)
- Oled
 - u8g2 (Arduino IDE 安裝)

