

This is the settings that have to be set correctly for the nursery to work as well as the headphone monitors from vMix.

Nursery TV needs to be on HDMI 2 (Volume around 15 to start so it's not too loud)

vMix Settings: Click Settings (Top right grey button in vMix)

Setting Pop-Up window comes up

In left hand column, click Audio Outputs

Master Output should say: Default Windows Playback Device --- 1+2

Headphones should say: Speakers (Realtek High Definition Audio) – 1+2

Now we need to check the Windows Audio Output Settings:

Click the speaker icon in the bottom right corner of the computer screen, it is directly to the left of where it displays the current time and date.

If the audio output reads **HDMI Extender (NVIDIA High Definition Audio)**, everything should work.

If it doesn't, click the ^ arrow and select the **HDMI Extender (NVIDIA High Definition Audio)** as the output.

Things to Doublecheck:

If no audio is getting to the Master on the right side of the screen under the Audio Mixer check to make sure that the M button is clicked and that it is green. This button is the "Send to Master" button. No audio will pass if this is not green (grey means not selected)

If no audio is getting to the #7 Audio window at all, double check that the Audio is properly routed to that window. Look on the left bottom side of the screen where all of the inputs are. (Example: 1 (Camera 1), 2 (Camera 2), 3 (Lower 3rds) and so on). Find the 7 (Audio) window and click the gear (for settings) that is in that window. This will open the setting for that input. When that window opens up, to the right of General, it should say Microphone (Scarlett 2i2 USB). If that is not case, click on "Change" that is to the right under the X for the close window. Click yes when the pop up appears. Look for the Audio Device drop down menu, and select Microphone (Scarlett 2i2 USB). Click ok. You should now have audio.