`TUYA_COMMON_PRIVATE_CLUSTER` (0xE000)

```
<td><code>TUYA_COMMON_PRIVATE_CLUSTER</code> (0xE000)</td>
```

Attributes

ID	Name	Data type (ID)	Range	Default
0xD001	Cycle timing (Tuya-specific attribute)	array	/	/
0xD002	Random timing (Tuya-specific attribute)	array	/	/
0xD003	Inching switch (Tuya-specific attribute)	array (0x48)	/	/
0xFFFD	ClusterRevision	uint16 (0x21)	0x0000 to 0xffff	0x0001

```
<tr><td>0xD001</td>
<td>Cycle timing (Tuya-specific attribute)</td>
<td>array</td></tr>
<tr><td>0xD002</td>
<td>Random timing (Tuya-specific attribute)</td>
<td>array</td></tr>
<tr><td>0xD003</td>
<td>Inching switch (Tuya-specific attribute)</td>
<td>array (0x48)</td></tr>
<tr><td>0xFFFD</td>
<td>ClusterRevision</td>
<td>uint16 (0x21)</td>
<td>0x0000 to 0xffff</td>
<td>0x0001</td></tr>
```

Payload format

Server to client	0xE000: TUYA_COMMON_PRIVATE	0xD002: Tuya-specific attribute	Payload

Feature	Length	Description
Version number	1 byte	0x00
Node length	1 byte	0x0A
Switch	1 byte	• Bit 0: used to turn on or off the node. 0: Off. 1: On. • Bit 1 to bit 7: indicates the channel ID.

```
<tr> <td>Version number</td> <td>1 byte</td> <td>0x00</td> </tr>
<tr> <td>Node length</td> <td>1 byte</td> <td>0x0A</td> </tr>
<tr> <td>Switch</td> <td>1 byte</td> <td><ul>
<li>Bit 0: used to turn on or off the node.
<br>0: Off. <br>1: On.</li>
<li>Bit 1 to bit 7: indicates the channel ID.</li>
</ul></td></tr>
```