List of Keycodes

This is the reference page for keycodes used by behaviors. Use the table of contents (on the right or the top) for easy navigation.



WARNING

Take extra notice of the spelling of the keycodes, especially the shorthand spelling. Otherwise, it will result in an elusive parsing error!

(!) KEYBOARD VS. CONSUMER KEYCODES

In the below tables, there are keycode pairs with similar names where one variant has a K_ prefix and another C_. These variants correspond to similarly named usages from different HID usage pages, namely the "keyboard/keypad" and "consumer" ones respectively.

In practice, some OS and applications might listen to only one of the variants. You can use the values in the compatibility columns below to assist you in selecting which one to use.

Keyboard

Letters

Names	Description	C	W	L	Α	m	i
A	a and A	ď	*	*	*	*	*
В	b and B	ď	$\stackrel{\wedge}{\rightleftharpoons}$	*	$\stackrel{\wedge}{\simeq}$	$\stackrel{\wedge}{\simeq}$	*
C	c and C	ď	*	*	*	*	*
D	d and D	ď	*	*	$\stackrel{\wedge}{\rightleftharpoons}$	À	*

E	e and E	ď	*	*	*	*	*
F	f and F	ď	*	À	Ŷ	*	*
G	g and G	ď	*	À	$\stackrel{\wedge}{\cong}$	$\stackrel{\wedge}{\rightleftharpoons}$	*
H	h and H	Ľ	*	*	*	*	*
I	i and I	Ľ	*	À	$\stackrel{\wedge}{\Longrightarrow}$	$\stackrel{\wedge}{\rightleftharpoons}$	*
J	j and J	Ľ	*	À	*	*	*
K	k and K	Ľ	*	*	*	*	*
L	I and L	ď	*	*	Ŷ	*	*
M	m and M	Ľ	*	$\stackrel{\wedge}{\rightleftharpoons}$	$\stackrel{\wedge}{\rightleftharpoons}$	*	*
N	n and N	ď	*	*	Ŷ	*	*
0	o and O	Ľ	*	*	$\stackrel{\wedge}{\rightleftharpoons}$	*	*
P	p and P	Ľ	*	*	*	*	*
Q	q and Q	ď	*		Ŷ	*	*
R	r and R	Ľ	*		Ŷ	*	*
S	s and S	ď	*	À	Ŷ	*	*
T	t and T	Ľ	*	À	Ŷ	*	*
U	u and U	ď	*	À	Ŷ	*	*
V	v and V	Ľ	*	À	Ŷ	*	*
W	w and W	ď	*	À	Ŷ	*	*
X	x and X	Ľ	*	Ŷ	Ŷ	*	*
Y	y and Y	Ľ	À	Ŷ	*	*	*
Z	z and Z	Ľ	*	*	*	*	*

Numbers

Names	Description	ď	W	L	Α	m	i
NUMBER_1 N1	1 and ! EXCLAMATION	ď	*	*	*	*	Ŷ

NUMBER_2 N2	2 and @ AT SIGN	ď	À	*	*	*	*
NUMBER_3	3 and # HASH / POUND	ď	À	*	À	*	À
NUMBER_4	4 and \$ DOLLAR	ď	À	*	À	*	*
NUMBER_5	5 and % PERCENT	ď	À	À	À	À	À
NUMBER_6	6 and CARET	ď	À	*	À	*	À
NUMBER_7	7 and & AMPERSAND	ď	À	À	À	À	*
NUMBER_8	8 and * ASTERISK / STAR	ď	À	*	*	*	*
NUMBER_9	9 and (LEFT PARENTHESIS	ď	À	*	*	*	*
NUMBER_Ø NØ	0 and) RIGHT PARENTHESIS	ď	À	À	À	À	À

Symbols / Punctuation

Names	Description	ď	W	L	Α	m	i
EXCLAMATION EXCL	! EXCLAMATION	ď	☆	☆	☆	☆	☆
AT_SIGN AT	@ AT SIGN	ď	☆	☆	☆	☆	☆
HASH POUND	# HASH / POUND	ď	À	À	À	À	*
M: Windows	L : Linux	nacOS			i : i0	os	

PRCNT	% PERCENT	ď	*	*	*	À	*
CARET	CARET	ď	☆	À	☆	☆	☆
AMPERSAND AMPS	& AMPERSAND	ď	À	À	À	À	*
ASTERISK ASTRK STAR	* ASTERISK / STAR	ď	☆	☆	☆	☆	*
LEFT_PARENTHESIS	LEFT PARENTHESIS	ď	☆	À	*	*	÷
RIGHT_PARENTHESIS RPAR	RIGHT PARENTHESIS	ď	☆	☆	☆	☆	À
EQUAL	= and + EQUAL PLUS	ď	À	÷	À	À	*
PLUS	+ PLUS	ď	☆	☆	☆	☆	*
MINUS	- and _ MINUS UNDERSCORE	ď	☆	À	☆	*	÷
UNDERSCORE UNDER	UNDERSCORE	ď	☆	À	*	*	*
SLASH	/ and ? FORWARD SLASH QUESTION MARK	ď	À	À	À	À	À
QUESTION QMARK	? QUESTION MARK	ď	À	À	À	À	÷
BACKSLASH BSLH	and D BACKSLASH PIPE	ď	À	À	À	À	À
PIPE	PIPE	ď	À	Ŕ	À	À	*
NON_US_BACKSLASH NON_US_BSLH NUBS	Non-US \ and BACKSLASH PIPE	ď	*	*	☆	*	*

PIPE2	PIPE	C	*	*	*	*	*
SEMICOLON SEMI	; and : SEMICOLON COLON	ď	*	*	*	*	*
COLON	COLON	ď	*	À	*	*	*
SINGLE_QUOTE SQT APOSTROPHE APOS	and " APOSTROPHE QUOTE (DOUBLE)	ď	*	*	*	*	*
DOUBLE_QUOTES	QUOTE (DOUBLE)	ď	À	÷	À	À	÷
СОММА	, and < COMMA LESS THAN	ď	*	*	À	*	*
LESS_THAN	LESS THAN	ď	À	Ŷ	À	À	÷
PERIOD DOT	and > PERIOD GREATER THAN	ď	À	À	À	À	☆
GREATER_THAN	> GREATER THAN	ď	À	À	À	À	÷
LEFT_BRACKET	[and { LEFT BRACE	ď	À	À	À	À	À
LEFT_BRACE	{ LEFT BRACE	ď	À	À	À	À	÷
RIGHT_BRACKET] and } RIGHT BRACKET RIGHT BRACE	ď	À	À	À	À	À
RIGHT_BRACE	RIGHT BRACE	ď	À	*	À	*	*
GRAVE	grave accent Tilde	ď	*	*	*	*	*
TILDE	TILDE	C	*	÷	*	*	*

NUN_US_HASH	Non-US # and ~ HASH/POUND TILDE	ď	À	À	$\stackrel{\wedge}{\rightleftharpoons}$	$\stackrel{\wedge}{\Longrightarrow}$	À	
TILDE2	TILDE	ď	*	*	Ŷ	*	*	

Control & Whitespace

Names	Description	ď	W	L	Α	m	i
ESCAPE ESC	Escape	ď	À	÷	÷	À	À
RETURN ENTER RET	Return (Enter)	ď	*	*	*	*	*
RETURN2 RET2	Return	ď	×	×	×	7	7
SPACE	Space	ď	À	*	*	*	*
TAB	Tab	ď	*	*	*	*	*
BACKSPACE BSPC	Backspace	ď	☆	À	À	À	☆
DELETE	Delete	ď	☆	À	À	À	☆
INSERT	Insert	ď	☆	À	À	À	☆

Navigation

Names	Description	ď	W	L	Α	m	i
HOME	Home	ď	*	*	$\stackrel{\wedge}{\Longrightarrow}$	*	*
END	End	ď	*	*	*	*	*
PAGE_UP PG_UP	Page Up	ď	*	*	*	*	*
PAGE DOWN							

PG_DN	Page Down	ď	*	*	☆	À	*
UP_ARROW UP	UP ARROW	ď	À	*	*	☆	*
DOWN_ARROW DOWN	DOWN ARROW	ď	À	À	÷	À	÷
LEFT_ARROW LEFT	LEFT ARROW	ď	☆	÷	÷	À	÷
RIGHT_ARROW RIGHT	RIGHT ARROW	ď	☆	÷	÷	À	÷
K_APPLICATION K_APP K_CONTEXT_MENU K_CMENU	Application (Context Menu)	ď	À	ŵ	÷	ŵ	☆ 1

Notes: ¹ Key press is registered, but has no visible effect in tested apps (Gmail, Safari, Notes) iPhone 6 / iOS 12.4.6

Locks

Names	Description	ď	W	L	Α	m	i
CAPSLOCK CAPS CLCK	Caps Lock	ď	À	À	*	*	À
LOCKING_CAPS LCAPS	Locking Caps Lock	ď	×	×	×	7	7
SCROLLLOCK SLCK	Scroll Lock	ď	À	À	À	*	☆
LOCKING_SCROLL LSLCK	Locking Scroll Lock	ď	*	×	×	7	7
LOCKING_NUM LNLCK	Locking Num Lock	ď	?	×	×	?	7

F Keys

Names	Description	Ľ	W	L	A	m	i
F1	F1	ď	$\stackrel{\wedge}{\rightleftharpoons}$	*	*	*	*
F2	F2	ď	*		*	*	*
F3	F3	ď	*	*	*	*	*
F4	F4	ď	*	*	*	*	*
F5	F5	ď	*	*	*	*	*
F6	F6	ď	*	Ŷ	Ŷ	Ŷ	*
F7	F7	ď	*	*	*	*	*
F8	F8	ď	*	*	*	*	*
F9	F9	ď	*	*	*	*	*
F10	F10	ď	*	$\stackrel{\wedge}{\rightleftharpoons}$	*	*	*
F11	F11	ď	*	*	*	*	*
F12	F12	ď	*	*	*	*	*
F13	F13	ď	*	$\stackrel{\wedge}{\cong}$	×	*	*
F14	F14	ď	*	*	×	*	*
F15	F15	ď	*	*	×	*	*
F16	F16	C	*	*	×	*	*
F17	F17	ď	*	$\stackrel{\wedge}{\rightleftharpoons}$	×	*	*
F18	F18	ď	*	*	×	*	*
F19	F19	ď	*	*	×	*	*
F20	F20	ď	*	*	×	À	*
F21	F21	ď	*		×	À	À
F22	F22	ď	*		×	*	À
F23	F23	ď	*		×	*	À
F24	F24	ď	*	À	×	*	*

International

Names	Description	ď	W	L	Α	m	i
INTERNATIONAL_1							
INT1	ろ (International 1)	ď	×	*	×	7	7
INT_R0							
INTERNATIONAL_2							
INT2				_			
INT_KATAKANAHIRAGANA	かな (International 2)	ď	×	*	×	7	7
INT_KANA							
INTERNATIONAL_3							
INT3	¥ (International 3)	ď	×	*	×	7	7
INT_YEN							
INTERNATIONAL_4							
INT4	变換 (International 4)	ď	×	*	×	7	7
INT_HENKAN							
INTERNATIONAL_5							
INT5	無変換 (International 5)	ď	×	*	×	7	7
INT_MUHENKAN							
INTERNATIONAL_6							
INT6	, (International 6)	ď	×	*	×	7	7
INT_KPJPCOMMA	カンマ						
INTERNATIONAL_7		_					
INT7	International 7	€ 2	7	X	×	7	7
INTERNATIONAL_8							-
INT8	International 8	€ 2	7	X	×	?	7
INTERNATIONAL_9							
INT9	International 9	ď	?	X	×	?	7

Language

Names	Description	ď	W	L	Α	m	i	

LANGUAGE_1							
LANG1	한/영 (Language 1)	C	*	*	×	7	7
LANG_HANGEUL							
LANGUAGE_2							
LANG2	한자 (Language 2)	ď			×	7	7
LANG_HANJA							
LANGUAGE_3							
LANG3	カタカナ (Language 3)	ď	×		×	7	7
LANG_KATAKANA							
LANGUAGE_4							
LANG4	ひらがな (Language 4)	ď	×	*	×	7	7
LANG_HIRAGANA							
LANGUAGE_5							
LANG5	半角/全角 (Language 5)	ď	×	*	×	7	7
LANG_ZENKAKUHANKAKU							
LANGUAGE_6							
LANG6	Language 6	C	?	×	×	7	?
LANGUAGE_7							
LANG7	Language 7	C	?	X	×	?	?
LANGUAGE_8							
LANG8	Language 8	C [*]	?	X	×	7	?
LANGUAGE_9							
LANG9	Language 9	C	?	X	×	7	7

Miscellaneous

Names	Description	ď	W	L	Α	m	i
PRINTSCREEN PSCRN	Print Screen	ď	☆	÷	÷	À	À
PAUSE_BREAK	Pause / Break	ď	*	*	*	*	*
ALT_ERASE	Alternate Erase	ď	?	×	×	?	?
SYSREQ							

ATTENTION	SysReq / Attention	ď	7	×	×	7	?
K_CANCEL	Cancel (Keyboard)	ď	7	×	×	7	7
CLEAR	Clear	ď	?	$\stackrel{\wedge}{\rightleftharpoons}$	×	7	?
CLEAR_AGAIN	Clear / Again	ď	?	×	×	7	?
CRSEL	CrSel / Props	ď	?	×	×	7	7
PRIOR	Prior	ď	?	×	×	7	?
SEPARATOR	Separator	ď	?	×	×	7	7
OUT	Out	ď	?	×	×	7	7
OPER	Oper	ď	?	X	×	7	7
EXSEL	ExSel	ď	7	×	×	7	7
K_EDIT	Edit (Keyboard)	ď	7	*	×	×	×

Modifiers

The Modifiers page includes further information.

Names	Description	ď	w	L	Α	m	i
LEFT_SHIFT LSHIFT LSHFT LS(code)	Left Shift ப	ď	*	*	*	*	☆
RIGHT_SHIFT RSHIFT RSHFT RS(code)	Right Shift 쇼	ď	☆	*	*	*	☆
LEFT_CONTROL LCTRL LC(code)	Left Control	ď	*	*	*	*	*
RIGHT_CONTROL RCTRL	Right Control	ď	À	À	À	À	☆

RC(code)							
LEFT_ALT LALT LA(code)	Left Alt	ď	÷	*	☆	☆	☆
RIGHT_ALT RALT RA(code)	Right Alt	ď	÷	÷	÷	÷	☆
LEFT_GUI LGUI LG(code) LEFT_WIN LWIN LEFT_COMMAND LCMD LEFT_META LMETA	Left GUI (Windows / Command / Meta)	얍	☆	☆	☆	☆	*
RIGHT_GUI RGUI RG(code) RIGHT_WIN RWIN RIGHT_COMMAND RCMD RIGHT_META RMETA	Right GUI (Windows / Command / Meta)	ď	☆	☆	☆	☆	☆

Keypad

Names	Description	Ľ	W	L	Α	m	i
KP_NUMLOCK KP_NUM KP_NLCK	Numlock and Clear	ď	*	*	*	?	7
(ID 01 = 10							

NP_CLEAK	Clear	ď	?	*	×	×	×
CLEAR2	Clear	ď	?	$\stackrel{\wedge}{\Longrightarrow}$	$\stackrel{\wedge}{\Longrightarrow}$?	?
KP_ENTER	Enter	ď	*	*	*	*	*

Numbers

Names	Description	ď	W	L	Α	m	i
KP_NUMBER_1 KP_N1	Keypad 1 and End	ď	À	÷	÷	À	À
KP_NUMBER_2 KP_N2	Keypad 2 and Down Arrow	ď	À	*	*	*	*
KP_NUMBER_3 KP_N3	Keypad 3 and Page Down	ď	÷	*	*	*	*
KP_NUMBER_4 KP_N4	Keypad 4 and Left Arrow	ď	*	*	*	*	*
KP_NUMBER_5 KP_N5	Keypad 5	ď	☆	☆	☆	☆	À
KP_NUMBER_6 KP_N6	Keypad 6 and Right Arrow	ď	÷	*	*	*	☆
KP_NUMBER_7 KP_N7	Keypad 7 and Home	ď	÷	*	*	*	☆
KP_NUMBER_8 KP_N8	Keypad 8 and Up Arrow	ď	÷	*	*	*	☆
KP_NUMBER_9 KP_N9	Keypad 9 and Page Up	ď	*	*	*	*	*
KP_NUMBER_0 KP_N0	Keypad 0 and Insert	C	*	*	*	*	*

Symbols / Operations

Names	Description	ď	W	L	Α	m	i	

KP_PLUS	+ PLUS	ď	*		À	À	*
KP_MINUS KP_SUBTRACT	- MINUS	ď	*	À	À	À	À
KP_MULTIPLY KP_ASTERISK	* MULTIPLY	ď	*	À	À	*	*
KP_DIVIDE KP_SLASH	/ DIVIDE	ď	À	À	À	☆	☆
KP_EQUAL	= EQUAL	ď	×	÷	À	7	À
KP_EQUAL_AS400	= (AS/400 keyboards) EQUAL	ď	×	×	×	7	7
KP_DOT	and Delete	ď	*	Ŷ	À	*	*
KP_COMMA	COMMA	ď	×	Ŷ	À	7	?
KP_LEFT_PARENTHESIS KP_LPAR	(LEFT PARENTHESIS	ď	×	À	À	×	×
KP_RIGHT_PARENTHESIS KP_RPAR	RIGHT PARENTHESIS	ď	×	☆	À	×	×

Editing

Cut, Copy, Paste

Names	Description	ď	W	L	Α	m	i
C_AC_CUT	Cut (Consumer AC)	ď	×	*	×	×	7
K_CUT	Cut (Keyboard)	ď	X	$\stackrel{\wedge}{\rightleftharpoons}$	×	☆ 1	7
C_AC_COPY	Copy (Consumer AC)	ď	×	*	×	×	7
K_COPY	Copy (Keyboard)	ď	X	$\stackrel{\wedge}{\Longrightarrow}$	×	☆ 1	7
C_AC_PASTE	Paste (Consumer AC)	ď	×	$\stackrel{\wedge}{\rightleftharpoons}$	×	×	7

K_PASTE	Paste (Keyboard)	ď	×	*	×	☆ 1	7
Notes: 1 On macOS, K_CUT,	K_COPY), and K_PASTE are recognized as key press	es, bı	ut do	nothi	ng by	/ defa	ult.

Undo, Redo

Names	Description	ď	W	L	Α	m	i
C_AC_UNDO	Undo (Consumer AC)	ď	×	*	×	×	7
K_UNDO	Undo (Keyboard)	ď	×	*	×	☆ 1	7
C_AC_REDO	Redo / Repeat (Consumer AC)	ď	×	*	×	X	7
K_AGAIN K_REDO	Again (Keyboard)	ď	×	$\stackrel{\wedge}{\rightleftharpoons}$	×	☆ 1	?

Notes: 1 On macOS, K_CUT, K_COPY, and K_PASTE are recognized as key presses, but do nothing by default.

Media

Sound / Volume

Names	Description	ď	W	L	A	m	i
C_VOLUME_UP C_VOL_UP	Volume Up (Consumer)	ď	*	*	À	À	
K_VOLUME_UP K_VOL_UP	Volume Up (Keyboard)	ď	×	ŵ	À	À	?
K_VOLUME_UP2 K_VOL_UP2	Volume Up (Keyboard)	ď	×	☆	☆	×	×
C_VOLUME_DOWN C_VOL_DN	Volume Down (Consumer)	ď	☆	À	À	À	À
K_VOLUME_DOWN K_VOL_DN	Volume Down (Keyboard)	ď	×	À	À	À	7
K_VOLUME_DOWN2 K_VOL_DN2	Volume Down (Keyboard)	ď	×	*	À	×	×

C_MUTE	Mute (Consumer)	ď	*		$\stackrel{\wedge}{\rightleftharpoons}$	*	*
K_MUTE	Mute (Keyboard)	ď	×	$\stackrel{\wedge}{\cong}$	$\stackrel{\wedge}{\cong}$	$\stackrel{\wedge}{\cong}$	7
K_MUTE2	Mute (Keyboard)	ď	×	$\stackrel{\wedge}{\rightleftharpoons}$	☆	×	×
C_ALTERNATE_AUDIO_INCREMENT C_ALT_AUDIO_INC	Alternate Audio Increment (Consumer)	ď	?	×	÷	7	7
C_BASS_B00ST	Bass Boost (Consumer)	ď	X	À	X	7	7

Display

Names	Description	C	W	L	Α	m	i
C_BRIGHTNESS_INC C_BRI_INC C_BRI_UP	Increase Brightness (Consumer)	ď	À	ŵ	ŵ	ŵ	À
C_BRIGHTNESS_DEC C_BRI_DEC C_BRI_DN	Decrease Brightness (Consumer)	ď	☆	÷	÷	÷	À
C_BRIGHTNESS_MINIMUM C_BRI_MIN	Minimum Brightness (Consumer)	ď	×	À	×	?	?
C_BRIGHTNESS_MAXIMUM C_BRI_MAX	Maximum Brightness (Consumer)	ď	×	*	×	?	7
C_BRIGHTNESS_AUTO C_BRI_AUTO	Auto Brightness (Consumer)	ď	×	À	×	?	?
C_BACKLIGHT_TOGGLE C_BKLT_TOG	Backlight Toggle (Consumer)	ď	×	À	×	?	?
C_ASPECT	Aspect (Consumer)	ď	×	*	×	?	7
C_PIP	Picture-in-Picture Toggle (Consumer)	ď	×	×		7	7

Media Controls

Names	Description	ď	W	L	Α	m	i
C_RECORD							

C_REC	Record (Consumer)	ď	×	*	*	7	7
C_PLAY	Play (Consumer)	ď	*	*	*	7	7
C_PLAY_PAUSE C_PP	Play / Pause (Consumer)	ď	☆	À	À	À	À
K_PLAY_PAUSE K_PP	Play / Pause (Keyboard)	ď	×	☆	☆	×	×
C_PAUSE	Pause (Consumer)	ď	*	*	*	7	7
C_STOP	Stop (Consumer)	ď	×	À	*	?	?
K_STOP2	Stop (Keyboard)	ď	×	*	*	×	×
K_ST0P3	Stop (Keyboard)	ď	×	*	*	×	×
C_STOP_EJECT	Stop / Eject (Consumer)	Ľ	7	×	×	7	7
C_EJECT	Eject (Consumer)	ď	7	*	*	7	7
K_EJECT	Eject (Keyboard)	ď	?	*	*	×	×
C_NEXT	Next (Consumer)	ď	*	*	*	*	*
K_NEXT	Next (Keyboard)	ď	×	*	*	×	X
C_PREVIOUS C_PREV	Previous (Consumer)	ď	☆	À	À	À	À
K_PREVIOUS K_PREV	Previous (Keyboard)	ď	×	À	À	×	×
C_FAST_FORWARD C_FF	Fast Forward (Consumer)	ď	*	*	*	7	7
C_REWIND C_RW	Rewind (Consumer)	ď	*	*	*	7	7
C_SLOW	Slow (Consumer)	ď	×	*	×	7	7
C_SLOW_TRACKING C_SLOW2	Slow Tracking (Consumer)	ď	×	À	×	?	?
C_REPEAT	Repeat (Consumer)	ď	×	*	×	7	7
C_RANDOM_PLAY C_SHUFFLE	Random Play (Consumer)	ď	×	À	×	7	7

C_CAPTIONS C_SUBTITLES	Closed Caption (Consumer)	ď	×	Ŷ	À	7	?
C_DATA_ON_SCREEN	Data On Screen (Consumer)	ď	?	*	?	7	7
C_SNAPSH0T	Snapshot (Consumer)	ď	×	*	$\stackrel{\wedge}{\Longrightarrow}$?	?

Consumer Menus

Names	Description	ď	W	L	A	m	i
C_MENU	Menu (Consumer Menu)	ď	?	$\stackrel{\wedge}{\cong}$		7	7
C_MENU_PICK C_MENU_SELECT	Pick (Consumer Menu)	ď	7	À	×	?	?
C_MENU_UP	Up (Consumer Menu)	ď	7		×	7	?
C_MENU_DOWN	Down (Consumer Menu)	ď	7	À	×	?	7
C_MENU_LEFT	Left (Consumer Menu)	ď	7	$\stackrel{\wedge}{\rightleftharpoons}$	×	?	?
C_MENU_RIGHT	Right (Consumer Menu)	ď	7	À	×	?	?
C_MENU_ESCAPE C_MENU_ESC	Escape (Consumer Menu)	ď	7	*	×	?	?
C_MENU_INCREASE C_MENU_INC	Value Increase (Consumer Menu)	ď	7	À	×	?	?
C_MENU_DECREASE C_MENU_DEC	Value Decrease (Consumer Menu)	ď	7	÷	×	?	?
C_RED_BUTTON C_RED	Red Button (Consumer Menu)	ď	?	☆	À	?	7
C_GREEN_BUTTON C_GREEN	Green Button (Consumer Menu)	ď	?	☆	À	?	?
C_BLUE_BUTTON C_BLUE	Blue Button (Consumer Menu)	ď	?	☆	À	?	7
C_YELLOW_BUTTON C_YELLOW	Yellow Button (Consumer Menu)	ď	7	÷	*	?	7

Consumer Controls

Names	Description	ď	W	L	Α	m	i
C_CHANNEL_INC C_CHAN_INC	Channel Increment (Consumer)	ď	?	*	*	?	?
C_CHANNEL_DEC C_CHAN_DEC	Channel Decrement (Consumer)	ď	?	*	À	?	7
C_RECALL_LAST C_CHAN_LAST	Recall Last (Consumer)	ď	?	*	*	?	7
C_MEDIA_VCR_PLUS	VCR Plus (Consumer Media)	ď	?	*	×	7	7
C_MEDIA_GUIDE	Program Guide (Consumer Media)	ď	7	À	À	7	7
C_MEDIA_STEP C_MODE_STEP	Mode Step (Consumer Media)	ď	7	*	×	7	7
C_MEDIA_HOME	Home (Consumer Media)	ď	?	*	*	7	7
C_MEDIA_TV	TV (Consumer Media)	ď	7	À	À	7	7
C_MEDIA_CABLE	Cable (Consumer Media)	ď	7	*	×	7	7
C_MEDIA_TUNER	Tuner (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_DVD	DVD (Consumer Media)	ď	7	*	×	7	7
C_MEDIA_CD	CD (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_SATELLITE	Satellite (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_VCR	VCR (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_TAPE	Tape (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_COMPUTER	Computer (Consumer Media)	ď	7	À	×	7	7
C_MEDIA_WWW	WWW (Consumer Media)	ď	7	À	À	7	7
C_MEDIA_GAMES	Games (Consumer Media)	ď	7	*	×	7	7
C_MEDIA_PHONE	Telephone (Consumer Media)	ď	7	*	À	7	7
C_MEDIA_VIDEOPHONE	Video Phone (Consumer Media)	ď	7	*	×	7	7
C_MEDIA_MESSAGES	Messages (Consumer Media)	ď	7	*	×	7	7
C_QUIT	Quit (Consumer)	ď	?	*	X	7	7

C_HELP	Help (Consumer)	ď	?	$\stackrel{\wedge}{\rightleftharpoons}$	X	7	7	

Applications

Application Controls

Names	Description	ď	W	L	Α	m	i
K_MENU	Menu (Keyboard)	ď	7	*	X	7	7
C_AC_PROPERTIES	Duranting (9 10)	ca.	-			7	7
C_AC_PROPS	Properties (Consumer AC)	♂	7	*	×	?	7
K_SELECT	Select (Keyboard)	ď	7	*	×	7	7
C_AC_CANCEL	Cancel (Consumer AC)	ď	?	$\stackrel{\wedge}{\rightleftharpoons}$	×	7	7
K_EXECUTE K_EXEC	Execute (Keyboard)	ď	7	☆	×	?	?
C_AC_REFRESH	Refresh (Consumer AC)	ď	7	*	×	7	7
K_REFRESH	Refresh (Keyboard)	ď	7	*	×	×	×
C_AC_STOP	Stop (Consumer AC)	ď	7	*	*	7	7
K_STOP	Stop (Keyboard)	ď	7	$\stackrel{\wedge}{\Rightarrow}$	*	7	7
C_AC_FORWARD	Forward (Consumer AC)	ď	7	*	*	7	7
K_F0RWARD	Forward (Keyboard)	ď	7	*	*	×	×
C_AC_BACK	Back (Consumer AC)	ď	7	*	*	7	7
K_BACK	Back (Keyboard)	ď	7	*	*	×	×
C_AC_HOME	Home (Consumer AC)	ď	7	*	*	7	7
C_AC_B00KMARKS							
C_AC_FAVORITES	Bookmarks (Consumer AC)	ď	?		*	7	7
C_AC_FAVOURITES							
C_AC_NEW	New (Consumer AC)	ď	7	*	×	7	7
C_AC_OPEN	Open (Consumer AC)	ď	7	À	×	7	7

C_AC_SAVE	Save (Consumer AC)	ď	7	*	X	7	7
C_AC_CLOSE	Close (Consumer AC)	ď	?	*	×	7	?
C_AC_EXIT	Exit (Consumer AC)	ď	7	À	×	7	7
C_AC_PRINT	Print (Consumer AC)	ď	7	À	×	7	7
C_AC_FIND	Find (Consumer AC)	ď	7	*	×	7	7
K_FIND	Find (Keyboard)	ď	7	À	×	7	7
K_FIND2	Find (Keyboard)	ď	7	*	×	×	×
C_AC_SEARCH	Search (Consumer AC)	ď	7	*	*	*	7
C_AC_GOTO	Go To (Consumer AC)	ď	7	*	×	7	7
C_AC_Z00M	Zoom (Consumer AC)	ď	7	*	×	7	7
C_AC_ZOOM_IN	Zoom In (Consumer AC)	ď	7	*	×	7	7
C_AC_Z00M_0UT	Zoom Out (Consumer AC)	ď	7	*	×	7	7
C_AC_SCROLL_UP	Scroll Up (Consumer AC)	ď	7	À	À	7	7
K_SCROLL_UP	Scroll Up (Keyboard)	ď	7	*	*	×	×
C_AC_SCROLL_DOWN	Scroll Down (Consumer AC)	ď	7	À	À	7	7
K_SCROLL_DOWN	Scroll Down (Keyboard)	ď	7	À	À	×	×
C_AC_REPLY	Reply (Consumer AC)	ď	7	*	×	7	?
C_AC_FORWARD_MAIL	Forward (Consumer AC)	ď	7	À	×	7	?
C_AC_SEND	Send (Consumer AC)	ď	7	À	×	7	7
C_AC_EDIT	Edit (Consumer AC)	ď	?	À	×	7	?
C_AC_INSERT C_AC_INS	Insert Mode (Consumer AC)	ď	?	*	×	?	?
C_AC_DEL	Delete (Consumer AC)	ď	7	*	×	7	7
C_AC_VIEW_TOGGLE	View Toggle (Consumer AC)	ď	7	*	×	7	7
C_AC_DESKTOP_SHOW_ALL_WINDOWS	Desktop Show All Windows (Consumer AC)	ď	7	*	7	*	?
C_AC_DESKTOP_SHOW_ALL_APPLICATIONS	Desktop Show All Applications (Consumer AC)	ď	?	À	?	À	?
C_VOICE_COMMAND	Voice Command (Consumer)	ď	7	À	7	7	7

C_AC_NEXT_KEYBOARD_LAYOUT_SELECT GLOBE	AC Next Keyboard Layout Select (Apple Globe) (Consumer AC)	ď	7	7	?	☆ 1	*	
--	--	---	---	---	---	------------	----------	--

Notes: ¹ Does not exactly replicate original key behavior on macOS, works for Globe+key modifiers but not Fn+key (#1938).

Applications (Launch)

Names	Description	ď	W	L	Α	m	i
C_AL_NEXT_TASK	Next Task / Application (Consumer AL)	ď	?	*	X	7	7
C_AL_PREVIOUS_TASK	Dravious Tools / Application (O. A.)	ra ra	7		V	7	7
C_AL_PREV_TASK	Previous Task / Application (Consumer AL)	ď	6	*	×	6	6
C_AL_SELECT_TASK	Select Task / Application (Consumer AL)	C	7	*	×	7	7
C_AL_MY_COMPUTER	Local Machine Browser (Consumer AL)	ď	?	*	×	7	7
C_AL_DOCUMENTS	Decuments (Consumer AL)	ď	7	*	×	7	7
C_AL_DOCS	Documents (Consumer AL)	٥	ě	×	^	ě	6
C_AL_FILE_BROWSER	File Browser (Consumer AL)	C	7	*	×	7	7
C_AL_FILES	The browser (consumer AL)		ě		^	è	ě
C_AL_WWW	Internet Browser (Consumer AL)	ď	?	*	*	7	7
K_WWW	Internet Browser (Keyboard)	ď	?	*	*	X	×
C_AL_EMAIL	Erroil Doodon (O. All)	ď	7			7	7
C_AL_MAIL	Email Reader (Consumer AL)	٥	6	*	*	6	?
C_AL_INSTANT_MESSAGING	Instant Messaging (Consumer AL)	ď	7	*	×	7	7
C_AL_IM	instant Messaging (consumer AL)		e	_		· ·	o
C_AL_NETWORK_CHAT	Network Chat (Consumer AL)	C ⁷	7	*	×	7	7
C_AL_CHAT	Trottonic onat (concumo, AL)						Ů
C_AL_CONTACTS	Contacts / Address Book (Consumer AL)	C ⁷	7	*	*	7	7
C_AL_ADDRESS_BOOK							
C_AL_CALENDAR	Calendar / Schedule (Consumer AL)	ď	7	*	*	×	×
C_AL_CAL						•	
C_AL_IMAGE_BROWSER	Image Browser (Consumer AL)	ď	7	*	*	7	7
C_AL_IMAGES							

C_AL_AUDIO_BROWSER C_AL_AUDIO C_AL_MUSIC	Audio Browser (Consumer AL)	Ľ	?	÷	÷	?	?
C_AL_MOVIE_BROWSER C_AL_MOVIES	Movie Browser (Consumer AL)	ď	7	*	×	7	7
C_AL_TEXT_EDITOR	Text Editor (Consumer AL)	ď	7	*	×	?	?
C_AL_WORD	Word Processor (Consumer AL)	ď	7	*	×	7	7
C_AL_SPREADSHEET C_AL_SHEET	Spreadsheet (Consumer AL)	ď	7	*	×	7	7
C_AL_PRESENTATION	Presentation (Consumer AL)	ď	7	À	×	7	?
C_AL_GRAPHICS_EDITOR	Graphics Editor (Consumer AL)	ď	7	*	×	7	7
C_AL_CALCULATOR C_AL_CALC	Calculator (Consumer AL)	ď	7	☆	☆	×	×
K_CALCULATOR K_CALC	Calculator (Keyboard)	ď	7	À	À	×	×
C_AL_NEWS	Newsreader (Consumer AL)	ď	7	*	×	7	?
C_AL_DATABASE C_AL_DB	Database App (Consumer AL)	ď	7	À	×	?	?
C_AL_VOICEMAIL	Voicemail (Consumer AL)	ď	7	*	×	7	7
C_AL_FINANCE	Checkbook / Finance (Consumer AL)	ď	7	*	X	7	7
C_AL_TASK_MANAGER	Task / Project Manager (Consumer AL)	ď	7	*	×	7	7
C_AL_JOURNAL	Log / Journal / Timecard (Consumer AL)	ď	7	*	×	7	7
C_AL_AV_CAPTURE_PLAYBACK	A/V Capture / Playback (Consumer AL)	ď	7	*	×	7	?
C_AL_SPELLCHECK C_AL_SPELL	Spell Check (Consumer AL)	ď	7	À	×	7	7
C_AL_SCREEN_SAVER	Screen Saver (Consumer AL)	ď	7	*	×	7	7
C_AL_KEYBOARD_LAYOUT	Keyboard Layout (Consumer AL)	ď	7	*	×	7	7
C_AL_CONTROL_PANEL	Control Panel (Consumer AL)	ď	7	*	×	7	7
C_AL_HELP	Integrated Help Center (Consumer AL)	ď	7	*	×	?	?

K_HELP	Help (Keyboard)	ď	?	$\stackrel{\wedge}{\rightleftharpoons}$	×	?	?
C_AL_TIPS C_AL_TUTORIAL	OEM Features / Tips / Tutorial Browser (Consumer AL)	ď	?	☆	×	?	7
C_AL_CCC	Consumer Control Configuration (Consumer AL)	ď	7	*		?	7

Input Assist

Names	Description	ď	w	L	A	m	i
C_KEYBOARD_INPUT_ASSIST_NEXT C_KBIA_NEXT	Next (Consumer KBIA)	ď	?	À	?	×	?
C_KEYBOARD_INPUT_ASSIST_PREVIOUS C_KBIA_PREV	Previous (Consumer KBIA)	ď	?	À	?	×	7
C_KEYBOARD_INPUT_ASSIST_NEXT_GROUP C_KBIA_NEXT_GRP	Next Group (Consumer KBIA)	ď	?	*	?	×	7
C_KEYBOARD_INPUT_ASSIST_PREVIOUS_GROUP C_KBIA_PREV_GRP	Previous Group (Consumer KBIA)	ď	?	*	?	×	?
C_KEYBOARD_INPUT_ASSIST_ACCEPT C_KBIA_ACCEPT	Accept (Consumer KBIA)	ď	7	*	?	×	7
C_KEYBOARD_INPUT_ASSIST_CANCEL C_KBIA_CANCEL	Cancel (Consumer KBIA)	ď	?	*	7	×	?

Power & Lock

Names	Description	ď	W	L	Α	m	i
C_POWER C_PWR	Power (Consumer)	ď	7	À	×	☆ 1	☆ 2
K_POWER K_PWR	Power (Keyboard)	ď	7	×	À	☆ 1	☆ 2
C_RESET	Reset (Consumer)	ď	7	$\stackrel{\wedge}{\Longrightarrow}$	×	7	7

C_SLEEP	Sleep (Consumer)	ď	7	*	×	?	?
K_SLEEP	Sleep (Keyboard)	ď	7	$\stackrel{\wedge}{\rightleftharpoons}$	×	×	×
C_SLEEP_MODE	Sleep Mode (Consumer)	ď	7	×	$\stackrel{\wedge}{\rightleftharpoons}$?	?
C_AL_LOGOFF	Logoff (Consumer AL)	ď	7	*	×	?	?
C_AL_LOCK C_AL_SCREENSAVER C_AL_COFFEE	Terminal Lock / Screensaver (Consumer AL)	ď	?	☆	À	?	?
K_LOCK K_SCREENSAVER K_COFFEE	Lock (Keyboard)	ď	?	À	÷	×	×

Notes: ¹ Both macOS power keys ignore quick presses, sleep on deliberate press, and display a prompt on long-press.

² Both iOS power keys lock the home screen.

Edit this page