

GRBL Post Processor Settings v 1.2

Help & User Guide

What it does

This program lets you change the main settings in grbl_post.py without manually editing the Python file.

The editor controls Precision, drill-cycle translation, Preamble and Postamble.

File

The File box shows which grbl_post.py is being edited. Use Browse to select another copy. The program loads the settings from that file.

Precision

Enter a whole number such as 3 or 4. This controls the number of decimal places used where the post processor applies its PRECISION setting.

Translate G81 / G82 / G83 drill cycles

Tick the box to enable TRANSLATE_DRILL_CYCLES. Clear it to disable the option. This controls how G81, G82 and G83 drilling cycles are handled.

Preamble

G-code placed at the beginning of the generated CNC program. Only use G-code that is appropriate for your machine/controller.

Postamble

G-code placed at the end of the generated CNC program. It is normally used for stopping the spindle, moving to a safe position and ending the program.

Buttons

Button	What it does
Reload	Loads the settings currently stored in grbl_post.py. Unsaved editor changes are discarded.
Save	Writes the settings to grbl_post.py. A grbl_post.py.bak backup is created first.
Preview	Shows the current settings in the editor before saving.
Reset	Restores the supplied default values in the editor. Click Save to write them to the file.
Close	Closes the editor. Unsaved changes are not saved.

Recommended workflow

1. Open the editor.
2. Check the correct grbl_post.py is selected.
3. Change the settings you need.
4. Click Preview and check the values.
5. Click Save.
6. Keep the .bak backup until the generated G-code has been tested.

Important safety note

Always check and simulate generated G-code before running a CNC job. Incorrect Preamble or Postamble commands can cause unexpected machine movement or spindle operation. Use your normal dry-run and machine-safety procedures.

Quick reference

Ctrl + Esc closes the editor.

C:\Program Files\FreeCAD 1.1\Mod\CAM\Path\Post\scripts\grbl_post.py

that's where my GRBL post is,

1. Put the Buttons Folder IN The Script
2. Put The Script in the Same Folder
3. Create Shortcut Put The Shortcut On The Desktop
4. there. There is a default in the grbl you can change it, to what you want it to be

default in the script

GRBL POST PROCESSOR
CONFIGURATION

=====

PRECISION = 3
TRANSLATE_DRILL_CYCLES = True

PREAMBLE = ""

G17 G90
M3 S1000
G4 P0.5
S2000
G4 P0.5
S5000
G4 P0.5
S8000
G4 P1
""

POSTAMBLE = ""

M5
G17 G90
G4 P0.5
G00 X0.0000 Y0.0000
M2 End Of Program
""

my spindle is a variable speed spindle manual one
this programme only works with autohotkey v1.1237

disclaimer owner