

GestureFlow

Gesture cheat sheet

Use your right hand; the left is ignored. Calibrate with your elbow resting. Disable Preview only, then hold an open palm for 0.35 seconds to turn control ON.

Do this	Make this gesture	Remember
Move pointer	Only index finger extended	Move your fingertip within the calibrated area.
Turn ON	Open palm	Hold 0.35 seconds; then point to move.
Click	Thumb touches SIDE of straight index	Keep other fingers curled; release contact to complete click.
Drag / select	Hold thumb against index side	Move index fingertip; release contact to drop.
Talk to FlowSpeak	Middle bent to thumb; index, ring, pinky extended	Hold the whole shape to speak; release/change shape to finish.
Enter / send	Ring bent to thumb; index, middle, pinky extended	Hold 0.18 seconds for one Enter; release/change shape to repeat.
Scroll	Thumbs-up; all four fingers curled	Hold 0.16 seconds; move up/down. Point with index to return.
Right-click	Thumb + pinky out; other three folded	Hold shaka for about 0.30 seconds. Leave pose to rearm.
Switch window	Index + pinky out; middle, ring, thumb closed	Hold to cycle every 0.75 seconds; release to select highlighted window.
Turn OFF	Closed fist; thumb tucked	Hold 0.30 seconds. App and camera stay on.

Immediate control

- Ctrl+Alt+G: toggle the gesture-control lock from anywhere.
- Escape: lock controls when GestureFlow is focused.
- Gestures cannot undo a keyboard lock. Unlock with Ctrl+Alt+G or the app control, then show an open palm.
- Hand loss releases held input and freezes movement, but keeps control ON. Pointing does not turn the system ON/OFF.

Three habits that help

1. Calibrate neutral, left, right, up, down: hold each for three seconds with your elbow resting. Adjust horizontal/vertical sensitivity separately.
2. Click on the index SIDE, not its tip. For FlowSpeak/Enter, keep all three other fingers extended throughout. Changing shape releases after 0.10 seconds.
3. Wait for dictated text before Enter; it follows the focused app. Release physical modifiers before Enter or window switching.

FlowSpeak must be running with its Right Control shortcut. GestureFlow leaves it unchanged. Hand loss or turning control OFF releases a hold and can finish recording; it does not cancel it.

Practice safely with Preview only: tracking and status feedback stay visible, but no mouse or keyboard input is sent.