update-loader.md 2024-10-21

How to update laptop SPI-NOR FLASH

• Download USB driver software and the latest uboot image through Baidu Netdisk or OneDrive.



• Install USB driver program on your X86 computer through DriverAssitant_v5.12.



- Connect the TYPEC port of the laptop to the X86 computer using a USB cable.
- Press the loader button on the motherboard, then click the power button, and the X86 computer will
 recognize a maskrom device.



- Open the Rockchip develop tool RKDevTool-v3.13_forw_indow_1.17.113.
- Select 'Force Write to Address' as shown in the following figure, and then click' Burn '.

update-loader.md 2024-10-21

