VCS Driver Association Guide

Every time you take control of a BNSF vehicle, the Vehicle Camera System needs to know who's behind the wheel. Associating yourself takes only a few seconds and keeps every trip, hours record, and safety event correctly attributed to you.

1 Log in at the start of your shift

When you start the vehicle for the first time that day, the camera will prompt: “Please log into the vehicle.” Log in one of two ways:

- The easy way: open the Samsara Driver App, log in, select your vehicle, and drive.
- The camera way: hold your driver's license or BNSF badge up to the camera so it can clearly read the ID number. Hold it in place until you hear the acceptance sound.

2 If you don't log in right away

The system reminds you every 30 to 60 seconds until you log in. If you keep driving without logging in, a BNSF AI agent will call into your camera and ask you to log in using your B Number verbally.

3 Switching vehicles mid-shift

Taking control of a different vehicle? You must associate yourself again, even without a prompt. Turn on the vehicle, then either:

- Select the new vehicle in your Driver App, or
- Hold your license or badge up to the camera and wait for the acceptance sound.

4 Logging out

- Idle or engine off for 45 minutes: you're logged out automatically, so the login prompt queues up for whoever takes the vehicle next.
- End of shift: after 4 hours with no vehicle movement, the system logs you out automatically.
- Logged in through the Driver App? Log yourself out there at the end of your shift, too, to clear your association from the vehicle.

Why this matters

Correct driver association keeps VCS footage, hours of service, and safety events tied to the right operator — protecting you and BNSF if a record ever needs to be reviewed.