The green status light means the printer is ready.

The blue status light means the printer is receiving a job.

The orange status light means the paper tray is empty.

This page is an image-only wiring diagram and cannot be extracted as text.

Use A4 or Letter plain paper in the main tray.

The main tray holds at most 150 sheets.

Envelopes must be fed one at a time through the rear slot.

To cancel the active print job, hold Cancel for two seconds.

Cleaning the rollers requires disconnecting the power cable first.

The printer enters sleep mode after ten minutes without a job.

Press any control-panel button to wake the printer from sleep.

The printer rejects jobs protected by an unsupported encryption format.