

CONTROL SYSTEM **BODE EDITOR** **VIEW**

FILE **ARCHITECTURE** **TUNING METHODS** **ANALYSIS** **DESIGNS** **RESULTS** **PREFERENCES**

Open Session **Save Session** **Edit Architecture** **Multimodel Configuration**

Tuning Methods **New Plot** **Store** **Retrieve** **Compare**

Export **Preferences**

Data Browser

- ▼ Controllers and Fixed Blocks
 - F
 - C
 - G
 - H
- ▼ Designs
- ▼ Responses
 - LoopTransfer_C
 - IOTransfer_r2y
 - IOTransfer_r2u
 - IOTransfer_du2y
 - IOTransfer_dy2y
 - IOTransfer_n2y
- ▼ Preview

Bode Editor for LoopTransfer_C

Bode Editor for LoopTransfer_C

Magnitude (dB)

Phase (deg)

10⁻¹ 10⁰

G.M.: inf
Freq: NaN
Stable loop

Root Locus Editor for LoopTransfer_C

Root Locus Editor for LoopTransfer_C

Imag Axis

Real Axis

IOTransfer_r2y: step

Step Response

From: r To: y

+ **-** **Hand icon** **Equalizer icon**

Amplitude

Time (seconds)