How to use TCP/UDP control the SMTAV camera?

The camera includes an internal TCP server. The default port number is 5678. When client and server set up a TCP connection, the client sends PTZ command to the internal server and the server will then parse and execute the PTZ commands.

The camera includes an internal UDP server. The default port number is 1259. When client and server set up a UDP connection, the client sends PTZ commands to the internal server and the server will then parse and execute the PTZ commands.

The command format based on VISCA is shown as bellow:

Inquiry Command	d List			
Command Command		Response	Comments	
		90 50 02 FF	On	Chat
		90 50 03 FF	Off (Standby)	
				Contact Us

CAM_PowerInq	81 09 04 00 FF	90 50 04 FF	Internal power circuit error
CAM_ZoomPosInq	81 09 04 47 FF	90 50 0p 0q 0r 0s FF	pqrs: Zoom Position
CAM_FocusAFMode		90 50 02 FF	Auto Focus
Inq	81 09 04 38 FF	90 50 03 FF	Manual Focus
CAM_FocusPosInq	81 09 04 48 FF	90 50 0p 0q 0r 0s FF	pqrs: Focus Position
		90 50 00 FF	Auto
		90 50 01 FF	Indoor mode
		90 50 02 FF	Outdoor mode
		90 50 03 FF	OnePush mode
		90 50 05 FF	Manual
CAM_WBModelnq	81 09 04 35 FF	90 50 20 FF	ColorTemperature Mode
CAM_RGainInq	81 09 04 43 FF	90 50 00 00 0p 0q FF	pq: R Gain
CAM_BGainInq	81 09 04 44 FF	90 50 00 00 0p 0q FF	pq: B Gain
		90 50 00 FF	Full Auto Contact Us

.

CAM_AEModeInq	81 09 04 39 FF	90 50 03 FF	Manual
		90 50 0A FF	Shutter priority
		90 50 0B FF	Iris priority
		90 50 0D FF	Bright
CAM_ShutterPosInq	81 09 04 4A FF	90 50 00 00 0p 0q FF	pq: Shutter Position
CAM_IrisPosInq	81 09 04 4B FF	90 50 00 00 0p 0q FF	pq: Iris Position
CAM_BrightPosInq	81 09 04 4D FF	90 50 00 00 0p 0q FF	pq: Bright Position

CAM_ExpCompN	Лod	90 50 02 FF	On	4
elnq	81 09 04 3E FF	90 50 03 FF	Off	1
CAM_ExpCompPosI				
nq	81 09 04 4E FF	90 50 00 00 0p 0q FF	pq: ExpComp Position	Contact Us

CAM_BacklightMode		90 50 02 FF	On
Inq	81 09 04 33 FF	90 50 03 FF	Off
CAM_Nosise2DM	lode	90 50 02 FF	Auto Noise 2D
Ing	81 09 04 50 FF	90 50 03 FF	Manual Noise 3D
CAM_Nosise2DL	ev 81 09 04 53 FF	90 50 0p FF	Noise Reduction (2D) p: 0 to 5
CAM_Noise3DLe	ve 8 1 09 04 54 FF	90 50 0p FF	Noise Reduction (3D) p: 0 to 8
CAM_FlickerModeIn			
q	81 09 04 55 FF	90 50 0p FF	p: Flicker Settings(0: OFF, 1: 50Hz, 2: 60Hz)
CAM_ApertureMo	odel	90 50 02 FF	Auto Sharpness
nq (Sharpness)	81 09 04 05 FF	90 50 03 FF	Manual Sharpness
CAM_ApertureInq			
(Sharpness)	81 09 04 42 FF	90 50 00 00 0p 0q FF	pq: Aperture Gain
		90 50 02 FF	On
SYS_MenuModeli	ng81 09 06 06 FF	90 50 03 FF	Off

.

CAM_PictureEffectM	90 50 02 FF	Off
odelnq 81 09 04 63 FF	90 50 04 FF	B&W
	90 50 02 FF	On
CAM_LR_Reverselr&1 09 04 61 FF	90 50 03 FF	Off
	90 50 02 FF	On
CAM_PictureFlipInαβ1 09 04 66 FF	90 50 03 FF	Off
CAM_ColorGainInq81 09 04 49 FF	90 50 00 00 00 0p FF	p: Color Gain setting 0h (60%) to Eh (200%)
	90 50 0w 0w 0w 0w	wwww: Pan Position
Pan-tiltPosInq 81 09 06 12 FF	0z 0z 0z 0z FF	zzzz: Tilt Position
CAM_GainLimitInq 81 09 04 2C FF	90 50 0q FF	p: Gain Limit
	90 50 01 FF	High
CAM_AFSensitivityl	90 50 02 FF	Normal
nq 81 09 04 58 FF	90 50 03 FF	Low

CAM_Brightnessl	n & 1 09 04 A1 FF	90 50 00 00 0p 0q FF	pq: Brightness Position
CAM_ContrastInc	81 09 04 A2 FF	90 50 00 00 0p 0q FF	pq: Contrast Position
		90 50 00 FF	Off
		90 50 01 FF	Flip-H
CAM_FlipIng	na 81 09 04 A4 FF	90 50 02 FF	Flip-V
CAW_I IIpIIIq	01 03 04 A411	90 50 03 FF	Flip-HV
CAM_AFZone	81 09 04 AA FF	90 50 00 FF	Тор

	90 50 01 FF	Center	4
	90 50 02 FF	Bottom	1
		p: Color Hue setting 0h (- 14 degrees) to Eh (+14	
CAM_ColorHuelnq 81 09 04 4F FF	90 50 00 00 00 0p FF	Contact Us	ŝ

	degrees	
--	---------	--

		90 50 00 FF	High
CAM_AWBSensit	ivit	90 50 01 FF	Normal
ylnq	81 09 04 A9 FF	90 50 02 FF	Low
		90 50 02 FF	On
CAM_UACInq	81 2A 02 A0 04 FF	90 50 03 FF	Off



Leave a comment

POST COMMENT		
	← BACK TO HOW TO USE THE CAMERA	
Quick links		
Affiliate Portal		
Home Page		
Usage Guide		

Documents			
Downloads			
Terms of Service			
Refund policy			
BUY ON ALIEXPRESS			
Products			
All Products			
4K Camera			
NDI Camera			
SDI Camera			1
USB Camera			
PTZ Controller			

Solution Kit		
Accessories		
SKD		
Newsletter		
		SUBSCRIBE
	f → Ø ⊙ y	
	© 2025, SMTAV Powered by Shopify	1

© 2025, SMTAV Powered by Shopify