

Contoso Electronics

Equipment Reference & Maintenance Guide

ESD-Protected Assembly Workstation

Contoso SafeBench ESD-200

Asset Identification

Field	Detail
Asset ID	CE-ESD-0100
Category	Assembly & Rework
Manufacturer	Contoso Assembly Tools
Location	Assembly Floor - Bench Group A
Installation Date	2024-02-15
Warranty Expiry	2029-02-15
Support Contact	assembly.support@contoso.com ext. 4155

Overview

The Contoso SafeBench ESD-200 is an ESD-protected assembly workstation providing a grounded work surface, wrist-strap monitoring, ionization, and task lighting to protect sensitive electronic components from electrostatic discharge damage during manual assembly and inspection.

Technical Specifications

Parameter	Value
Work Surface	Dissipative laminate, 1500 x 750 mm
Surface Resistance	10 ⁶ - 10 ⁹ Ω
Wrist Strap Monitor	Continuous dual-conductor
Ionizer	Balanced DC, ±35 V offset
Grounding	Common point ground (CPG)
Lighting	LED, glare-free, 1000 lux
Power	120/230 VAC, 50/60 Hz

Preventive Maintenance Schedule

Interval	Task
Each shift	Test wrist strap with tester before starting work.
Daily	Clean work surface with ESD-safe cleaner.
Weekly	Verify surface-to-ground resistance; check ionizer balance.

Quarterly	Calibrate ionizer; inspect ground cords and snaps.
-----------	--

Safety Guidelines

- Always wear and test the wrist strap before handling components.
- Keep non-ESD-safe materials (plastics, foam cups) off the bench.
- Do not modify or defeat the grounding system.
- Ensure the common point ground is connected to building ground.

Common Issues & Troubleshooting

Symptom	Recommended Action
Wrist strap monitor alarm	Check strap fit and cord; replace worn strap or cord.
High surface resistance	Clean surface; verify ground cord connection to CPG.
Ionizer imbalance	Clean emitter points; recalibrate ionizer offset.
Static damage reports	Audit grounding, humidity, and handling procedures.

Contoso Electronics internal maintenance documentation. For service requests, contact assembly.support@contoso.com | ext. 4155 or submit a work order through the maintenance portal.