

-
- 1 **Antenna-in connector (on supported models)** — Connects to an external antenna to view programs using the TV tuner card (optional).

 - 2  **Audio out/Headphone connector** — Connects to a pair of headphones or to a powered speaker or sound system.

 - 3  **Audio in/Microphone connector** — Connects to a microphone or inputs signal for use with audio programs.

 - 4  **USB connector with USB PowerShare** — Connects to USB devices, such as a mouse, keyboard, printer, external drive, or MP3 player.

The USB Powershare feature allows you to charge USB devices when the computer is powered on/off or in sleep state.

NOTE: Certain USB devices may not charge when the computer is powered off or in sleep state. In such cases, turn on the computer to charge the device.

NOTE: If you turn off your computer while charging an USB device, the device will stop charging. To continue charging, disconnect the USB device and connect it again.

 - 5  **USB 2.0 connector** — Connects to USB devices, such as a mouse, keyboard, printer, external drive, or MP3 player.

 - 6  **AC adapter connector** — Connects to the AC adapter to power the computer and charge the battery.
-