



Front



Left



Right



Base



Display

Right



1 Power button

Press to turn on the computer if it is turned off or in Sleep state.

Press to put the computer in Sleep state if it is turned on.

Press and hold for 4 seconds to force shut-down the computer.

NOTE: You can customize the power-button behavior in Power Options. For more information, see *Me and My Dell* at dell.com/support.

2 Volume-control buttons (2)

Press to increase or decrease the volume.

3 Right speaker

Provides audio output from your computer.

4 USB 2.0 port

Connect peripherals such as storage devices, printers, and so on. Provides data transfer speeds up to 480 Mbps.

5 Media-card reader

Reads from and writes to media cards.

6 Passive stylus

Allows you to draw shapes, select items, and perform touch gestures on the screen.