

# Interface Description

---

ServiceAd\_REST



---

Revision date: 20.04.2026

TecAlliance GmbH

---

# Contents

## Module Details

1. AdjustController

## ObjectModel

1. AdItemMp
2. AdMainGroup
3. AdSubGroup
4. AdValueData
5. AdValueItemMp
6. AdValueSubGroup
7. ImageMsg
8. ImageNamesForItemMpMsg
9. ImageNamesForMainGroupMsg
10. ImageNamesForSubGroupMsg
11. ItemHtmlMsg
12. ItemMpDataMsg
13. KindOfLinkTypes
14. ListMsg
15. MainGroupDataMsg
16. MainGroupHtmlMsg
17. SubGroupDataMsg
18. SubGroupHtmlMsg
19. VehicleHasAdjustMsg

## Module Details

### 1. AdjustController

#### 1.1. Prerequisites

Some of the html documents could contain graphics in the .SVG format. So the system requirements for viewing html documents are: MS Internet Explorer v. 9.0 and higher  
Mozilla Firefox 15 and higher

#### 1.2. Sequence Of Calls

First of all, you should check whether there is adjustment data available for the currently selected vehicle. To perform this check, you simply call [VehicleHasAdjust](#) which returns a boolean value indicating whether there is adjustment data ( **true**) or not ( **false**)

To build a working menu for selecting adjustment data for a specific vehicle you should invoke the method [List](#) . From this method, you will get a list containing further lists which hold all the information on the adjustment data sub groups and items of the vehicle.

To get an adjustment data manual in html format, you have to call [MainGroupHtml](#) where you pass the type id of your chosen vehicle and one of the main group ids which you got from [List](#) . Wenn you set the property "PrintView" to true the html document will be optimized for printing.

You can also create adjustment data manuals which only contain information for a special subgroup or item instead of a whole main group. To get such a manual for a special sub group you simply call [SubGroupHtml](#) where you pass the subgroup id which you probably already got from [List](#) and, as usual, the type id of the selected vehicle. To do this for a special item use [ItemHtml](#) and passing the item mount position id from [List](#) .

#### 1.3. Summary

Area [RestRMI.Areas.Ad.Controllers.AdjustController](#) provides the web service methods for the part adjustment data. Here technical data on the selected vehicle, such as torques, filling quantities and specification are shown.

#### 1.4. Detailed Module Documentation

##### 1.4.1. Properties

- **HttpContext ActionContext**  
No description available
- **HttpConfiguration Configuration**  
No description available
- **HttpControllerContext ControllerContext**  
No description available

- **string Ip**  
Gets the IP.
- **ModelStateDictionary ModelState**  
No description available
- **HttpRequestMessage Request**  
No description available
- **HttpContext RequestContext**  
No description available
- **UrlHelper Url**  
No description available
- **IPrincipal User**  
No description available

### 1.4.2. Methods

- **bool VehicleHasAdjust([VehicleHasAdjustMsg](#) input)**

Checks whether the vehicle has adjustment data.

#### Parameter

input - Instance of the message class VehicleHasAdjustMsg.

#### Returns

true - if adjustment data exists; otherwise false.

- **IEnumerable<[AdMainGroup](#)> List([ListMsg](#) input)**

Delivers a country specific list to generate the adjustment data topic tree for the type id in the given language.

#### Parameter

input - Instance of the message class ListMsg.

#### Returns

The topic tree for the part adjustment data.

- **IEnumerable<[AdValueSubGroup](#)> MainGroupData([MainGroupDataMsg](#) input)**

Delivers a collection with the adjustment data for the selected vehicle, main group and country.

#### Parameter

input - Instance of the message class MainGroupDataMsg.

#### Returns

The data of the adjustment data main group.

**- AdValueSubGroup SubGroupData(SubGroupDataMsg input)**

Delivers a collection with the adjustment data for the selected vehicle, sub group and country.

**Parameter**

input - Instance of the message class SubGroupDataMsg.

**Returns**

The data of the adjustment data sub group.

**- AdValueItemMp ItemMpData(ItemMpDataMsg input)**

Delivers a collection with the adjustment data for the selected type, item and country.

**Parameter**

input - Instance of the message class ItemMpDataMsg

**Returns**

The data of the adjustment data item mount position.

**- string MainGroupHtml(MainGroupHtmlMsg input)**

Delivers a country specific string which contains the HTML lines for an adjustment data HTML file.

**Remarks**

Link elements (hrefs) in the HTML code are enclosed in 'p' (U+00DE LATIN CAPITAL LETTER THORN) characters and consists of a letter and a number (e.g. pm123p). Those can be evaluated on the web server before the HTML is sent to the client, or handled in an embedded browser control using the relevant navigation events. Following letters where possible: m - indicates a link to 0..\* technical manual(s) followed by a manual id. p - indicates a link to a picture, followed by the full picture URL.

**Parameter**

input - Instance of the message class MainGroupHtmlMsg.

**Returns**

A string which contains the whole HTML file..

**- string SubGroupHtml(SubGroupHtmlMsg input)**

Delivers a string which contains the HTML lines for an adjustment data HTML file for the given sub group.

**Remarks**

Link elements (hrefs) in the HTML code are enclosed in 'p' (U+00DE LATIN CAPITAL LETTER THORN) characters and consists of a letter and a number (e.g. pm123p). Those can be evaluated on the web server before the HTML is sent to the client, or handled in an embedded browser control using the relevant navigation events. Following letters where possible: m - indicates a link to 0..\* technical manual(s) followed by a manual id.

p - indicates a link to a picture, followed by the full picture URL.

**Parameter**

input - Instance of the message class SubGroupHtmlMsg.

**Returns**

A string which contains the whole HTML file.

**- string ItemHtml(ItemHtmlMsg input)**

Delivers a string which contains the HTML lines for an adjustment data HTML file for the given item.

**Remarks**

Link elements (hrefs) in the HTML code are enclosed in 'p' (U+00DE LATIN CAPITAL LETTER THORN) characters and consists of a letter and a number (e.g. pm123p). Those can be evaluated on the web server before the HTML is sent to the client, or handled in an embedded browser control using the relevant navigation events. Following letters where possible: m - indicates a link to 0..\* technical manual(s) followed by a manual id. p - indicates a link to a picture, followed by the full picture URL.

**Parameter**

input - Instance of the message class ItemHtmlMsg.

**Returns**

A string containing the complete HTML lines for a HTML file of the adjustment data.

**- IEnumerable<String> ImageNamesForMainGroup(ImageNamesForMainGroupMsg input)**

Delivers a country specific collection of strings which contains the picture names necessary for the adjustment data layout.

**Parameter**

input - Instance of the message class ImageNamesForMainGroupMsg.

**Returns**

A collection of strings containing all image names of the HTML file.

**- IEnumerable<String> ImageNamesForSubGroup(ImageNamesForSubGroupMsg input)**

Delivers a country specific collection of strings which contains the picture names necessary for the adjustment data layout.

**Parameter**

input - Instance of the message class ImageNamesForSubGroupMsg.

**Returns**

A collection of strings containing all image names of the HTML file.

**- IEnumerable<String> ImageNamesForItemMp(ImageNamesForItemMpMsg input)**

Delivers a country specific collection of strings which contains the picture names necessary for the adjustment data layout.

**Parameter**

input - Instance of the message class ImageNamesForItemMpMsg.

**Returns**

A collection of strings containing all image names of the HTML file.

**- string Image(ImageMsg input)**

Returns a byte array which contains the requested adjustment data image.

**Parameter**

input - Instance of the message class ImageMsg.

**Returns**

An array which contains the requested image.

# Object Model

## 1. AdItemMp

### 1.1. Summary

Represents an item mount position of the adjustment data topic tree. In the topic tree hierarchy, item mount positions are children of sub groups. The same item mount position might also be a child of several different sub groups making the topic tree rather a directed acyclic graph than a tree.

### 1.2. Detailed Module Documentation

#### 1.2.1. Properties

- **bool InfoDataExists**

Gets or sets a value indicating whether there are information data existing for this item mount position.

The portal database must be available to provide information data.

**Property-Value**

true if info data exists; otherwise, false.

- **bool IsLocked**

Gets or sets a value indicating whether access to this item mount position is denied.

**Property-Value**

true if this item mount position is locked; otherwise, false.

- **int ItemMpld**

Gets or sets the id of the item mount position.

**Property-Value**

The item mount position id.

- **string ItemMplImageName**

Gets or sets the name of the item mount position image.

**Property-Value**

The the item mount position image name.

- **string ItemMpText**

Gets or sets the text of the item mount position.

**Property-Value**

The item mount position text.

- **int SortOrder**

Gets or sets the order number of this topic item mount position. A collection of topic item mount position will be sorted against this number.



**Property-Value**

The sort order.

## 2. AdMainGroup

### 2.1. Summary

Represents a main group of the adjustment data topic tree. In the topic tree hierarchy, main groups are on the topmost level. Each main group may have several sub groups as children.

### 2.2. Detailed Module Documentation

#### 2.2.1. Properties

- **bool InfoDataExists**

Gets or sets a value indicating whether there are information data existing for this main group.

The portal database must be available to provide information data.

**Property-Value**

true if info data exists; otherwise, false.

- **int MainGroupId**

Gets or sets the id of the main group.

**Property-Value**

The main group id.

- **string MainGroupImage**

Gets or sets the image of the main group.

**Property-Value**

The main group image.

- **string MainGroupName**

Gets or sets the name of the main group.

**Property-Value**

The the main group name.

- **int SortOrder**

Gets or sets the order number of this main group. A collection

of main groups will be sorted against this number.

**Property-Value**

The sort order.

- **List<[AdSubGroup](#)> SubGroups**

Gets or sets a collection of sub groups which belongs to this main group.

**Property-Value**

The sub groups.

### 3. AdSubGroup

#### 3.1. Summary

Represents a sub group of the adjustment data topic tree. In the topic tree hierarchy, sub groups are children of main groups. The same sub group might also be a child of several different main groups making the topic tree rather a directed acyclic graph than a tree. Each sub group may have several item mount positions as children.

#### 3.2. Detailed Module Documentation

##### 3.2.1. Properties

- **bool InfoDataExists**

Gets or sets a value indicating whether there are information data existing for this sub group. The portal database must be available to provide information data.

**Property-Value**

true if info data exists; otherwise, false.

- **List<[AdItemMp](#)> ItemMps**

Gets or sets a collection of item mount positions which belongs to this sub group.

**Property-Value**

The item mount positions.

- **int SortOrder**

Gets or sets the order number of this sub group. A collection of sub groups will be sorted against this number.

**Property-Value**

The sort order.

- **int SubGroupId**

Gets or sets the id of the sub group.

**Property-Value**

The sub group id.

- **string SubGroupImage**

Gets or sets the sub group image.

**Property-Value**

The sub group image.

- **string SubGroupName**

Gets or sets the name of the sub group.

**Property-Value**

The sub group name.

## 4. AdValueData

### 4.1. Summary

Represents value data for AD. This is the actual adjustment data.

### 4.2. Detailed Module Documentation

#### 4.2.1. Properties

- **string AdditionalText**

Gets or sets the additional text.

**Property-Value**

The additional text.

- **KindOfLinkTypes** KindOfLink

Gets or sets the kind of link.

**Property-Value**

The kind of link.

- **string LinkValue**

Gets or sets the link value.

**Property-Value**

The link value.

- **int QualCollId**

Gets or sets the id of the qualifier collection.

**Property-Value**

The qualifier collection id.

- **string QualColText**

Gets or sets the text of the qualifier collection.

**Property-Value**

The qualifier collection text.

- **string QuantityText**

Gets or sets the quantity text.

**Property-Value**

The quantity text.

- **int ValueSortOrder**

Gets or sets the value sort order.

**Property-Value**

The value sort order.

- **string ValueText**

Gets or sets the value text.

**Property-Value**

The value text.

## 5. AdValueItemMp

### 5.1. Summary

Represents an item mount position along with a collection of their values.

### 5.2. Detailed Module Documentation

#### 5.2.1. Properties

- **bool InfoDataExists**

Gets or sets a value indicating whether there are information data existing for this item mount position.

The portal database must be available to provide information data.

**Property-Value**

true if info data exists; otherwise, false.

- **bool IsLocked**

Gets or sets a value indicating whether access to this item mount position is denied.

**Property-Value**

true if this item mount position is locked; otherwise, false.

- **bool IsOnlyForReference**

Gets or sets a value indicating whether this instance is only for reference.

**Property-Value**

true if this instance is only for reference; otherwise, false.

- **int ItemMplId**

Gets or sets the id of the item mount position.

**Property-Value**

The item mount position id.

- **string ItemMplImageName**

Gets or sets the name of the item mount position image.

**Property-Value**

The the item mount position image name.

- **string ItemMpText**

Gets or sets the text of the item mount position.

**Property-Value**

The item mount position text.

- **int SortOrder**

Gets or sets the order number of this topic item mount position. A collection of topic item mount position will be sorted against this number.

**Property-Value**

The sort order.

- **List<AdValueData> Values**

Gets or sets a collection of values of this item mount position.

**Property-Value**

The values of the item mount position.

## 6. AdValueSubGroup

### 6.1. Summary

Represents a sub group for adjustment data that has a collection of item mount positions. Each of the item mount positions has a list of values representing the actual adjustment data.

### 6.2. Detailed Module Documentation

#### 6.2.1. Properties

- **bool InfoDataExists**

Gets or sets a value indicating whether there are information data existing for this sub group. The portal database must be available to provide information data.

**Property-Value**

true if info data exists; otherwise, false.

- **List<AdValueItemMp> ItemMps**

Gets or sets a collection of item mount positions which belongs to this sub group.

**Property-Value**

The item mount positions.

- **int SortOrder**

Gets or sets the order number of this sub group. A collection of sub groups will be sorted against this number.

**Property-Value**

The sort order.

- **int SubGroupId**

Gets or sets the id of the sub group.

**Property-Value**

The sub group id.

- **string SubGroupImage**

Gets or sets the sub group image.

**Property-Value**

The sub group image.

- **string SubGroupName**

Gets or sets the name of the sub group.

**Property-Value**

The sub group name.

## 7. ImageMsg

### 7.1. Summary

Class [RestRMI.Models.GlobalServiceMessages.ImageMsg](#) contains the properties which are necessary to call the web service methods `Image(ImageMsg)`,

### 7.2. Detailed Module Documentation

#### 7.2.1. Properties

- **string ImageName**

Gets or sets the name of the requested image.

**Property-Value**

The name of the image.

## 8. ImageNamesForItemMpMsg

### 8.1. Summary

Class [RestRMI.Areas.Ad.Models.ImageNamesForItemMpMsg](#) contains the properties which are necessary to call the web service methods `ImageNamesForItemMp(ImageNamesForItemMpMsg)`,

## 8.2. Detailed Module Documentation

### 8.2.1. Properties

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **int ItemMpld**

Gets or sets the TecRMI item mount position id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The item mount position id.

- **int Typeld**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 9. ImageNamesForMainGroupMsg

### 9.1. Summary

Class [RestRMI.Areas.Ad.Models.ImageNamesForMainGroupMsg](#) contains the properties which are necessary to call web service methods `ImageNamesForMainGroup(ImageNamesForMainGroupMsg)`.

## 9.2. Detailed Module Documentation

### 9.2.1. Properties

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **int MainGroupld**

Gets or sets the TecRMI topic main group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic main group id.

- **int Typeld**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 10. ImageNamesForSubGroupMsg

### 10.1. Summary

Class [RestRMI.Areas.Ad.Models.ImageNamesForSubGroupMsg](#) contains the properties which are necessary to call the web service methods `ImageNamesForSubGroup(ImageNamesForSubGroupMsg)`.

### 10.2. Detailed Module Documentation

#### 10.2.1. Properties

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **int SubGroupId**

Gets or sets the TecRMI topic sub group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic sub group id.

- **int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 11. ItemHtmlMsg

### 11.1. Summary

Class [RestRMI.Areas.Ad.Models.ItemHtmlMsg](#) contains the properties which are necessary to call the web service method `ItemHtml(ItemHtmlMsg)`.

### 11.2. Detailed Module Documentation

#### 11.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.



**Property-Value**

Unique end user identifier.

**- string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

**- int ItemMpld**

Gets or sets the TecRMI item mount position id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The item mount position id.

**- string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

**- string LinkUrl**

Gets or sets the link url. The actual link information is going to be added at the end of this url.

It is used where documents contains links to other and are shown in custom application.

**Property-Value**

The link url.

**Example**

```
LinkURL = "http://localhost/" // -> Generated link in documents:  
http://localhost/Ð1234Ð;
```

**- bool PrintView**

Gets or sets a value indicating whether the HTML file should be prepared for printing.

**Property-Value**

true if the HTML file is prepare for printing; otherwise, false.

**- int Typeld**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 12. ItemMpDataMsg

### 12.1. Summary

Class [RestRMI.Areas.Ad.Models.ItemMpDataMsg](#) contains the properties which are necessary to call the web service methods `ItemMpData(ItemMpDataMsg)`.

### 12.2. Detailed Module Documentation

#### 12.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.

**Property-Value**

Unique end user identifier.

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **int ItemMpld**

Gets or sets the TecRMI item mount position id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The item mount position id.

- **string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

- **int Typeld**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 13. KindOfLinkTypes

### 13.1. Summary

Enum **KindOfLinkTypes** specifies the kinds of link types.

## 13.2. Remarks

The AuDaLib includes several methods that return HTML documents as strings. Some of the HTML documents may contain links. The **href** attribute of the links follows a certain scheme: e.g. href="someUrl/pa1205p", where "someUrl/" is the link URL, "p" is the link separator, "a" is the kind of link type represented as char and "1205" is the link id. The kind of link type determines how the link id has to be interpreted and, therefore, determines the target module the link is referencing. The enumerators can be casted into chars. Altogether, a link can be evaluated on the web server before the HTML is sent to the client, or handled in an embedded browser control using the relevant navigation events.

## 13.3. Detailed Module Documentation

### 13.3.1. Enums

- **None**  
No link.
- **AdItemMpld**  
A link to an item mount position from the adjustment data module.
- **FusesBoxItemMpld**  
Unused at the moment.
- **BgItemGroup**  
A link to an item group from the body graphics module.
- **DiagnosisItemId**  
A link to an item from the diagnosis module.
- **ErrorCodeManualId**  
A link to an error code manual.
- **Fuses**  
A link to fuses.
- **HotSpotGenArt**  
A link to a generic article.
- **BgMainGroupId**  
A link to a main group from the body graphics module.
- **TmItemMpld**  
A link to an item mount position from the technical manuals module.
- **DiagnosticContentId**  
Unused at the moment.
- **Unused\_K**  
Unused at the moment.
- **LockedItem**  
A link to an item for which access is denied because the user has no permissions to access the referenced item.
- **TmManualId**

A link to a manual from the technical manuals module.

- **OeSparePartNo**

A link to a OE spare part no from a technical manual.

- **WdMainGroupId**

A link to main group from the wiring diagrams module.

- **Image**

A link to an image.

- **Unused\_Q**

Unused at the moment.

- **Unused\_R**

Unused at the moment.

- **BgSubGroupId**

A link to a sub group from the body graphics module.

- **VehicleTreeTypeId**

A link to a vehicle type from the vehicle tree module.

- **Unused\_U**

Unused at the moment.

- **Unused\_V**

Unused at the moment.

- **WdItemMpid**

A link to an item mount position from the wiring diagrams module.

- **Unused\_X**

Unused at the moment.

- **ImageLinkId**

A link from an image, currently used for partposition module.

- **Unused\_Z**

Unused at the moment.

## 14. ListMsg

### 14.1. Summary

Class [RestRMI.Areas.Ad.Models.ListMsg](#) is the base class for a few message classes and contains the properties which are necessary to call web service methods List(ListMsg),

### 14.2. Detailed Module Documentation

#### 14.2.1. Properties

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

**- Nullable<Int32> GenArtNumber**

Gets or sets the generic article number.

Only if this contains a value and TextSearch is NULL or empty a search after the passed generic article is performed.

**Property-Value**

The generic article number.

**- Nullable<Int32> GenCritNumber**

Gets or sets the generic criterion number.

**Property-Value**

The generic criterion number.

**- string GenCritValue**

Gets or sets the generic criterion value.

**Property-Value**

The generic criterion value.

**- string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

**- string TextSearch**

Gets or sets the text search. If this isn't NULL or empty a search after this value will be performed.

**Property-Value**

The text search.

**- int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 15. MainGroupDataMsg

### 15.1. Summary

Class [RestRMI.Areas.Ad.Models.MainGroupDataMsg](#) contains the properties which are necessary to call web service methods `MainGroupData(MainGroupDataMsg)`.

## 15.2. Detailed Module Documentation

### 15.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.

**Property-Value**

Unique end user identifier.

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

- **int MainGroupId**

Gets or sets the TecRMI topic main group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic main group id.

- **int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 16. MainGroupHtmlMsg

### 16.1. Summary

Class [RestRMI.Areas.Ad.Models.MainGroupHtmlMsg](#) contains the properties which are necessary to call the web service method `MainGroupHtml(MainGroupHtmlMsg)`.

## 16.2. Detailed Module Documentation

### 16.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.

**Property-Value**

Unique end user identifier.

**- string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

**- string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

**- string LinkUrl**

Gets or sets the link url. The actual link information is going to be added at the end of this url.

It is used where documents contains links to other and are shown in custom application.

**Property-Value**

The link url.

**Example**

```
LinkURL = "http://localhost/" // -> Generated link in documents:  
http://localhost/12345;
```

**- int MainGroupId**

Gets or sets the TecRMI topic main group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic main group id.

**- bool PrintView**

Gets or sets a value indicating whether the HTML file should be prepared for printing.

**Property-Value**

true if the HTML file is prepared for printing; otherwise, false.

**- int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 17. SubGroupDataMsg

### 17.1. Summary

Class [RestRMI.Areas.Ad.Models.SubGroupDataMsg](#) contains the properties which are necessary to call the web service methods `SubGroupData(SubGroupDataMsg)`.

### 17.2. Detailed Module Documentation

#### 17.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.

**Property-Value**

Unique end user identifier.

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

- **int SubGroupId**

Gets or sets the TecRMI topic sub group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic sub group id.

- **int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 18. SubGroupHtmlMsg

### 18.1. Summary

Class [RestRMI.Areas.Ad.Models.SubGroupHtmlMsg](#) contains the properties which are necessary to call the web service method `SubGroupHtml(SubGroupHtmlMsg)`.



## 18.2. Detailed Module Documentation

### 18.2.1. Properties

- **string ConsumerId**

Unique identifier for end user which receive the called data.

**Property-Value**

Unique end user identifier.

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **string LanguageCode**

Gets or sets the 2-letter international language code as defined by ISO 639-1.

**Property-Value**

The ISO language code.

- **string LinkUrl**

Gets or sets the link url. The actual link information is going to be added at the end of this url.

It is used where documents contains links to other and are shown in custom application.

**Property-Value**

The link url.

**Example**

```
LinkURL = "http://localhost/" // -> Generated link in documents:
```

```
http://localhost/12345;
```

- **bool PrintView**

Gets or sets a value indicating whether the HTML file should be prepared for printing.

**Property-Value**

true if prepared for printing; otherwise, false.

- **int SubGroupId**

Gets or sets the TecRMI topic sub group id.

The id can be fetched by using the topic tree methods from the respective modules.

**Property-Value**

The topic sub group id.

- **int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.

## 19. VehicleHasAdjustMsg

### 19.1. Summary

Class [RestRMI.Areas.Ad.Models.VehicleHasAdjustMsg](#) contains the properties which are necessary to call the web service module check methods.

### 19.2. Detailed Module Documentation

#### 19.2.1. Properties

- **string CountryCode**

Gets or sets the 2-letter international country code as defined by ISO 3166-1.

**Property-Value**

The ISO country code.

- **int TypeId**

Gets or sets the TecRMI type id which identifies a vehicle unique.

The id can be fetched by using the ServiceVt web service.

**Property-Value**

The TecRMI type id.