

Linuxup Push API

Contents

Overview..... 2

Positions..... 3

Fence Events..... 6

Stops..... 8

Usage Hours..... 10

Trips..... 12

Alerts..... 14

Device Updates..... 16

Appendix A..... 17

Linuxup Push API

Overview

This document describes how we push data to customers in real time. Customers are required to provide the following for this API to be configured:

- One or more of the following SSL secured URL end points that we can send JSON to:
 - SSL secured URL for POSTing GPS positions and fence events.
 - SSL secured URL for POSTing stops.
 - SSL secured URL for POSTing trips.
 - SSL secured URL for POSTing usage hour segments.
 - SSL secured URL for POSTing alerts.
- Bearer token that will be included in every call to the customer's URLs in the "Authentication" header.
- A single URL can be provided for all data.
- We plan to add items to the pushed data in the future, so please be flexible in your JSON parsing.

Linuxup Push API

Positions

Whenever a GPS position is received from a device, it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- pushType – should be set to “POSITION”.
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - “Linuxup AT3”, for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fenceName - name of geofence which contains the device.
- geofenceUUID - unique identifier for geofence which contains the device.
- fleetName – name of the group device belongs to (set to “Default” if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. “Chevrolet”).
- model – model of vehicle device is installed in (e.g. “Silverado”).
- year – year of vehicle device is installed in (e.g. “2011”).
- date - milliseconds since epoch.
- formattedDate - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- latitude
- longitude
- altitude – in meters.
- speed - in mph.
- heading - the heading (e.g. "N", "SE", etc.). May be "None" if not moving.
- direction - degrees from north. See Appendix A: Direction.
- odo – odometer in miles (some devices provide actual odo, others virtual calculated via GPS).
- battery – voltage of battery. In case of asset trackers 2 values separated by “/” are provided – external and internal voltages (e.g. “12.1” or “14.1/4.0”). For asset trackers, internal voltage of 4.2V means fully charged while less than 3.3 means discharged.
- fuelLevel - only available on newer plugins. Reported as a percentage.
- estSpeedLimit - estimated speed limit at the lat/lon. Not guaranteed to be present.
- speeding - whether the device was considered speeding (above the estimated speed limit). If the speed is 0, may be null.
- behaviorCd - an alert for the position.
 - "HAC" - rapid acceleration.
 - "HBR" - harsh braking.
- street – generally not present.
- city - generally not present.

Linxup Push API

- stateCode - generally not present.
- postalCode - generally not present.
- countryCode - generally not present.
- currentState – STOPPED or MOVING are the two possible values.
- engineOn – true or false.
- sensorData - array of sensor readings each of which has:
 - o sensorNumber - number of sensor (starts at 0)
 - o temperature - temperature in degrees Fahrenheit
 - o humidity - relative humidity percentage
- customerUUID - unique identifier for customer.

Example

```
{
  "altitude": 174,
  "battery": "12.4",
  "behaviorCd": null,
  "city": null,
  "countryCode": null,
  "currentState": "STOPPED",
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",
  "date": 1442392916000,
  "deviceNumber": "351112223334444",
  "deviceSerialNumber": "SN123456",
  "deviceTypeDescription": "Linxup Plugin",
  "deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
  "direction": 0,
  "driverNumber": "DRV01234",
  "engineOn": false,
  "estSpeedLimit": null,
  "fenceName": "Depot 1",
  "geofenceUUID": "0efc215a-47d7-4b07-89fc-89f8fb3b5906",
  "firstName": "Bill",
  "fleetName": "Default",
  "formattedDate": "2015-09-16T03:41:56-0500",
  "fuelLevel": "88.1%",
  "heading": "N",
  "lastName": "McCoy",
  "latitude": 38.67386,
  "longitude": -90.5117,
  "make": "Chevrolet",
  "model": "Colorado",
  "odo": 15124,
  "postalCode": null,
  "pushType": "POSITION",
  "sensorData": [
    {
      "humidity": 29.71,
      "sensorNumber": 0,
      "temperature": 24.91
    }
  ],
  "speed": 0,
  "speeding": false,
```

Linuxup Push API

```
"stateCode": null,  
"street": null,  
"vin": "1WAHSBE44G3230973",  
"year": "2013"  
}
```

Fence Events

Whenever a GPS position is received from a device that results in a fence being entered or exited, it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- pushType – should be set to "FENCE_EVENT".
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - "Linxup AT3", for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fenceName - name of geofence which contains the device.
- geofenceUUID - unique identifier for geofence which contains the device.
- fleetName – name of the group device belongs to (set to "Default" if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. "Chevrolet").
- model – model of vehicle device is installed in (e.g. "Silverado").
- year – year of vehicle device is installed in (e.g. "2011").
- fenceEventCd - FENCE_ENTER or FENCE_EXIT.
- date - milliseconds since epoch.
- formattedDate - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- latitude
- longitude
- altitude – in meters.
- speed - in mph.
- heading - the heading (e.g. "N", "SE", etc.). May be "None" if not moving.
- direction - degrees from north. See Appendix A: Direction.
- odo – odometer value in miles (some devices provide actual odo, others virtual calculated via GPS).
- battery – voltage of battery. In case of asset trackers 2 values separated by "/" are provided – external and internal voltages (e.g. "12.1" or "14.1/4.0"). For asset trackers, internal voltage of 4.2V means fully charged while less than 3.3 means discharged.
- fuelLevel - only available on newer plugins. Reported as a percentage.
- estSpeedLimit - estimated speed limit at the lat/lon. Not guaranteed to be present.
- speeding - whether the device was considered speeding (above the estimated speed limit). If the speed is 0, may be null.
- behaviorCd - an alert for the position.
 - "HAC" - rapid acceleration.
 - "HBR" - harsh braking.
- street – generally not present.

Linxup Push API

- city - generally not present.
- stateCode - generally not present.
- postalCode - generally not present.
- countryCode - generally not present.
- currentState – STOPPED or MOVING are the two possible values.
- engineOn – true or false
- customerUUID - unique identifier for customer.

Example

```
{
  "altitude": 174,
  "battery": "12.4",
  "behaviorCd": null,
  "city": null,
  "countryCode": null,
  "currentState": "STOPPED",
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",
  "date": 1442392916000,
  "deviceNumber": "351112223334444",
  "deviceSerialNumber": "SN123456",
  "deviceTypeDescription": "Linxup Plugin",
  "deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
  "direction": 0,
  "driverNumber": "DRV01234",
  "engineOn": false,
  "estSpeedLimit": null,
  "fenceEventCd": "FENCE_ENTER",
  "fenceName": "Depot 1",
  "firstName": "Bill",
  "fleetName": "Default",
  "formattedDate": "2015-09-16T03:41:56-0500",
  "fuelLevel": "88.1%",
  "geofenceUUID": "0efc215a-47d7-4b07-89fc-89f8fb3b5906",
  "heading": "N",
  "lastName": "McCoy",
  "latitude": 38.67386,
  "longitude": -90.5117,
  "make": "Chevrolet",
  "model": "Colorado",
  "odo": 15124,
  "postalCode": null,
  "pushType": "FENCE_EVENT",
  "speed": 0,
  "speeding": false,
  "stateCode": null,
  "street": null,
  "vin": "1WAHSBE44G3230973",
  "year": "2013"
}
```

Linxup Push API

Stops

Whenever a stop concludes, it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- pushType – should be set to “STOP”.
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - "Linxup AT3", for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fenceName - name of geofence which contains the device.
- geofenceUUID - unique identifier for geofence which contains the device.
- fleetName – name of the group device belongs to (set to “Default” if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. “Chevrolet”).
- model – model of vehicle device is installed in (e.g. “Silverado”).
- year – year of vehicle device is installed in (e.g. “2011”).
- latitude
- longitude
- startDateTime - milliseconds since epoch.
- formattedStartDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- endDateTime - milliseconds since epoch.
- formattedEndDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- durationMinutes – the duration of the stop in minutes.
- street – street address of the stop (not guaranteed to be present).
- city – city of the stop (not guaranteed to be present).
- stateCode – state of the stop (not guaranteed to be present).
- postalCode – postal code of the stop (not guaranteed to be present).
- countryCode – country code of the stop (not guaranteed to be present).
- stopType – “Engine Off” or “Idling”
- customerUUID - unique identifier for customer.

Example

```
{  
  "city": "Weldon Spring",  
  "countryCode": "USA",  
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",  
  "deviceNumber": "351112223334444",  
  "deviceSerialNumber": "SN123456",  
  "deviceTypeDescription": "Linxup Plugin",  
}
```


Linuxup Push API

```
"deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
"driverNumber": "DRV01234",
"durationMinutes": 60,
"endDateTime": 1506436325574,
"fenceName": "Depot 1",
"firstName": "Bill",
"fleetName": "Default",
"formattedEndDateTime": "2017-09-26T09:32:05-0500",
"formattedStartDateTime": "2017-09-26T08:32:05-0500",
"geofenceUUID": "0efc215a-47d7-4b07-89fc-89f8fb3b5906",
"lastName": "McCoy",
"latitude": 38.7156,
"longitude": -90.6702,
"make": "Chevrolet",
"model": "Colorado",
"postalCode": "63304",
"pushType": "STOP",
"startDateTime": 1506432725574,
"stateCode": "MO",
"stopType": "Engine Off",
"street": "612 Northbrook Court",
"vin": "1WAHSBE44G3230973",
"year": "2013"
}
```

Usage Hours

Whenever an asset concludes a usage session (ignition off received from a properly wired device), it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- pushType – should be set to “USAGE_HOURS”.
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - "Linxup AT3", for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fenceName - name of geofence which contains the device.
- geofenceUUID - unique identifier for geofence which contains the device.
- fleetName – name of the group device belongs to (set to “Default” if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. “Chevrolet”).
- model – model of vehicle device is installed in (e.g. “Silverado”).
- year – year of vehicle device is installed in (e.g. “2011”).
- startDateTime - milliseconds since epoch.
- formattedStartDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- startLatitude
- startLongitude
- startAddress - if available.
- startFenceName - if available.
- endDateTime - milliseconds since epoch.
- formattedEndDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- endLatitude
- endLongitude
- endAddress - if available.
- endFenceName - if available.
- durationMinutes - duration in minutes.
- customerUUID - unique identifier for customer.

Example

```
{
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",
  "deviceNumber": "351112223334444",
  "deviceSerialNumber": "SN123456",
  "deviceTypeDescription": "Linxup Plugin",
  "deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
  "driverNumber": "DRV01234",
```

Linuxup Push API

```
"durationMinutes": 60,
"endAddress": "123 Circle Dr, Chesterfield, MO 63017",
"endDateTime": 1506436325574,
"endFenceName": "Depot 1",
"endLatitude": 38.7156,
"endLongitude": -90.6702,
"fenceName": "Depot 1",
"firstName": "Bill",
"fleetName": "Default",
"formattedEndDateTime": "2017-09-26T09:32:05-0500",
"formattedStartDateTime": "2017-09-26T08:32:05-0500",
"geofenceUUID": "0efc215a-47d7-4b07-89fc-89f8fb3b5906",
"lastName": "McCoy",
"make": "Chevrolet",
"model": "Colorado",
"pushType": "USAGE_HOURS",
"startAddress": "123 Circle Dr, Chesterfield, MO 63017",
"startDateTime": 1506432725574,
"startFenceName": "Depot 1",
"startLatitude": 38.7156,
"startLongitude": -90.6702,
"vin": "1WAHSBE44G3230973",
"year": "2013"
}
```

Linxup Push API

Trips

Whenever a vehicle concludes a usage session (ignition off received from a properly wired device), it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- pushType – should be set to “TRIP”.
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - "Linxup AT3", for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fleetName – name of the group device belongs to (set to “Default” if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. “Chevrolet”).
- model – model of vehicle device is installed in (e.g. “Silverado”).
- year – year of vehicle device is installed in (e.g. “2011”).
- startDateTime - milliseconds since epoch.
- formattedStartDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- startLatitude
- startLongitude
- startAddress - if available.
- endDateTime - milliseconds since epoch.
- formattedEndDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- endLatitude
- endLongitude
- endAddress - if available.
- durationMinutes - duration in minutes.
- distanceMiles – distance in miles (rounded to nearest mile).
- authorizedMiles – distance driven within allowed hours (rounded to nearest mile).
- unauthorizedMiles – distance driven outside of allowed hours (rounded to nearest mile).
- distanceMilesDetailed – distance in miles (to 3 decimal places).
- authorizedMilesDetailed – distance driven within allowed hours (to 3 decimal places).
- unauthorizedMilesDetailed – distance driven outside of allowed hours (to 3 decimal places).
- customerUUID - unique identifier for customer.

Example

```
{  
  "authorizedMiles": 25,  
  "authorizedMilesDetailed": 24.781,  
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",  
  "deviceNumber": "351112223334444",
```

Linuxup Push API

```
"deviceSerialNumber": "SN123456",
"deviceTypeDescription": "Linuxup Plugin",
"deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
"distanceMiles": 25,
"distanceMilesDetailed": 24.781,
"driverNumber": "DRV01234",
"durationMinutes": 60,
"endAddress": "123 Circle Dr, Chesterfield, MO 63017",
"endDateTime": 1506436325574,
"endLatitude": 38.7156,
"endLongitude": -90.6702,
"firstName": "Bill",
"fleetName": "Default",
"formattedEndDateTime": "2017-09-26T09:32:05-0500",
"formattedStartDateTime": "2017-09-26T08:32:05-0500",
"lastName": "McCoy",
"make": "Chevrolet",
"model": "Colorado",
"pushType": "TRIP",
"startAddress": "123 Circle Dr, Chesterfield, MO 63017",
"startDateTime": 1506432725574,
"startLatitude": 38.7156,
"startLongitude": -90.6702,
"unauthorizedMiles": 0,
"unauthorizedMilesDetailed": 0,
"vin": "1WAHSBE44G3230973",
"year": "2013"
}
```

Linxup Push API

Alerts

Whenever a vehicle generates an alert, it will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Alert types are:

- FIRST_IGNITION_OF_DAY
- GEOFENCE_ENTERED
- GEOFENCE_EXITED
- HARSH_BRAKING
- HIGH_SPEED - Vehicle has exceed a hard upper limit set by the customer
- SPEEDING - Vehicle has exceed the posted speed limit (including buffer)
- IDLE_START - Vehicle has started idling (engine on, not moving)
- IDLE_END
- NO_SIGNAL - Device has not reported in (12 hours for vehicles, 50 for assets)
- RAPID_ACCELERATION
- SENSOR_USE_EXCEEDS_LIMIT - Sensor has gone HIGH more than allowed limit
- SENSOR_UNAUTHORIZED_USE - Sensor has gone HIGH outside of authorized hours
- POWER_ON - Device has powered on (this is also known as TAMPER)
- UNAUTHORIZED_USE - Vehicle is being used outside of authorized hours
- ASSET_LOW_BATTERY
- DIAGNOSTIC_TROUBLE_CODE_NEW - Vehicle has thrown a new diagnostic code
- DIAGNOSTIC_TROUBLE_CODE_CLEAR - Vehicle has cleared a diagnostic code
- SENSOR_ONE_HIGH
- SENSOR_ONE_LOW
- SENSOR_TWO_HIGH
- SENSOR_TWO_LOW

Note that all alert types are not available on all devices. For example, ASSET_LOW_BATTERY is not available on OBD2 plugs. Some, like SENSOR types, require additional wiring. Some, like DIAGNOSTIC types, are only available on OBD2 plugs.

Data sent

- pushType – should be set to “ALERT”.
- deviceNumber - unique IMEI of the device.
- deviceSerialNumber – manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- deviceTypeDescription - "Linxup AT3", for example.
- driverNumber – unique alphanumeric value assigned to this device by customer.
- firstName – first name assigned to this device by customer.
- lastName – last name assigned to this device by customer.
- fenceName - name of geofence which contains the device.
- geofenceUUID - unique identifier for geofence which contains the device.
- fleetName – name of the group device belongs to (set to “Default” if no groups set up)
- vin – VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make – make of vehicle device is installed in (e.g. “Chevrolet”).

Linxup Push API

- model – model of vehicle device is installed in (e.g. “Silverado”).
- year – year of vehicle device is installed in (e.g. “2011”).
- alertCode – The type of alert.
- alertShortDesc – Short description, suitable for a subject line.
- alertDesc – Long description of the alert.
- alertDateTime - milliseconds since epoch.
- formattedAlertDateTime - ISO 8601 format (yyyy-MM-dd'T'HH:mm:ssZ).
- customerUUID - unique identifier for customer.

Example

```
{
  "alertCode": "NO_SIGNAL",
  "alertDateTime": 1506432725574,
  "alertDesc": "Tracking device has not reported a location for more than 12 hours.",
  "alertShortDesc": "No Signal Alert",
  "customerUUID": "6499d7a4-529b-45b9-a8b9-910dc22fc655",
  "deviceNumber": "351112223334444",
  "deviceSerialNumber": "SN123456",
  "deviceTypeDescription": "Plugin",
  "deviceUUID": "366a471b-3064-4cef-8f20-b6c4eed33687",
  "driverNumber": "DRV01234",
  "fenceName": "Depot 1",
  "firstName": "Bill",
  "fleetName": "Default",
  "formattedAlertDateTime": "2017-09-26T08:32:05-0500",
  "geofenceUUID": "0efc215a-47d7-4b07-89fc-89f8fb3b5906",
  "lastName": "McCoy",
  "make": "Chevrolet",
  "model": "Colorado",
  "pushType": "ALERT",
  "vin": "1WAHSE44G3230973",
  "year": "2013"
}
```

Device Updates

Whenever information about a tracker or the vehicle in which it's installed are updated, a message will be posted to the provided URL in JSON format. HTTP status code of 201 should be returned in response.

Data sent

- deviceNumber - unique IMEI of the device.
- deviceSerialNumber - manufacturer serial number of the device.
- deviceUUID - unique identifier for the device.
- driverNumber - unique alphanumeric value assigned to this device by customer.
- customerUUID - unique identifier for customer.
- firstName - first name assigned to this device by customer.
- lastName - last name assigned to this device by customer.
- deviceTypeDescription - "Linxup AT3", for example.
- vin - VIN of vehicle device is installed in. Automatically obtained on most newer plugins.
- make - make of vehicle device is installed in (e.g. "Chevrolet").
- model - model of vehicle device is installed in (e.g. "Silverado").
- year - year of vehicle device is installed in (e.g. "2011").
- fleetName - The name of the group that the device is assigned to.

Example

```
{
  "deviceNumber": '3519340418424',
  "deviceSerialNumber": 'VB581556027',
  "deviceUUID": '43b1b40e-096d-4660-8c3c-a46bc98c72ee',
  "driverNumber": null,
  "customerUUID": 'db20426d-d502-4e43-ab32-f451153c0a77',
  "firstName": 'Example',
  "lastName": 'Device',
  "deviceTypeDescription": 'Linxup Wired (3G Dual-Band 2160)',
  "vin": "1WAHSBE44G3230973",
  "make": "Chevrolet",
  "model": "Colorado",
  "year": "2013",
  "fleetName": 'Fake No Group'
}
```


Appendix A

Direction

Whenever direction in degrees from north is provided, you can interpret it as follows:

- 0-22 or 338-360 = N
- 23-67 = NE
- 68-112 = E
- 113-157 = SE
- 158-202 = S
- 203-247 = SW
- 248-292 = W
- 293-337 = NW