## LS1043 GPIO support in Linux SDK

This document introduces how to configure RCW to support GPIO on LS1043 platform, how to configure Linux Kernel to load Linux GPIO driver to access GPIO from SYSFS and using loopback method to do verification on the target board.

## 1. RCW configuration to support GPIO

On LS1043 UART and GPIO signal multiplexing, users need to configure RCW[UART\_BASE] to GPIO, there are 6 options defined in LS1043 reference manual.

366-368	UART_BASE	This field configures functionality of UART pins.	Options:
			000 {GPIO1_15, GPIO1_17, GPIO1_19], GPIO1_21], GPIO1_16], GPIO1_18], GPIO1_20], GPIO1_22]}
			011 {UART1_SOUT, UART1_SIN, GPIO1[19], GPIO1[21], GPIO1[16], GPIO1[18]. GPIO1_20], GPIO1_22] }
			100 {UART1_SOUT, UART1_SIN, UART1_RTS_B, UART1_CTS_B, GPIO1_16], GPIO1_18, GPIO1_20, GPIO1_22}
			101 {UART1_SOUT, UART1_SIN, GPIO1_19, GPIO1_[21], UART2_SOUT, UART2_SIN, GPIO1_20], GPIO1_22}
			110 {UART1_SOUT, UART1_SIN, UART1_RTS_B, UART1_CTS_B, UART2_SOUT, UART2_SIN, UART2_RTS_B, UART2_CTS_B}
			111 {UART1_SOUT, UART1_SIN, UART3_SOUT, UART3_SIN, UART2_SOUT, UART2_SIN, UART4_SOUT, UART4_SIN}

Uses could choose RCW[UART\_BASE] option from 0b011, 0b100 and 0b101.

For 0b011, 8 pins are defined, UART1\_SOUT, UART1\_SIN, GPIO1[19], GPIO1[21], GPIO1[16], GPIO1[18]. GPIO1[20], GPIO1[22], 2 pins for UART1 and 6 pins for GPIO. In this option, UART1 doesn't have RTS & CTS pins, so it doesn't support hardware flow control.

For 0b100, 8 pins are defined, UART1\_SOUT, UART1\_SIN, UART1\_RTS\_B, UART1\_CTS\_B, GPIO1[16], GPIO1[18], GPIO1[20], GPIO1[22], 4 pins for UART1 and 4 pins for GPIO. In this option, UART1 has RTS & CTS pins so it supports Hardware flow control.

For 0b101, 8 pins are defined, UART1\_SOUT, UART1\_SIN, GPIO1[19], GPIO1[21], UART2\_SOUT, UART2\_SIN, GPIO1[20], GPIO1[22], 2 pins for UART1, 2 pins for UART2, 4 pins for GPIO. In this option, 2 UART ports are enabled and with extra 4 GPIO pins. Both UART ports have no hardware flow control support.

The users need to configure RCW[UART\_BASE] according to their requirement about UART and GPIO. If UART hardware flow control is required, users could choose 0b100 and use UART1. If no hardware flow control required, users could choose one of above three options according to GPIO pins number.

In Linux SDK, RCW[UART\_BASE] is configured as 0b111 by default, the user needs to modify RCW configuration to support GPIO. The following introduces how to regenerate RCW binary file in Linux SDK, RCW[UART\_BASE] will be configured as 0b100.

\$ bitbake rcw -c cleansstate

\$ bitbake rcw -c configure

Go to the source folder build\_ls1043ardb/tmp/work/ls1043ardb-fsl-linux/rcw/git-r0/git/ls1043ardb/RR\_FQPP\_1455, configure UART\_BASE as 4 in rcw\_1600.rcw, go back to the build folder.

\$ bitbake rcw
Get rcw\_1600.bin in
build ls1043ardb/tmp/deploy/images/ls1043ardb/rcw/ls1043ardb/RR FQPP 1455.

## 2. Configure GPIO driver in Linux Kernel

LS1043 platform could use GPIO driver for PowerPC architecture. Individual GPIO signals may be accessed from userspace, GPIOs are only made available to userspace by an explicit "export" operation. The user needs to configure the following Kernel options as the following.

```
CONFIG_ARCH_WANT_OPTIONAL_GPIOLIB=y
CONFIG_ARCH_REQUIRE_GPIOLIB=y
CONFIG_GPIOLIB=y
CONFIG_GPIO_DEVRES=y
CONFIG_OF_GPIO=y
CONFIG_GPIOLIB_IRQCHIP=y
CONFIG_GPIO_SYSFS=y
CONFIG_GPIO_GENERIC=y
CONFIG_GPIO_GENERIC_PLATFORM=y
CONFIG_GPIO_MPC8XXX=y
CONFIG_GPIO_XGENE=y
CONFIG_DEBUG_FS=y
```

The user could use the following procedure to rebuild Linux Kernel with GPIO enabled.

\$ bitbake virtual/kernel -c cleansstate

\$ bitbake virtual/kernel -c configure

Go to the folder /home/b25805/test/QorIQ-SDK-V2.0-20160527-

yocto/build\_ls1043ardb/tmp/work/ls1043ardb-fsl-linux/linux-qoriq/4.1-r0/build/ to configure Kernel with the command "make ARCH=arm64 menuconfig".

```
--- GPIO Support

[ ] Debug GPIO calls
[*] /sys/class/gpio/... (sysfs interface)

Memory mapped GPIO drivers --->

T2C GPIO expanders --->

MFD GPIO expanders ----

PCI GPIO expanders --->
SPI GPIO expanders --->
USB GPIO expanders --->
```

```
Sepio driver for 74xx-ICs with MMIO access
> Altera GPIO
> Synopsys DesignWare APB GPIO driver
-*- Generic memory-mapped GPIO controller support (MMIO platform device)
> Aeroflex Gaisler GRGPIO support
|* MPC512x/MPC8xxx/QorIQ GPIO support
> Qualcomm MSM GPIO v2
|* PrimeCell PL061 GPIO support
> SMSC SCH311x SuperI/O GPIO
> GPIO based on SYSCON
> VIA VX855/VX875 GPIO
|* APM X-Gene GPIO controller support
> APM X-Gene GPIO standby controller support
```

Regenerate Kernel itb image

\$ bitbake fsl-image-kernelitb

## 3. Verify GPIO on the target board

```
Program RCW on NOR flash and reset the target board.
```

- => tftp 82000000 b25805/ls1043ardb/rcw\_1600.bin
- => protect off 60000000 +\$filesize
- => erase 60000000 +\$filesize
- => cp.b 82000000 60000000 \$filesize
- => protect on 60000000 +\$filesize
- => reset

u-boot console log is as the following:

U-Boot 2016.012.0+g187aa26 (Apr 05 2016 - 16:47:25 +0800)

SoC: unknown (0x87920410)

Clock Configuration:

CPU0(A53):1600 MHz CPU1(A53):1600 MHz CPU2(A53):1600 MHz

CPU3(A53):1600 MHz

Bus: 400 MHz DDR: 1600 MT/s FMAN: 500 MHz

Reset Configuration Word (RCW):

00000000: 08100010 0a000000 00000000 00000000

00000010: 14550002 80004012 e0025000 c1002000

00000020: 00000000 00000000 00000000 00020800

00000030: 00000000 00001101 00000096 00000001

I2C: ready

Model: LS1043A RDB Board

Board: LS1043ARDB, boot from vBank 4

Under u-boot set CFG\_MUX\_UART\_S0/1 under uboot to bring the GPIO pins out for testing.

=> mw.b 7fb0005e 0x02

```
GPIO1_22 <---- > JP2_4
```

The following section describes how to verify GPIO under Linux.

GPIOs are defied as they are inside the kernel, using integers in the range 0 .. INT\_MAX.

/sys/class/gpio

/export : asks the kernel to export a GPIO to userspace

/unexport: to return a GPIO to the kernel

/gpioN: for each exported GPIO #N

/value: always readable, writes fail for input GPIOs

/direction: r/w as in, out (default low); write(high, low)

/edge: r/w as none, falling, rising, both

/gpiochipN: for each gpiochip; #N is its first GPIO

/base: (r/o) same as N

/label: (r/o) descriptive, not necessarily unique

/ngpio: (r/o) number of GPIOs; numbered N to N + (ngpio - 1)

GPIO block mapping could be get as the following.

QorIQ SDK (FSL Reference Distro) 2.0 ls1043ardb /dev/ttyS0

Is1043ardb login: root

root@ls1043ardb:~# ls /sys/class/gpio/

export gpiochip384/ gpiochip416/ gpiochip448/ gpiochip480/ unexport

root@ls1043ardb:~# cat /sys/kernel/debug/gpio

GPIOs 384-415, /soc/gpio@2330000:

GPIOs 416-447, /soc/gpio @2320000:

GPIOs 448-479, /soc/gpio @2310000:

GPIOs 480-511, /soc/gpio @2300000:

GPIO496(480+16) corresponds with GPIO1\_16.

Verify GPIO as output as the following.

root@ls1043ardb:/sys/class/gpio# echo 496 > export

root@ls1043aqds:/sys/class/gpio# ls

export gpio496 gpiochip384 gpiochip416 gpiochip448 gpiochip480 unexport

root@ls1043ardb:/sys/class/gpio# echo "out" > gpio496/direction

root@ls1043ardb:/sys/class/gpio# echo 1 > gpio496/value root@ls1043ardb:/sys/class/gpio# echo 0 > gpio496/value root@ls1043ardb:/sys/class/gpio# echo "in" > gpio496/direction root@ls1043ardb:/sys/class/gpio# cat gpio496/value 1

GPIO is used as input and check the interrupt counter. root@ls1043ardb:/sys/class/gpio# ls /sys/class/gpio/ export gpio496 gpiochip384 gpiochip416 gpiochip448 gpiochip480 unexport le root@ls1043ardb:/sys/class/gpio# cd gpio496/ root@ls1043ardb:/sys/class/gpio/gpio496# ls active\_low direction edge power subsystem uevent value root@ls1043ardb:/sys/class/gpio/gpio496# echo out > direction root@ls1043ardb:/sys/class/gpio/gpio496# echo both > edge [ 562.634440] GPIO chip /soc/gpio@2300000: gpiochip\_lock\_as\_irq: tried to flag a GPIO set as output for IRQ root@ls1043ardb:/sys/class/gpio/gpio496# cat /proc/interrupts | grep 8xxx gpiolib, gpiolib 70: 0 mpc8xxx-gpio 16 Edge root@ls1043ardb:/sys/class/gpio/gpio496# echo 1 > value root@ls1043ardb:/sys/class/gpio/gpio496# echo 0 > value root@ls1043ardb:/sys/class/gpio/gpio496# echo 1 > value root@ls1043ardb:/sys/class/gpio/gpio496# cat /proc/interrupts | grep 8xxx 70: 4 0 0 0 mpc8xxx-gpio 16 Edge gpiolib, gpiolib root@ls1043ardb:/sys/class/gpio/gpio496#