# Slat control and monitoring system

Fault isolation — SLAT SYS 1 FAULT

| | | | |
|---|---|---|---|
| **Object code** | DMC-MRDX-A-27-81-00-00A-420A-A | **Issue** | 001-00 (new) |
| **Issue date** | 2026-02-18 | **Language** | en-GB |
| **Responsible partner** | AERALIS S.A.S. (U8025) | **Originator** | AERALIS S.A.S. — Technical Data Valmont (U8025) |
| **Security** | 01 — Unclassified | **Quality assurance** | First verification (tabtop) |
| **Applicability** | MRDX-42 and MRDX-46, all aircraft | | |

## 1. Fault description

The maintenance status page shows the fault message `SLAT SYS 1 FAULT` together with the correlated message `SFCC1 (27CV1)`. The slat system continues to operate on the standby channel at half rate.

Do this procedure after a flight in which the fault message was shown, or after the message is raised during a system test on the ground.

## 2. Job set-up information

### A. Referenced information

| TYPE | DESIGNATION | IDENTIFICATION No. |
|---|---|---|
| DM | The aircraft electrical power is available. | DMC-MRDX-A-24-41-00-00A-861A-A |

### B. Fixtures, tools, test and support equipment

| QTY | DESIGNATION | IDENTIFICATION No. |
|---|---|---|
| 1 | Portable maintenance access terminal | 98D45111000000 (CAGE U8025) |

### C. Consumable materials

*No consumable materials required*

### D. Expendable parts

*No expendable parts required*

### E. Safety conditions

**WARNING**

Make sure that the slat travel area is clear of persons and equipment before you do a system test. The slats move without a warning when the test is started.

## 3. Fault isolation procedure

**STEP 1**

Do the SFCC 1 built-in test on the maintenance terminal. Is the fault message `SFCC1 CHANNEL A` shown at the end of the test?

| ANSWER | ACTION |
|---|---|
| **YES** | The fault is inside the computer or on its power supply.<br>**Go to step 2** |
| **NO** | The fault is in the position feedback or in the wiring.<br>**Go to step 3** |

**STEP 2**

Examine the circuit breaker 4027GA on panel 121VU. Is the circuit breaker tripped?

| ANSWER | ACTION |
|---|---|
| **YES** | **Corrective action:** Reset the circuit breaker and do the slat system operational test. If the circuit breaker trips again, replace the SFCC 1.<br>**Go to the end of the procedure** |
| **NO** | **Corrective action:** Replace the SFCC 1 and do the slat system operational test.<br>**Go to the end of the procedure** |

**STEP 3**

Do a continuity check of the harness between connector 2027VC on the PCU and connector 2101VC on the SFCC 1. Is the resistance of each conductor less than 1.5 ohm?

| ANSWER | ACTION |
|---|---|
| **YES** | **Corrective action:** Replace the feedback position pick-off unit on the PCU output and do the slat system operational test.<br>**Go to the end of the procedure** |
| **NO** | **Corrective action:** Repair the harness between the two connectors and do the slat system operational test.<br>**Go to the end of the procedure** |

**END OF FAULT ISOLATION PROCEDURE**

Make sure that no fault message is shown on the maintenance status page and make an entry in the aircraft technical log.

## 4. Close-up

Remove the maintenance terminal and close the access panels.