Contents

MRDX Aircraft Maintenance Manual — ATA 27 Flight Controls

Object code	PMC-MRDX-U8025-00027-00	**Issue**	007-00 (revised)
Issue date	2026-07-01	**Language**	en-GB
Responsible partner	AERALIS S.A.S. (U8025)	**Originator**	—
Security	02 — Restricted	**Quality assurance**	First verification (tabtop)
Applicability	MRDX-42 and MRDX-46, all aircraft		

Contents

1 Slat control and monitoring system

1.1 Description and operation

Slat control and monitoring system — Description of function····· DMC-MRDX-A-27-81-00-00A-042A-A

High lift system — Description····· DMC-MRDX-A-27-80-00-00A-040A-A

1.2 Fault isolation

Slat control and monitoring system — Fault isolation — SLAT SYS 1 FAULT····· DMC-MRDX-A-27-81-00-00A-420A-A

1.3 Removal and installation

Slat actuation power control unit — Removal····· DMC-MRDX-A-27-81-00-00A-520A-A

Slat actuation power control unit — Installation····· DMC-MRDX-A-27-81-00-00A-720A-A

1.4 Illustrated parts data

Slat actuation power control unit — Illustrated parts data····· DMC-MRDX-A-27-81-00-00A-941A-A

2 Flap control and monitoring system

2.1 Description and operation

Flap control and monitoring system — Description of function····· DMC-MRDX-A-27-51-00-00A-042A-A

2.2 Scheduled maintenance

Flap transmission — Scheduled maintenance····· DMC-MRDX-A-27-51-00-00A-310A-A

3 Referenced publications

MRDX Aircraft Wiring Manual — ATA 27····· PMC-MRDX-U8025-00029-00

Graphic symbols for aircraft hydraulic and pneumatic systems····· SAE AS1290