CONTENTS:

PAGE1 - CONTENTS

PAGE2 - POWER, CM4, MIC, USB,SD CARD

PAGE3 - CSI, DSI, HDMI,SPEAKER,GYRO,MCU

REVISION HISTORY:

11/30/2018 - V1.0 - Initial Version

7/10/2018 - V1.1 - Change USB\SD\HDMI connectors and optimize the fist version .

2/17/2020 - V1.2 - Change battery charge with NTC wire and D17\D18 symbol ,add BT_DIS.

9/10/2020 - V1.3 - Add 22 Ohm resistors to SD CLK and data line for ESD protection;
                    Change LCD RST pull up voltage to 1V8.

9/24/2020 - V1.3 - Change Camera and HDMI share one I2C Line ;

11/11/2020 - V2.0 - Change CM3 TO CM4 and all the peripherals ;

DISPLAY

CAMMERA 1

CAMMERA 0

B/L

7P3S

SPEAKER

Micro-HDMI

MCU

GYRO

ADDR:1101000

TOUCH Panel

This page is a full schematic / circuit diagram consisting of electronic component labels, reference designators, and net names distributed across the board layout. Representative annotations include:

BATTERY

CHARGE MAX=1.45A
IN MAX=2.1A
OUT MAX=2.8A

EN=H->CHARGE
MODE=H->BOOST

2 wires battery need remove 10K res !!!

USB A

PUSH-PUSH SD CARD

SD Card

MIC2

MIC1