

SCC.131: Digital Systems Introduction to C/C++ CODAL (Part 1)

Ioannis Chatzigeorgiou (i.chatzigeorgiou@lancaster.ac.uk)

Summary of the last lecture



The following points were covered in the last lecture:

- What the key hardware components of micro:bit are and how they interact.
- What the functions of the target MCU and the interface MCU are.
- What the role of the interface firmware (DAPLink) is.
- How the runtime environment (CODAL) facilitates code development.
- What the pros and cons of compiled code and interpreted code are when it is flashed to the micro:bit.
- How micro:bit can be programmed using MakeCode.

Latest version of CODAL



• The repository that provides the necessary tooling to compile a **C/C++ CODAL** program for the micro:bit V2 and generate a HEX file that can be downloaded to the device is:

https://github.com/lancaster-university/microbit-v2-samples


- Pre-requisite tools to build the repo include the **GNU Arm Embedded Toolchain**, **Git**, **Cmake** and **Python 3**. Details on how to install them are provided in README.md in the repository above.
- Ubuntu **Linux** is as assumed. Windows users should install the **Windows Subsystem for Linux** (WSL), install the pre-requisite tools and then clone the repository.
- Given that the repository is constantly updated / upgraded, we have created a stable **copy** of the repository, which can be found in scc-source.lancs.ac.uk.

How to build MICROBIT.hex



- Clone the repository https://scc-source.lancs.ac.uk/scc.Y1/scc.131/microbit-v2-samples
 - git clone https://scc-source.lancs.ac.uk/scc.Y1/scc.131/microbit-v2-samples.git
- In the root of the folder, where you cloned the repository, type:
 - python3 build.py (or python build.py, depending on the installed Python version)
- The hex file MICROBIT. hex will be created in the root.
- Open File Explorer (Windows), find the location of the Windows Subsystem for Linux and go to the folder **microbit-v2-samples**, where the file MICROBIT. hex is located.
- Connect micro:bit and transfer the file MICROBIT.hex across (i.e., drag and drop).

How to build MICROBIT.hex






- Type:
 python3 build.py
 to create
 MICROBIT.hex
- Drag and drop
 MICROBIT.hex
 to the micro:bit
 'USB disk'

Problems?



- Since an update to **Windows** in February 2023, an increase in the prevalence of errors 504, 506, 521 and 537 has been observed (FAIL.TXT ⇒ error: The transfer timed out).
- The issue is with **DAPLink** (software for Arm Cortex CPUs that makes micro:bit appear as a USB drive when connected to a Windows PC).



- Programmers experience longer flashing times when using the drag-and-drop method to copy files to the micro:bit drive.
- Preferred workaround: WebUSB (https://microbit.org/tools/webusb-hex-flashing/)
 - WebUSB is a way for your browser to connect directly to the micro:bit.
 - WebUSB works in Google Chrome (version 79 or newer) and Microsoft Edge (recommended version 79 or newer).

WebUSB (https://microbit.org/tools/webusb-hex-flashing/)



micro:bit WebUSB hex file flashing tool This tool uses WebUSB to flash (program) a hex file that you already have to a BBC micro:bit. It works in Google Chrome and Microsoft Edge browsers, and can be used instead of drag-anddropping your hex file onto the MICROBIT drive. Drag and drop a hex file here Drag-and-drop or click to browse MICROBIT.hex Note: If your hex file was created with Microsoft MakeCode or the Python Editor we recommend that you open the hex file in those tools (in Google Chrome or Microsoft Edge) and use WebUSB to flash them from inside those editors. In MakeCode, choose "Connect Device" from the "..." menu to the right of the "Download" button. In the Python Editor, use "Send to micro:bit".

WebUSB (https://microbit.org/tools/webusb-hex-flashing/)



micro:bit WebUSB hex file flashing tool

This tool uses WebUSB to flash (program) a hex file that you already have to a BBC micro:bit. It works in Google Chrome and Microsoft Edge browsers, and can be used instead of drag-and-dropping your hex file onto the MICROBIT drive.

File: MICROBIT.hex

Send to micro:bit

Note: If your hex file was created with Microsoft MakeCode or the Python Editor we recommend that you open the hex file in those tools (in Google Chrome or Microsoft Edge) and use WebUSB to flash them from inside those editors. In MakeCode, choose "Connect Device" from the "..." menu to the right of the "Download" button. In the Python Editor, use "Send to micro:bit".

WebUSB (https://microbit.org/tools/webusb-hex-flashing/)



micro:bit WebUSB hex file flashing tool

This tool uses WebUSB to flash (program) a hex file that you already have to a BBC micro:bit. It works in Google Chrome and Microsoft Edge browsers, and can be used instead of drag-and-dropping your hex file onto the MICROBIT drive.

Flashing hex file...

Note: If your hex file was created with Microsoft MakeCode or the Python Editor we recommend that you open the hex file in those tools (in Google Chrome or Microsoft Edge) and use WebUSB to flash them from inside those editors. In MakeCode, choose "Connect Device" from the "..." menu to the right of the "Download" button. In the Python Editor, use "Send to micro:bit".

Summary of methods to upload HEX file



- 1. Drag the icon of the HEX file and drop it into the MICROBIT USB drive.
- 2. ... or use WebUSB to upload the HEX file onto the micro:bit device.
- 3. ... or type the following command in the terminal of a lab machine:

cp MICROBIT.hex /media/\$USER/MICROBIT

The MicroBit class



• The MicroBit class consists of **variables** and **methods** (i.e., resources) that operate as drivers to control commonly used features of the micro:bit.

uBit.storage
uBit.serial
uBit.MessageBus
uBit.buttonA
uBit.buttonB
uBit.display
uBit.accelerometer
uBit.compass
uBit.thermometer
uBit.io
uBit.radio

uBit.i2c

"Hello World!" for micro:bit



#include "MicroBit.h" Include the library that contains key functions for micro:bit. MicroBit uBit; int main() Declare uBit as a 'variable' of type MicroBit. uBit.init(); (Create object uBit, which is an while (1) instance of class MicroBit). uBit.display.scroll("HELLO WORLD!"); Initialise uBit (i.e., initialise the scheduler, memory allocator and Bluetooth stack). Scroll "HELLO WORLD!" across the 5×5 display of uBit.

uBit.display (the MicroBitDisplay class)



Scrolling and printing text or numbers

```
uBit.display.scroll("HELLO!");
uBit.display.scroll("HELLO!", 100);
uBit.display.scroll(42);
uBit.display.scroll(42);
uBit.display.scroll(7);
uBit.display.print(7);
```

- The scroll function scrolls a string (or number), pixel by pixel, across the display, from right to left.
- The print function shows the letters of a string (or numbers) in turn on the screen.
- The delay can also be specified: i.e., the lower the value, the faster the message will be scrolled/printed.
- If you print a string/number with two or more characters/digits, each will appear in turn, then disappear.
- If you print a single character/numeric digit, it will stay on screen until you explicitly change the screen.

uBit.display (the MicroBitDisplay class)



Changing Display Mode

```
uBit.display.setDisplayMode(DISPLAY_MODE_BLACK_AND_WHITE);
uBit.display.setDisplayMode(DISPLAY_MODE_BLACK_AND_WHITE_LIGHT_SENSE);
uBit.display.setDisplayMode(DISPLAY_MODE_GREYSCALE);
```

DISPLAY_MODE_BLACK_AND_WHITE: Each pixel can be **on** or **off**. The brightness of all pixels is controlled by the setBrightness function, e.g., uBit.display.setBrightness(value between 1 and 255). This mode is the most efficient, in terms of processing time and battery power.

DISPLAY_MODE_BLACK_AND_WHITE_LIGHT_SENSE: Each pixel can be **on** or **off**, and the display driver will also sense the ambient brightness from the LEDs.

DISPLAY_MODE_GREYSCALE: Each pixel can independently have **256 levels of brightness** (0-255).

uBit.display (the MicroBitDisplay class)



Setting and getting pixel values

```
uBit.display.image.setPixelValue(2,2,255);
int i = uBit.display.image.getPixelValue(2,2);
```

- The function setPixelValue sets the pixel at the given (x, y) co-ordinates to a given brightness value. The coordinates are of type int16_t. The brightness is of type uint8_t.
- The function getPixelValue retrieves the brightness value of the pixel at the given (x, y) co-ordinates.

| (0,0) | (1,0) | (2,0) | (3,0) | (4,0) |
|-------|-------|-------|-------|-------|
| (0,1) | (1,1) | (2,1) | (3,1) | (4,1) |
| (0,2) | (1,2) | (2,2) | (3,2) | (4,2) |
| (0,3) | (1,3) | (2,3) | (3,3) | (4,3) |
| (0,4) | (1,4) | (2,4) | (3,4) | (4,4) |

(x, y) co-ordinates of pixels in the 5×5 display

• When the display mode is set to DISPLAY_MODE_BLACK_AND_WHITE, setting the brightness value to 1, 2, ..., 255, will not make a difference.



Creating and showing images

```
MicroBitImage smiley("0,255,0,255,0\n 0,255,0,255,0\n 0,0,0,0,0\n 255,0,0,0,0,255\n 0,255,255,255,0\n");
uBit.display.print(smiley);
```

- The MicroBitImage class represents a bitmap picture. It is a managed type (memory will be used and release automatically, as needed).
- The **string** constructor takes the form of a series of comma separated values. Each value is the brightness of a pixel value in the range 0 255, starting at the top left of your image and working to the right.
- Whenever you put a newline character \n in the string, this moves onto a new line of pixels.
- The class also provides functions to undertake graphical operations on an image (e.g., setting pixels, clearing the image, pasting one image onto another at a given position, etc.).



Creating and showing images (examples)


```
// Create a 3x3 picture of a cross
MicroBitImage cross("0,1,0\n1,0,1\n0,1,0\n");

// Create a blank 4x4 image (4 columns, 4 rows)
MicroBitImage myImage(4, 4);

// Paste the content of cross onto myImage at pixel (1, 1)
myImage.paste(cross, 1, 1); // Omit co-ordinates for (0, 0)

// Set brightness of pixel (2, 2) to 0
myImage.setPixelValue(2, 2, 0);

// Print myImage
uBit.display.print(myImage);
```






Storing and printing read-only images

- A constant array of unsigned integers can be used to store a read-only picture. Values between 0 and 255 can be used. In this example, we have assumed that micro:bit operates in the black and white mode.
- The MicroBitImage class offers a constructor that creates a bitmap representation of a given size (i.e., 5×5 in this example), based on a given buffer (i.e., the array smiley in this example).
- The dimensions of myImage do not have to be 5×5; any size can be used, provided that the product matches the length of the array.



Storing and printing read-only images (example)




C/C++ examples



Demonstration of code development using C/C++

Objective: Develop code for micro:bit to display a 'flashing heart'.



The script
flashing_heart_v1.cpp
is available on the
SCC.130 Moodle page
(see 'Code' in Week 8).


```
flashing_heart_v1.cpp (1 of 2)
```

```
#include "MicroBit.h"
MicroBit uBit;
int main()
    MicroBitImage largeHeart("0,1,0,1,0\n \
                               1,1,1,1,1\n \
                               1,1,1,1,1\n \
                               0,1,1,1,0\n \
                               0,0,1,0,0(n");
    MicroBitImage smallHeart("0,0,0,0,0)n \
                               0,1,0,1,0 n 
                               0,1,1,1,0\n
                               0,0,1,0,0 n 
                               0,0,0,0,0 \setminus n");
```



```
uBit.init();
uBit.display.setDisplayMode(DISPLAY_MODE_BLACK_AND_WHITE);
while (1)
{
    uBit.display.print(largeHeart); // a large heart
    uBit.sleep(500);
    uBit.display.print(smallHeart); // a small heart
    uBit.sleep(500);
}
```

Objective: Develop code for micro:bit to display a 'trapped dot'.



The script trapped_dot.cpp is available on the SCC.130 Moodle page (see 'Code' in Week 8).

```
#include "MicroBit.h"
MicroBit uBit; // The MicroBit object
int main()
    int16_t x = 0; // The x co-ordinate
    int16_t y = 0; // The y co-ordinate
    // Initialise the micro:bit
    uBit.init();
    // Turn on the pixel in location (x, y)
    uBit.display.image.setPixelValue(x, y, 255);
    // Wait for 100 ms
    uBit.sleep(100)
```



```
#include "MicroBit.h"
MicroBit uBit; // The MicroBit object
int main()
    int16_t x = 0; // The x co-ordinate
    int16_t y = 0; // The y co-ordinate
    // Initialise the micro:bit
    uBit.init();
                                                       (0,0)
    // Turn on the pixel in location (x, y)
    uBit.display.image.setPixelValue(x, y, 255);
    // Wait for 100 ms
    uBit.sleep(100)
```





```
while (1)
    // Turn off the pixel in location (x, y)
    uBit.display.image.setPixelValue(x, y, 0);
    // Consider the edge conditions, i.e., (4,0), (4,4), (0,4), (0,0)
    // and update the x and y co-ordinates accordingly.
    if (x < 4 \&\& y == 0) // left -> right of the top row
            X++;
        else
            if (x == 4 \&\& y < 4) // top -> bottom of right-most column
                V++;
            else
                if (x > 0 \&\& y == 4) // right -> left of the bottom row
                    X - - ;
```



```
trapped_dot.cpp (2 of 3)
```

(4,0)

(4,4)

```
while (1)
                                                                         (0,0)
    // Turn off the pixel in location (x, y)
    uBit.display.image.setPixelValue(x, y, 0);
    // Consider the edge conditions, i.e., (4,0), (4,4), (0,4), (0,0)
    // and update the x and y co-ordinates accordingly.
                                                                         (0,4)
    if (x < 4 \&\& y == 0) // left -> right of the top row
            X++;
        else
            if (x == 4 \&\& y < 4) // top -> bottom of right-most column
                V++;
            else
                if (x > 0 \&\& y == 4) // right -> left of the bottom row
                    X - - ;
```



```
while (1)
    // Turn off the pixel in location (x, y)
    uBit.display.image.setPixelValue(x, y, 0);
    // Consider the edge conditions, i.e., (4,0), (4,4), (0,4), (0,0)
    // and update the x and y co-ordinates accordingly.
    if (x < 4 \&\& y == 0) // left -> right of the top row
        else
            if (x == 4 \&\& y < 4) // top -> bottom of right-most column
            else
                if (x > 0 \&\& y == 4) // right -> left of the bottom row
```



```
else
            if (x == 0 \&\& y > 0) // bottom -> top of left-most column
                y--;
// Turn on the pixel in location (x, y)
uBit.display.image.setPixelValue(x, y, 255);
// Wait for 100 ms
uBit.sleep(100);
```



```
else
            if (x == 0 \&\& y > 0) // bottom -> top of left-most column
// Turn on the pixel in location (x, y)
uBit.display.image.setPixelValue(x, y, 255);
// Wait for 100 ms
uBit.sleep(100);
```

Summary



clears the screen!

Today we learnt:

- How to copy the necessary tools to create C/C++ for micro:bit.
- How to edit main.cpp, build MICROBIT.hex and 'flash' it using Windows, Linux or the browser-based WebUSB approach.
- About the general **MicroBitClass** (init, sleep).
- About the MicroBitDisplay class (scroll, print, setDisplayMode, setBrightness, image.setPixelValue, image.getPixelValue).
- About the MicroBitImage class (setPixelValue, getPixelValue, paste).

Resources



- Tools to compile a C/C++ CODAL program for the micro:bit V2: https://github.com/lancaster-university/microbit-v2-samples
- Tools to compile a C/C++ CODAL program for the micro:bit V2 (stable version for SCC.131): https://scc-source.lancs.ac.uk/scc.Y1/scc.131/microbit-v2-samples
- WebUSB: https://microbit.org/tools/webusb-hex-flashing/
- Microbit documents: https://lancaster-university.github.io/microbit-docs/
 - The MicroBit class: https://lancaster-university.github.io/microbit-docs/ubit/
 - The MicroBitDisplay class: https://lancaster-university.github.io/microbit-docs/ubit/display/
 - The MicroBitImage class:
 https://lancaster-university.github.io/microbit-docs/data-types/image/