
Zählerwert als Bargraph anzeigen Indicating a counter value as a bar graph



X1 X

Prio = 0

Quit = off

Text1: ISO8859_1 Text2: disabled Der Zähler soll bis 20 zählen und dann den Ausgang einschalten.

Also soll der Bargraph auch von 0-20 gehen.

- B004 zeigt den aktuellen Wert des Vorwärts-/Rückwärtszählers an.
- Horizontal und vertikal ist der Zählerwert als Bargraph dargestellt.
 Der Bargraph ist eine Funktion, die im Meldetext ausgewählt wird ("Balkendiagramm in Meldung einfügen").
 Der Wertebereich kann skaliert werden, damit er dem Bereich des Zählers (0-20) entspricht.

The counter shall count up to 20 and shall then switch on its output.

So the bar graph should also has a range from 0-20.

- B004 displays the actual value of the up-/down counter.
- Horizontally and vertically the counter value is indicated as a bargraph.

The bar graph is a function, which can be selected in the message text ("Insert a bar graph into the message"). The value range can be scaled in order to be equal to the range of the counter (0-20).

Creator:	ADBEJO0
Checked:	Beyer
Date:	3/22/10 3:57 PM/3/24/10 2:13 PM



Project:	Zählerwert als Bargraph anzeigen	Customer:	SIEMENS AG
Installation:	Indicating a counter value as a bar graph	Diagram No.:	
File:	indicating_a_counter_value_as_bar_graph.lsc	Page:	1/2

SIEMENS AG- Beispielprogramm

Warnung und Haftungsausschluss

Siemens AG

Programmbeispiel ohne Gewähr

Warnung:

Steuerungen können bei unsicheren Betriebszuständen ausfallen und dadurch den unkontrollierten Betrieb der gesteuerten Geräte verursachen. Solche gefährliche Ereignisse können zu tödlichen und/oder schweren Verletzungen und/oder Sachschaden führen. Sorgen Sie daher für eine NOT-AUS-Funktion, elektrische oder andere redundante Sicherheitseinrichtungen, die von Ihrem Automatisierungssystem unabhängig sind.

Haftungsausschluss:

Jeder Anwender ist für den sachgemäßen Betrieb seines LOGO-Systems selbst verantwortlich. Dieses Programm enthebt Sie nicht der Verpflichtung zu sicherem Umgang bei Anwendung, Instalation, Betrieb und Wartung. Durch die Nutzung dieses von der Siemens AG erstellten Programm-Beispieles erkennen Sie an, daß die Siemens AG unter keinen Umständen für möglicherweise infolge der Nutzung auftretende Sach- und/oder Personenschäden haftbar gemacht werden kann.

SIEMENS AG- Example Program

Warning and Disclaimer of Liability

Siemens AG Example Program without Liability

Warning:

Unsafe operating conditions can cause controllers to fail, resulting in unchecked operation of controlled devices.

Such hazardous events can cause death and/or serious injury and/or material damage. You must therefore provide an emergency stop function and electric or other redundant safety devices that are independent of your automation system.

Disclaimer of Liability:

Users are solely responsible for the correct operation of their LOGO! systems. This program does not relieve you of the obligation to observe safe practices during implementation, installation, operation, and maintenance. By using this example program created by Siemens AG, you acknowledge that Siemens AG cannot under any circumstances be held liable for any possible personal injury or material damage resulting from the use of this program.

Creator:	ADBEJO0		Project:	Zählerwert als Bargraph anzeigen	Customer:	SIEMENS AG
Checked:	Beyer	CIERAENIC	Installation:	Indicating a counter value as a bar graph	Diagram No.:	
Date:	3/22/10 3:57 PM/3/24/10 2:13 PM	SIEMENS	File:	indicating_a_counter_value_as_bar_graph.lsc	Page:	2/2

Rem = off On=20+ Off=20 Start=0 Prio = 0 Quit = off Quit = off Text1: ISO88 Text2: disab> Ticker setti Characte - Line1: N - Line2: N - Line3: N - Line4: N Message Dest - Both Both = 10	Checked: Beyer SIEMENS Installation: Indic Date: 3/22/10 3:57 PW3/24/10 2:13 PM File: indic	ADREION Project:	I2(Input): Abwärts zählen Count down	Il(Input) : Aufwärts zählen Count up	<pre>Line1.11 Bar: B001 - Counter; Max = 20; Min = 0; Dir = Ver; Len Line2.2 Param: B001 - Counter Line4.1 Bar: B001 - Counter; Max = 20; Min = 0; Dir = Hor; Len</pre>	B001 - Counter Bar: 0	B004(Message texts) :	B001(Up/Down counter) : Limit at 20	Block Number (Type)
ination siemens age: Siemen Siemens age: 3	Indicating a counter_value as a Diagram No.: indicating_a_counter_value_as_b Page: 3				" "	Ticker setting - Character by - Line1: N - Line2: N - Line3: N - Line4: N Message Destinat - Both		Rem = off On=20+ Off=20 Start=0	Parameter

Connection Label
nection la
nection la
nection la
nection la
nection labeled the second section labeled the section
nection labeled the second section labeled the second second section labeled the section labeled the second section labeled the section
nection labeled the second section labeled the second section labeled the second section labeled the second second section labeled the second section labeled the second s
nection labeled the second section labeled the second section labeled the second section labeled the second second section labeled the second section labeled the second s
nection
nection
Onnection
onnection onnection
onnection
5 4 3 2 1 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
onnection
onnection
onnection 2
onnection

Checked: Date:	Creator:	X	ХЗ	X	×	AQ2	AQ1	Q16	Q15	Q14	Q13	Q12	Q11	Q10	Q9	Q8	Q7	Q6	Q5	Q4	Q3	Q2	Q	AI8	AI7	Al6	AI5	AI4	AI3	AI2	<u>A</u> 1	S8	S7	S6	S5	S4	Co
						2		6	5	4	ω	2		0																							Connection
Beyer 3/22/10 3:57 PM/3/24/10 2:13 PM	ADBE-100																																				
PM/3/24/10 2																																					Label
13 PM																																					
S																																					
SIEMENS																																					
Installation: File:	Proje																																				
Indicating a cindicating_a_	Zählerwert al																																				
Indicating a counter value as a indicating_a_counter_value_as_l	s Bargraph a																																				
as a Diag e_as_b Page	nzeigen Cust																																				
ram No.: e:	omer:																																				
ហ	SIEMENS A																																				
	ה 																																				

୍ଦ୍ରାଦ୍ରୀ	I	I	<u> </u>			I	I	Ι		<u> </u>	I		
Creator: ADBE Checked: Beyer Beyer 3/22/1	X16	X15	X14	X13	X12	X11	X10	X9	X8	X7	X6	X5	Connection
ADBEJO0 Beyer 3/22/10 3:57 PM/3/24/10 2:13 PM													Label
SIEMENS													
Project: Installation: File:													
SIEMENS Poject Zahlerwert als Bargapah azzaiger (Castomer. Indicating a counter value as a Diagram No.: Indicating a counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a Counter value as a Diagram No.: SEMENS AG Indicating a													
Customer: Diagram No.:													
SIEMENS AG													