lexicon® | MX200 | Dual Reverb Effects Processor

MX200 User Guide

Important!

MIDI Port Error Message

If you see this message, the MX200 is either disconnected or its USB MIDI ports are in use by an application. Some hosts, such as Cubase, may automatically open the MX200's MIDI ports by default. In this case, you will need to deselect or disable the port named "Lexicon MX200 Control" in the application's MIDI Devices setup.

CC Mapping

Processor 1 Effect Type	CC 12
Processor 1 Bypass	CC 13
Processor 1 Pre Delay Knob	CC 14
Processor 1 Decay Knob	CC 15
Processor 1 Liveliness Knob	CC 16
Processor 1 Tempo	CC 17
Processor 1 Effect Mix	CC 26
Processor 2 Effect Type	CC 19
Processor 2 Bypass	CC 20
Processor 2 Pre Delay Knob	CC 21
Processor 2 Decay Knob	CC 22
Processor 2 Liveliness Knob	CC 23
Processor 2 Tempo	CC 24
Processor 2 Effect Mix	CC 27
Effect Routing	CC 28

MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default	X	1	
	Changed	X	1-16, Omni, Off	
Mode	Default		Mode 2	
	Messages	X	X	
	Altered		X	
Note Number	True Voice	X	X	
Velocity	Note ON	X	X	
	Note OFF	X	X	
After Touch	Keys	X	X	
	Channels	X	X	
Pitchbend		X	X	
Control Change		X	1-127	See MIDI CC list
Program Change	True #	X	0-98 = 1-99	See Program mapping
	Bank Select	X	0	MIDI CC 32 Value 0 = Factory, Value 1 = User
System Exclusive		0	0	Lexicon Editor Only. Sys Ex channel follows MIDI channel except when MIDI channel is set to Off, where Sys Ex channel then receives on all channels.
System Common				
	Song Position:	X	X	
	Song Select:	X	X	
	Tune:	X	X	
System Real Time				
	Clock:	X	0	MIDI clock can set Delay Tempo
	Commands:	X	X	
Aux Messages		X	X	

0 = Yes **Mode 1: OMNI ON, POLY** **Mode 2: OMNI ON, MONO**
X = No **Mode 3: OMNI OFF, POLY** **Mode 4: OMNI OFF, MONO**

Appendix

Delay

Time Range Values

Value	Notation	Note Value
0		sixteenth note
4		triplet sixteenth
6		dotted sixteenth
12		eighth note
20		triplet eighth
24		dotted eighth
36		**quarter note**
48		triplet quarter
54		dotted quarter
72		half note

Note: A value of 36 is the 12 o'clock knob position, or equal to the **Tempo LED** rate. Intermediate values (e.g. 1-3) do not represent exact note values.

De-Esser

Frequency Values

Display Value	Frequency (Hz)
1	1600
2	1680
3	1760
4	1840
5	1920
6	2000
7	2100
8	2200
9	2300
10	2400
11	2500
12	2630
13	2760
14	2890
15	3020
16	3150
17	3320
18	3490
19	3660
20	3830
21	4000
22	4200
23	4400
24	4600
25	4800
26	5000
27	5260
28	5520
29	5780
30	6040
31	6300
32	6640
33	6980
34	7320
35	7660
36	8000
37	8400
38	8800
39	9200
40	9600
41	10000

Bandwidth Values

Value	Bandwidth
1	1/4 Oct
2	1/8 Oct
3	1/12 Oct
4	1/16 Oct
5	1/20 Oct
6	1/24 Oct

Program List

Program #	Title	Application	P1	P2	Routing
1	BIG POP VOCAL	Vocal	Studio Delay	Vocal Hall	2
2	POP VOCALS	Vocal	Tape Delay	Studio Reverb	3
3	RETROVERB	Vocal	Tape Delay	Vocal Plate	2
4	CHORUS + PLATE	Vocal	Chorus	Plate	4
5	VOCAL HALL+PLATE	Vocal	Vocal Hall	Vocal Plate	4
6	EXTRA ROOMY	Live Sound	Room	Small Hall	2
7	TUNED ROOM	Live Sound	Detune	Room	2
8	ECHOVERB	Live Sound	Digital Delay	Small Hall	2
9	QUICKIE	Live Sound	Small Hall	Digital Delay	2
10	ACOUSTIC CHAMBER	Instrumental	*Tape Delay*	Chamber	2
11	AMBIENT CHAMBER	Instrumental	Ambience	Chamber	4
12	ACOUSTIC BLISS	Instrumental	Detune	Large Hall	4
13	GUITAR WORLD	Instrumental	Chorus	Modulated Delay	2
14	SPRINGTIME	Instrumental	*Tremolo/Pan*	Spring	2
15	GIANT SNARE	Drums & Percussion	Studio Delay	Drum Hall	2
16	**SMOOTH DRM PLATE**	Drums & Percussion	Compressor	Drum Plate	2
17	**RICH DRUM HALL**	Drums & Percussion	Compressor	Drum Hall	2
18	BIG TIME	Special	Digital Delay	Large Hall	4
19	VOICE OF EVIL	Special	Pitch Shifter	Reverse Reverb	2
20	WAYBACK MACHINE	Special	Reverse Delay	Reverse Reverb	2
21	BIG VOCAL VERB	Vocal	Large Plate	Vocal Hall	2
22	TWO ROOMS	Vocal	Small Hall	Vocal Hall	1
23	BIG EASY	Vocal	Chorus	Vocal Hall	2
24	NASHVILLE	Vocal	Vocal Plate	Room	4
25	**LA-LA LAND**	Vocal	Compressor	Vocal Hall	2
26	**SMOOTH VOCALS**	Vocal	Compressor	Small Hall	2
27	**COMPRESSED VOX**	Vocal	Compressor	Vocal Hall	2
28	**NO "S" VOCALS**	Vocal	De-Esser	Vocal Plate	2
29	**DE-ESSER+COMPR**	Vocal	De-Esser	Compressor	2
30	**COMPRESSOR**	Vocal	Compressor	*Compressor*	4
31	**DE-ESSER**	Vocal	De-Esser	*De-Esser*	4
32	STUDIO DELAY	Vocal	Studio Delay	*Vocal Hall*	2
33	60'S DELAY	Vocal	Tape Delay	Spring	2
34	SLAPBACK	Vocal	*Detune*	Tape Delay	2
35	DELAY + VERB	Vocal	Studio Delay	Vocal Hall	1
36	VOCAL CHORUS	Vocal	Chorus	*Vocal Hall*	2
37	CHORAL HALL	Vocal	Chorus	Large Hall	2
38	TAPE CHOURUS	Vocal	Tape Delay	Chorus	2
39	CORE US	Vocal	Chorus	Chorus	1
40	DOUBLE TRACKS	Vocal	Detune	Chorus	2
41	SHIFTED ROOM	Vocal	Pitch Shift	Room Reverb	3
42	LIKE THAT!	Vocal	Pitch Shifter	Vocal Hall	4
43	PLATE + HALL	Live Sound	Vocal Plate	Small Hall	1
44	VOCAL + INST 1	Live Sound	Vocal Hall	Studio	4
45	VOCAL + INST 2	Live Sound	Vocal Plate	Detune	4
46	VOCAL + INST 3	Live Sound	Vocal Hall	Small Hall	4
47	GET SMALL	Live Sound	Small Hall	Small Plate	4
48	ALIVE N' KICKING	Live Sound	Small Hall	Studio	4
49	MUY GRANDE	Live Sound	Drum Hall	Digtal Delay	4
50	BIGGER BAND	Live Sound	Chorus	Studio Delay	2

Effects in the list that are italicized and shaded are in Bypass in the factory programs. Effects that are bolded are designed to be Full Wet only (e.g. Compressor).

Program #	Title	Application	P1	P2	Routing
51	TAPS	Live Sound	Chorus	Tape Delay	2
52	TAP CHAMBER	Live Sound	Pong Delay	Chamber	2
53	SPACED OUT	Live Sound	Large Plate	Modulated Delay	2
54	DUAL HALLS	Instrumental	Large Hall	Small Hall	1
55	TRIED AND TRUE	Instrumental	Studio	Small Hall	4
56	MORE & MORE	Instrumental	Large Plate	Arena	4
57	SPRING STUDIO	Instrumental	Spring	Studio	4
58	HIT ME	Instrumental	Tape Delay	Studio	2
59	PRECISION DELAY	Instrumental	Digital Delay	Small Hall	2
60	MODULATED DELAY	Instrumental	Chorus	Modulated Delay	2
61	ROCK LEAD	Instrumental	Tape Delay	Small Plate	4
62	PONG VERB	Instrumental	Small Plate	Pong Delay	2
63	MOD-U-VERB	Instrumental	Vocal Plate	Chorus	2
64	**ROTO-VERB**	Instrumental	Drum Hall	Rotary Speaker	2
65	**ROTARY**	Instrumental	Rotary	Small Room	4
66	**HAM 'N EGGS**	Instrumental	Tape Delay	Rotary	2
67	**VIBROLUX**	Instrumental	Rotary Speaker	Spring	1
68	SIDE BY SIDE	Instrumental	Tremolo	Panner	4
69	WOBBLERS	Instrumental	Chorus	Small Plate	4
70	RHODES PANNER	Instrumental	Phaser	Tremolo/Panner	4
71	BREWED AWAKENING	Instrumental	Flanger	Tape Delay	1
72	JET FLANGE	Instrumental	Flanger	Arena	2
73	PHASE GATE	Instrumental	Gated	Phaser	4
74	PHASED PLATE	Instrumental	Phaser	Small Plate	2
75	PHAME	Instrumental	Phaser	Large Plate	1
76	PHASER TASER	Instrumental	Phaser	Digital Delay	2
77	DUALING GUITARS	Instrumental	Pitch Shifter	Pitch Shifter	4
78	THE LOW DOWN	Instrumental	Pitch Shift	Modulated Delay	1
79	AND THEN SOME	Instrumental	Reverse Delay	Tremolo	2
80	**SQUISHED KICK**	Drums & Percussion	Compressor	Drum Hall	2
81	GATED SNARE	Drums & Percussion	Gated Reverb	Gated Reverb	3
82	SNARE DELAY	Drums & Percussion	Studio Delay	Drum Plate	2
83	DRUM DELAY	Drums & Percussion	Tape Delay	Drum Hall	2
84	DRUM ECHO	Drums & Percussion	Tape Delay	Small Hall	2
85	TEMPO GATE	Drums & Percussion	Studio Delay	Gated	2
86	FLANGE DRUMS	Drums & Percussion	*Studio Delay*	Flanger	2
87	TOM-TOM	Drums & Percussion	Studio Delay	Drum Hall	4
88	SNARE + TOMS	Drums & Percussion	Drum Hall	Room	4
89	DRUM PLATE/HALL	Drums & Percussion	Drum Plate	Drum Hall	4
90	VIBRATO	Special	Vibrato	Vibrato	4
91	VIBRA-SLAP	Special	Vibrato	Digital Delay	1
92	**SPIN CYCLE**	Special	Rotary	Tremolo/Panner	2
93	ROLE REVERSAL	Special	TremoloPan	Reverse	2
94	GET SOME	Special	Flanger	Reverse Delay	3
95	REWIND	Special	Chamber	Reverse	2
96	BACK AT YA	Special	Reverse Delay	Reverse	4
97	DELAY WARS	Special	Pong Delay	Modulated Delay	4
98	PITCH OUT	Special	Pitch Shifter	Pong Delay	2
99	HUH?	Special	Pitch Shifter	Vocal Plate	2

Effects in the list that are italicized and shaded are in Bypass in the factory programs. Effects that are bolded are designed to be Full Wet only (e.g. Compressor).