

BRAKE INSPECTION

MA01R-0

- 1. INSPECT BRAKE PEDAL AND PARKING BRAKE (See pages BR-9 and BR-11)
- 2. INSPECT BRAKE LINE PIPES AND HOSES HINT:

 $\label{lem:check_helphatire_circumference} Check_helphatire_circumference and_length_of_helphakelphoses_using_almirror_as_lequired._Turn theffront_wheels_fully_right_or_left_before_checking_theffront_brake.$

- (a) ☐ Check all brake lines and hoses for.
 - Damage
 - •□ Wear
 - □ Deformation
 - □ Cracks
 - □ Corrosion
 - •□ Leaks
 - •□ Bends
 - •□ Twists
- (b) Check[all[clamps[for[ightness[and[connections[for[]eakage.
- (c) Check[that[the[hoses[and[tines[are[clear[of[sharp[edges, moving[parts[and[the[exhaust[system.
- (d) Check that the tines install in the toronte center of the toro
- 3. INSPECT FRONT AND REAR BRAKE PADS AND DISCS

(FRONT[PADS:[See[page[BR-15]) (REAR[PADS:[See[page[BR-25])

(FRONT DISCS: See page BR-21)

(REAR DISCS: See page BR-30)

- 4. INSPECT[PARKING[BRAKE[LININGS[AND[DRUMS (See[page[BR-35)
- 5. INSPECTOR CHANGE BRAKE FLUID (See page BR-4)

Fluid: SAE 1703 or FMVSS No.116 DOT3