ST06J-01

REASSEMBLY

HINT:

Use high-temperature grease to lubricate the bearings and gears when assembling the starter.