SERVICE HINTS

I12 IGNITION SW

7–6 : Closed with ignition SW at **ON** or **ST** position 7–8 : Closed with ignition SW at **ST** position

N1 NEUTRAL START SW

6–5 : Closed with A/T shift lever in ${\bf P}$ or ${\bf N}$ position

S2 (A), S3 (B) STARTER

Points closed with neutral start SW at P or N position and ignition SW at ST position

: PARTS LOCATION

Co	ode	See Page	Code		See Page	Code		See Page
	٠,3	68 (LHD)		<u></u>	70 (LHD)	J29		84 (RHD)
C3		82 (RHD)	14		84 (RHD)	J39		88 (RHD)
E2	А	68 (LHD)	l12		72 (LHD)	N1		70 (LHD)
"		82 (RHD)			86 (RHD)			84 (RHD)
E5	D	68 (LHD)	J	1	70 (LHD)	- N2		70 (LHD)
		82 (RHD)	J3	Α	70 (LHD)	INZ		84 (RHD)
1.	1	70 (LHD)	J4	В	70 (LHD)	S2	Α	70 (LHD)
'	ı	84 (RHD)	J5		70 (LHD)	52	_ ^	84 (RHD)
	2	70 (LHD)	J16		74 (LHD)	S3	В	70 (LHD)
12		84 (RHD)		25	84 (RHD)	55	صـــــ	84 (RHD)
	3	70 (LHD)	J27	А	84 (RHD)			
13		84 (RHD)	J28	В	84 (RHD)			

: RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
Г	1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)
1		54 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)
l ''	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
EA2	96 (LHD)				
LAZ	106 (RHD)	Engine Wire and Cowl Wire (Inside of the ECU Box)			
EA3	96 (LHD)	Eligille ville alla Cowi ville (ilisiae oi tile ECO Box)			
LAS	106 (RHD)				
IA1	98 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Driver Side J/B)			
IAT	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)			
IA2	98 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Driver Side J/B)			
IAZ	108 (RHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)			
114	100 (LHD)	HD) Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)			
IK1	110 (RHD) Engine Room Main Wire and Cowl Wire (Near the Driver Side J/B)				


: GROUND POINTS


Code	See Page	Ground Points Location		
ED	96 (LHD)	Rear Side of the Intake Manifold		
	106 (RHD)	Near Side of the Intake Marilloid		
EE	96 (LHD)	Under the ABS & TRC & VSC Actuator		
	106 (RHD)	Officer the ABS & TRC & VSC Actuator		





: SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E2	96 (LHD)	Engine Wire	E2	106 (RHD)	Engine Wire




















(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)



(Hint: See Page 7,23, 39)



(Hint : See Page 7,23, 39)



N2 GRAY

\$2 (A) BLACK \$3 (B)