CO (w/o TWC) INSPECTION

EMOGL 01

HINT:

This check is used only to determine whether or not the idle CO complies with regulations.

1. INITIAL CONDITIONS


- (a) Engine at normal operating temperature
- (b) Air cleaner installed
- (c) All pipes and hoses of air induction system connected
- (d) All accessories switched OFF
- (e) All vacuum lines properly connected
- (f) EFI system wiring connectors fully plugged
- (g) Ignition timing checked correctly
- (h) Transmission in neutral position
- (i) Air conditioning switched OFF
- (j) Tachometer and CO meter calibrated by hand

2. CHECK AND ADJUST CO CONCENTRATION AT IDLE NOTICE:

Always use a CO meter when adjusting the idle mixture. It is not necessary to adjust with the idle mixture screw in most vehicles if they are in good condition. If a CO meter is not available, DO NOT ATTEMPT TO ADJUST IDLE MIXTURE.


(a) Using SST, connect terminals 13 (TC) and 4 (CG) of the DLC3.


SST 09843-18040



- (b) Race the engine at 2,500 rpm for approx. 180 seconds.
- (c) Insert a tester probe at least 40 cm (1.3 ft) into the tailpipe.
- (d) Wait at least 1 minute before measuring to allow the concentration to stabilize. Complete the measuring within 3 minutes.


Idle CO concentration: 1.0 - 2.0 %





If the CO concentration does not conform to regulations, adjust by turning the IDLE MIXTURE ADJUSTING SCREW in the variable resistor with SST.

SST 09243-00020



HINT:

The idle mixture adjusting screw can be tightened through on angle of 180°.

- If the CO concentration is within specification, this adjustment is complete.
- If the CO concentration cannot be corrected by idle mixture@djustment,@ee@he@able@n@age@M-3ffor other possible causes.
- (e) Remove the SST.

SST 09843-18040