DI86H-01

17. Panel witch does not function. Navigation creen only)

INSPECTION[PROCEDURE 1 Display[check[mode][Panel[switch]check[screen]. NG Replace[he[multi[display. OK 2 Check[AVC-LANcommunication]circuit"[See[page]DI-914)[NG Replace[or[repair[AVC-LANcommunication]circuit.

OK

Replace the navigation ECU.