
DI2A0-02

Wireless door lock buzzer circuit

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Incase of using the LEXUS hand-held tester, start the inspection from step of and incase of the LEXUS hand-held tester, start from step 2.

1 | CI

Check[wireless[door[lock[buzzer[using[LEXUS[hand-held[tester.

PREPARATION:

Connect[]he[]LEXUS[]hand-held[]ester[]o[]he[]DLC[3].

CHECK:

Check[]hat[]he[]wireless[door[]ock[]buzzer[can[]operated[]n[]an[]ACTIVE[]TEST.

OK:

The wireless door lock buzzer should sound.



Proceed_to_next_circuit_inspection_shown_on problem_symptoms_table._(See_page_DI-616)

NG

2 | Check[wireless[door[lock[buzzer.[See[page[BE-17]1]]

NG□

Replace[the[wireless[door[lock[buzzer.

OK

3 Check[wireless[and[connector[between[wireharness[door[lock[buzzer[and[body No.1[ECU.

NG

Repair or replace wireless or connector.

OK

Proceed lo next circuit inspection shown on problem symptoms table. (See page DI-616)