

16 GS 300 (Cont' d) * 1 : G. C. C. * 2 : Except G. C. C. * 3 : Europe ECT and A/T Indicator J 1(LHD) J25(RHD) JUNCTION CONNECTOR A/T INDICATOR LIGHT SW [NEUTRAL START SW] J 3(A), J 4(B) (LHD) 4 (1H) J27 A, J28 B (RHD) 2 JUNCTION CONNECTOR A J18(LHD) J35(RHD) JUNCTION ٷؖڴڐؠ۩ڰ۠ۉؖڰٛڐؖ J 1(LHD) J25(RHD) JUNCTION CONNECTOR E 2 (A), E 3 (B), E 4 (C), C11 COMBINATION METER E 5 D, E 6 E, E 7 F ENGINE AND ECT ECU K 3 KICK DOWN SW J37 JUNCTION CONNECTOR J10 JUNCTION CONNECTOR W-B A JI8 JUNCTION CONNECTOR A J 8(LHD) J42(RHD) JUNCTION CONNECTOR J 8 JUNCTION CONNECTOR Left kick panel ECT PATTERN (*1) --- I Right side of | |

IF : Left kick panel(LHD)
II : Cowl side panel RH(RHD)

the cowl panel