ILLUMINATION (LHD)

SERVICE HINTS

TAIL RELAY

5-3: Closed with light control SW at **TAIL** or **HEAD** position

C13 LIGHT CONTROL SW [COMB. SW]

15–16: Closed with light control SW at TAIL or HEAD position

: PARTS LOCATION

Co	de	See Page	Code	See Page	Code	See Page
A16		72 (LHD)	G1	72 (LHD)	J18	74 (LHD)
A21		72 (LHD)	G2	72 (LHD)	M2	74 (LHD)
A:	36	76 (LHD)	H20	72 (LHD)	R2	74 (LHD)
A:	37	76 (LHD)	H21	72 (LHD)	R6	74 (LHD)
B6	Α	72 (LHD)	H22	72 (LHD)	R7	74 (LHD)
С	9	72 (LHD)	J8	74 (LHD)	R13	78 (LHD)
C	13	72 (LHD)	J10	74 (LHD)	R14	78 (LHD)
D	1	72 (LHD)	J13	74 (LHD)	S4	74 (LHD)
E11		72 (LHD)	J17	74 (LHD)	V4	74 (LHD)

: RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)	
ſ	1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1A	58 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1C	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
1E	58 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)		
1F	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)		
1G	59 (LHD)			
1H	39 (EHD)			
3C	62	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)		
3D	02			
3E	- 63			
3F				
3G	03			
3H				

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
IC1	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)		
IJ2	100 (LHD)	(LHD) Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)		
IL1	100 (LHD)	Floor No.1 Wire and Cowl Wire (Right Kick Panel)		
BA1	102 (LHD)	Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)		
BB1	102 (LHD)	Rear Door RH Wire and Floor No.1 Wire (Under the Center Pillar RH)		


: GROUND POINTS

Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
IH	98 (LHD)	Instrument Panel Brace RH
II	98 (LHD)	Right Side of the Cowl Panel
BJ	102 (LHD)	Rear Floor Partition Panel LH
BL	102 (LHD)	Rear Floor Partition Panel RH



: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
l1	100 (LHD)	Cowl Wire			







A37 BLACK



