
SR0GF-0




## INSTALLATION

- 1. INSTALL [PS[VANE [PUMP [ASSEMBLY]
- (a) Torque the 2 bolts.

Torque: [58[N·m[590[kgf·cm, 43[ft·lbf]

(b) Connect the connector.



## 2. CONNECT PRESSURE FEED TUBE

Torque[the[union[bolt[over[a]]]hew[gasket.


HINT:

Make[sure[that[the[stopper[of[the[tube[is[touching[the[PS]]vane pump[body,[as[shown,[before[torquing[the[bolt.

Torque: 49 N·m 500 kgf·cm, 36 ft·lbf)

3. CONNECT [RETURN]HOSE

Connect he hose with he clip.



## 4. INSTALL DRIVE BELT

Loosen@the@drive@belt@ension@by@urning@he@drive@belt@ensionerclockwise,@and@nstall@the@belt.

Tighten the 16 bolts.

6. BLEED POWER STEERING SYSTEM

(See page \$R-4)