DI28G-02

DTC C1223 43 ABS Control System Malfunction

CIRCUIT DESCRIPTION

DTC[No.	DTC[Detecting[Condition	Trouble [Area
C1223 <u>∏</u> [43	ABS[control[system]s[abnormal.	ABS[control[system

INSPECTION PROCEDURE

1 Check[the[DTC[for[the[ABS[(See[page[DI-210)[]

*1[]

Repair [ABS] control [system] according [to] the code output.

*1: Output NG code