SYSTEM OUTLINE

ILLUMINATED ENTRY SYSTEM

This system provides various functions listed below through communication control of the body ECU and door ECU etc.

- * Each relevant light lights up if any door is opened.
- * If all the doors are closed with the ignition SW set at OFF after any door is opened, each light lights up for 15 sec., and then fades out when the time set on the timer has elapsed.
- * If any door is unlocked from the driver or passenger side or if any door is unlocked with the unlock SW on the transmitter after all the doors are closed and locked, each light lights up for **15** sec., and then fades out when the time set on the timer has elapsed.
- * If the ignition SW is turned to the **ACC** or **ON** position while each light is being lit by the timer, the timer lighting is cancelled and the light fades out.
- * If all the doors are closed and locked from the driver or passenger side or with the lock SW on the transmitter while each light is being lit, the timer lighting is cancelled and the light fades out.
- * If all the doors are closed with the ignition SW set at **ACC** or **ON** after any door is opened, the timer lighting is cancelled and the light fades out.
- * Each light above is the interior light, ignition key cylinder light, and step lights LH and RH.

SERVICE HINTS

D8, D9, D10, D11 DOOR COURTESY SW FRONT LH, RH, REAR LH, RH

1-2: Closed with door open

L5 LUGGAGE COMPARTMENT DOOR COURTESY SW

2-GROUND: Luggage compartment door open

W6 WIRELESS DOOR LOCK ECU

7-GROUND : Always approx. **12** volts 1-GROUND : Always continuity

D19 (B) DRIVER DOOR ECU

15-14: Continuity with driver door open

F12 (B) FRONT PASSENGER DOOR ECU

15-14: Continuity with front passenger door open

R13 REAR DOOR LH ECU

8-18: Continuity with rear LH door open

R14 REAR DOOR RH ECU

8-18: Continuity with rear RH door open

: PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page	
A16		72 (LHD)	D20	С	76 (LHD)	L5	78 (LHD)	
B5 A		72 (LHD)	E5		68 (LHD)	L7	78 (LHD)	
B6	А	72 (LHD)	F11	Α	76 (LHD)	M2	74 (LHD)	
C12		72 (LHD)	F12	В	76 (LHD)	P6	78 (LHD)	
)3	76 (LHD)	F13	С	76 (LHD)	P19	80 (LHD)	
)4	76 (LHD)	l11		72 (LHD)	R13	78 (LHD)	
[)5	76 (LHD)	l14		78 (LHD)	R14	78 (LHD)	
)6	76 (LHD)	l15		78 (LHD)	S6	74 (LHD)	
)7	76 (LHD)	J7		74 (LHD)	S7	74 (LHD)	
	08	76 (LHD)	J8		74 (LHD)	T5	74 (LHD)	
D9		76 (LHD)	J10		74 (LHD)	V6	78 (LHD)	
D	10	76 (LHD)	J13		74 (LHD)	V7	78 (LHD)	
D11		76 (LHD)	J16		74 (LHD)	W6	78 (LHD)	
D18	А	76 (LHD)	J1	18	74 (LHD)			
D19	В	76 (LHD)	J2	22	78 (LHD)			

: RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)
ı	1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
1E	58 (LHD)	Floor No.2 Wire and Driver Side J/B (Left Kick Panel)		
1F	58 (LHD)			
1G	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)		
1H	39 (LITID)			
2B	60 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)		
2D	60 (LHD)	Roof Wire and Passenger Side J/B (Right Kick Panel) Floor No.1 Wire and Passenger Side J/B (Right Kick Panel)		
2E	60 (LHD)			
2F	60 (LHD)			
2G	61 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)		
2H	01 (1110)			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

	i				
Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
IB1	98 (LHD)	Front Door LH Wire and Cowl Wire (Left Kick Panel)			
IC1					
IC2	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)			
IC3]				
IE1	98 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)			
IJ1	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)			
IJ2	100 (LITD)	Institution ratio vite and cowi vite (Left Side of the blower Offit)			
IK1	100 (LHD)	Front Door RH Wire and Cowl Wire (Right Kick Panel)			
IL1	100 (LHD)	Floor No.1 Wire and Cowl Wire (Right Kick Panel)			
IL3	100 (LITD)	Floor No. 1 Write and Cown Write (Night Nick Fahel)			
BA1	102 (LHD)	Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)			
BB1	102 (LHD)	Rear Door RH Wire and Floor No.1 Wire (Under the Center Pillar RH)			
BC1	104 (LHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Driver's Seat)			

: GROUND POINTS

Code	See Page	Ground Points Location
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel
BJ	102 (LHD)	Rear Floor Partition Panel LH
BL	102 (LHD)	Rear Floor Partition Panel RH
BM	102 (LHD)	Quarter Panel RH

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	100 (LHD)	Cowl Wire	B2	102 (LHD)	Roof Wire
16					

INTERIOR LIGHT (LHD)



