UPPER INSTRUMENT PANEL REMOVAL

PROCEDURE


1. PRECAUTION

Click here

- 2. DISCONNECT FRONT DOOR OPENING TRIM WEATHERSTRIP LH
 - a. Disconnect the front door opening trim weatherstrip LH.
- 3. REMOVE FRONT PILLAR GARNISH LH


Click here

- 4. REMOVE NO. 1 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY
 - Disengage the 2 clips and 3 claws as shown in the illustration.





b. Disengage the 2 guides to remove the No. 1 instrument panel speaker panel sub-assembly as shown in the illustration.





5. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY (for LH Side)


Click here

- 6. DISCONNECT FRONT DOOR OPENING TRIM WEATHERSTRIP RH
 - a. Disconnect the front door opening trim weatherstrip RH.
- 7. REMOVE FRONT PILLAR GARNISH RH

Tech Tips


Use the same procedure as for the LH side.

- **8.** REMOVE NO. 2 INSTRUMENT PANEL SPEAKER PANEL SUB-ASSEMBLY
 - a. Disengage the 2 clips and 3 claws as shown in the illustration.





b. Disengage the 2 guides to remove the No. 2 instrument panel speaker panel sub-assembly as shown in the illustration.






Remove in this Direction

9. REMOVE FRONT NO. 2 SPEAKER ASSEMBLY (for RH Side)

Tech Tips


Use the same procedure as for the LH side.

- 10. REMOVE INSTRUMENT CLUSTER FINISH PANEL END (w/ Headup Display)
 - a. Disengage the 5 claws as shown in the illustration.





b. Disengage the 2 guides to remove the instrument cluster finish panel end as shown in the illustration.




II

Remove in this Direction

11. REMOVE INSTRUMENT CLUSTER FINISH PANEL ASSEMBLY


Click here

- 12. REMOVE UPPER INSTRUMENT PANEL ASSEMBLY
 - a. Disconnect each connector.



*A w/ Navigation Antenna - -

 $\ensuremath{\mathbf{b}}.$ Remove the upper instrument panel assembly as shown in the illustration.



Remove in this Direction - -

Note

- Do not damage the upper instrument panel assembly.
- Do not allow the wire harnesses to interfere with the surrounding parts.