DI87F-01

Power source circuit

CIRCUIT DESCRIPTION

This circuit provides power to operate the passenger door ECU.

WIRING DIAGRAM



