## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J26	84 (RHD)	J36	88 (RHD)	J45	90 (RHD)
J28	84 (RHD)	J37	88 (RHD)	J46	94 (RHD)
J29	84 (RHD)	J42	88 (RHD)	J47	94 (RHD)
J32	88 (RHD)	J44	90 (RHD)		

## : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	54 (RHD)	Engine Room No.1 R/B (Engine Compartment Left)
2	55 (RHD)	Engine Room No.2 R/B (Engine Compartment Right)
3 56 Engine Room No.3 R/B (Engine Compartment Left) 4 57 (RHD) Passenger Side R/B (Left Kick Panel)		Engine Room No.3 R/B (Engine Compartment Left)
		Passenger Side R/B (Left Kick Panel)
5	57 (RHD)	Driver Side R/B (Right Kick Panel)

# : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1C	58 (RHD)	Instrument Panel Wire and Driver Side J/B (Right Kick Panel)			
1D	30 (KHD)	Institution and wife and briver side s/b (Mynt Mok Latter)			
1F	58 (RHD)	Cowl Wire and Driver Side J/B (Right Kick Panel)			
1G	59 (RHD)	Cowi Wile and Driver Side 3/B (Night Nick Pariet)			
2D	60 (RHD)	Roof Wire and Passenger Side J/B (Left Kick Panel)			
2F	60 (RHD)	Cowl Wire and Passenger Side J/B (Left Kick Panel)			
2G	61 (RHD)	Cowi Wile and Passenger Side 3/B (Left Nick Paner)			
3A	62				
3B					
3C		Instrument Banal Wire and Instrument Banal I/P (Instrument Banal Painforcement Center)			
3E	63	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)			
3F					
3H					

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)			
EA1	106 (RHD)	Engine Wire and Cowl Wire (Inside of the ECU Box)			
EA3	100 (1(11D)	Linguile wife and cowi wife (inside of the Loo box)			
EB1	106 (RHD)	Cowl Wire and Relay Block Wire (Inside of the Engine Room No.3 R/B)			
EB2	100 (1(11))	Cowi while and Nelay block while (histae of the Engine Nooth No.3 N/b)			
IB1	108 (RHD)	Front Door LH Wire and Cowl Wire (Left Kick Panel)			
IE1	108 (RHD)	Cowl Wire and A/C Sub Wire (Right Side of the Blower Unit)			
II1	110 (RHD)	Cowl Wire and Cowl Wire (Left Side of the Steering Column)			
IJ1	110 (RHD)	Instrument Panel Wire and Cowl Wire (Right Side of the Steering Column)			
IL1	110 (RHD)	Front Door RH Wire and Cowl Wire (Right Kick Panel)			
BA1	112 (RHD)	Rear Door LH Wire and Floor No.2 Wire (Under the Center Pillar LH)			
BB1	112 (RHD)	Rear Door RH Wire and Floor No.1 Wire (Under the Center Pillar RH)			
BC1	114 (RHD)	Floor No.2 Wire and Front Seat LH Wire (Under the Front Passenger's Seat)			
BD1	114 (RHD)	Floor No.1 Wire and Front Seat RH Wire (Under the Driver's Seat)			


## $\nabla$

### : GROUND POINTS


Code	See Page	Ground Points Location
EA	106 (RHD)	Right Fender
EB	106 (RHD)	Left Fender
EC	106 (RHD)	Front Side of the Intake Manifold
ED	106 (RHD)	Rear Side of the Intake Manifold
EE	106 (RHD)	Under the ABS & TRC & VSC Actuator
IF	108 (RHD)	Left Kick Panel
IG	108 (RHD)	Behind the Combination Meter
IH	108 (RHD)	Instrument Panel Brace LH
II	108 (RHD)	Cowl Side Panel RH
BJ	112 (RHD)	Rear Floor Partition Panel LH
BK	112 (RHD)	Quarter Panel LH
BL	112 (RHD)	Rear Floor Partition Panel RH
BM	112 (RHD)	Quarter Panel RH

#### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	106 (RHD)	Engine Wire	I10	110 (RHD)	Cowl Wire
E4	106 (RHD)	Cowl Wire	B1	112 (RHD)	Roof Wire
12			B4	112 (RHD)	Floor No.2 Wire
18	110 (RHD)	Cowl Wire	B7	114 (RHD)	Front Seat RH Wire
19	]				




(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint: See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)




(Hint : See Page 7, 23, 39)



(Hint: See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)



(Hint : See Page 7, 23, 39)