#### SERVICE HINTS \_

# **T7 TURN SIGNAL FLASHER**

4-GROUND : Always approx. 12 volts

1-GROUND : Approx. 12 volts with ignition SW at ON or ST position

7-GROUND : Always continuity

## : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B5	72 (LHD)	F6	68 (LHD)	J21	78 (LHD)
C11	72 (LHD)	H20	72 (LHD)	R10	78 (LHD)
C13	72 (LHD)	J8	74 (LHD)	R12	78 (LHD)
F3	68 (LHD)	J10	74 (LHD)	T7	74 (LHD)
F4	68 (LHD)	J12	74 (LHD)		
F5	68 (LHD)	J18	74 (LHD)		

#### : RELAY BLOCKS

	Code	See Page	Relay Blocks (Relay Block Location)	
I	1	54 (LHD)	Engine Room No.1 R/B (Engine Compartment Right)	

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
1B	58 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1C	58 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1D	30 (LI ID)	motivinent i anei vviie and briver olde s/b (Leit Nok i anei)			
1F	58 (LHD)				
1G	59 (LHD)	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1H	39 (LI ID)				
2B	60 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)			
2F	60 (LHD)				
2G	61 (LHD)	Cowl Wire and Passenger Side J/B (Right Kick Panel)			
2H	OT (LITE)				
3C	62	Instrument Panel Wire and Instrument Panel J/B (Instrument Panel Reinforcement Center)			
3G	63				

#### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IC2	98 (LHD)	Floor No.2 Wire and Cowl Wire (Left Kick Panel)	
IE2	98 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Steering Column)	
114	100 (LHD)	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)	
IJ2	100 (LHD)	Instrument Panel Wire and Cowl Wire (Left Side of the Blower Unit)	

#### : GROUND POINTS

Code	See Page	Ground Points Location
EA	96 (LHD)	Right Fender
EB	96 (LHD)	Left Fender
IF	98 (LHD)	Left Kick Panel
II	98 (LHD)	Right Side of the Cowl Panel
BK	102 (LHD)	Quarter Panel LH

# : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E4	96 (LHD)	Cowl Wire	B4	102 (LHD)	Floor No.2 Wire
15	100 (LHD)	Engine Room Main Wire			

# TURN SIGNAL AND HAZARD WARNING LIGHT (LHD)

