FROM POWER SOURCE SYSTEM (SEE PAGE 134)

15A
ECU–IG

120A
ALT

LG

B–R

B

J7 (A), J41 (B)
JUNCTION
CONNECTOR

B (A)(LHD)
E (B)(RHD)

B (A)(LHD)
E (B)(RHD)

B–R

J16 (A), J31 (B)
JUNCTION
CONNECTOR

B (A)(LHD)
C (B)(RHD)

B (A)(LHD)
C (B)(RHD)

B–R

B

LG

IG
RELAY

20A
SEAT
HTR

W–B
(LHD)

W–B

W–B
(RHD)

W–B
(RHD)

W–B
(LHD)

J37
JUNCTION
CONNECTOR

J32
JUNCTION
CONNECTOR

J42
JUNCTION
CONNECTOR

IF

II

II

LG

LG

S 4
SEAT HEATER SW

IG

LH

E

RH

B–Y

W–B
(LHD)

W–B
(RHD)

L–Y

IC2

IL2 (LHD)
IM2 (RHD)

B–Y

L–Y

BC1

BD1

B–Y

B

B

L–Y

S17 (LHD)
SEAT HEATER
(DRIVER'S SEAT
CUSHION)

J14
JUNCTION
CONNECTOR

J37
JUNCTION
CONNECTOR

S19 (LHD)
SEAT HEATER
(FRONT PASSENGER'S
SEAT CUSHION)

S19 (RHD)
SEAT HEATER
(FRONT PASSENGER'S
SEAT CUSHION)

S17 (RHD)
SEAT HEATER
(DRIVER'S SEAT
CUSHION)

L–B

W–B
(LHD)

W–B
(RHD)

L–B

S16 (LHD)
SEAT HEATER
(DRIVER'S SEAT
BACK)

1F

S18 (LHD)
SEAT HEATER
(FRONT PASSENGER'S
SEAT BACK)

S18 (RHD)
SEAT HEATER
(FRONT PASSENGER'S
SEAT BACK)

1G

S16 (RHD)
SEAT HEATER
(DRIVER'S SEAT
BACK)

W–B

W–B
(LHD)

W–B
(LHD)

W–B
(RHD)

W–B

B (A)(LHD)
A (B)(RHD)

J24 (A), J47 (B)
JUNCTION
CONNECTOR

J23 (LHD),
J46 (RHD)
JUNCTION
CONNECTOR

J10
JUNCTION
CONNECTOR

B (A)(LHD)
A (B)(RHD)

BC1

BD1

W–B

W–B
(LHD)

W–B
(RHD)

W–B

J8
JUNCTION CONNECTOR

J42
JUNCTION CONNECTOR

BJ

EB

IF

II

BL