BE0HG-02

ADJUSTMENT

Resetting method of the motor for jam protection.

- When replacing the motor from the regulator or running the motor, make sure to reset the motor.
- This operation sets the limit switch OFF.
 - Connect the motor connector to the vehicle side harness.
 - Rotate the motor from 6 turns to 10 turns or for 4 5 secs moving it to the glass ascending direction.

HINT:

Rotating the motor from 6 turns to 10 turns or for 4 - 5 secs. sets the limit switch to "OFF". (Top dead center of the door glass.)