BE0HE–02

LOCATION

Power Window Switch

Driver side Junction Block
● Body ECU No.2

Passenger side Junction Block
● Body ECU No.1

Ignition Switch

Power Window Master Switch

Power Window Switch

Power Window Motor

Power Window Motor

Power Window Switch

I05310