CRUISE CONTROL SYSTEM
HOW TO PROCEED WITH TROUBLESHOOTING

DI26R–03

Troubleshoot in accordance with the procedure on the following page.

```
              ┌──────────────────────────────┐
              │  Vehicle Brought to Workshop  │
              └──────────────────────────────┘
                            ⬇
    1      Customer Problem Analysis
                  P. DI–537
                            ⬇
    2      Check and Clear DTC (Precheck)
                  P. DI–538
                            ⬇
    3   Problem Symptom Confirmation  ──Symptom does not occur──▶  4  Symptom Simulation
                                                                        P. IN–19
          Symptom occurs  ◀──────────────────────────────────────────────┘
                            ⬇
    5      DTC Check                         ──Normal code──┐
                  P. DI–538                                  │
                            ⬇ Malfunction code               ⬇
    6      DTC Chart                         7   Problem Symptom Table
                  P. DI–543                         P. DI–546
                            ⬇                           ⬇
    8   Circuit Inspection    9  Input Signal Check        Parts Inspection
              P. DI–547 – DI–556
                            ⬇
          Identification of Problem
                            ⬇
              Repair
                            ⬇           NG
    10    Confirmation Test
                            ⬇ OK
              ┌──────────┐
              │    End    │
              └──────────┘
```

Items inside ▱ are titles of pages in this manual with the page number indicated in the bottom portion.   See the indicated pages for detailed explanations.

Step 2, 5, 8, 10: Diagnostic steps permitting the use of the TOYOTA hand–held tester or TOYOTA break–out–box.