INSTALLATION

Installation is in the reverse order of removal (See page SA−30).
AFTER INSTALLATION, CHECK FRONT WHEEL ALIGNMENT (See page SA−4)