



 $\tt M86(J), z11(K), z13(C), z14(D), z15(E), z16(F), z20(H), z21(I), z27(A), z28(B), z29(G) \\ HV \ Supply \ Battery \ Assembly$




z13(C), z14(D), z15(E), z16(F), z27(A), z28(B) Battery ECU Assembly

LG LG




 $\tt M86(J), z11(K), z13(C), z14(D), z15(E), z16(F), z20(H), z21(I), z27(A), z28(B), z29(G) \\ HV \ Supply \ Battery \ Assembly$




z13(C), **z14(D)**, **z15(E)**, **z16(F)**, **z27(A)**, **z28(B)** Battery ECU Assembly

LG LG





 $\begin{tabular}{ll} M86(J), z11(K), z13(C), z14(D), z15(E), z16(F), z20(H), z21(I), z27(A), z28(B), z29(G) \\ HV Supply Battery Assembly \\ \end{tabular}$




z13(C), z14(D), z15(E), z16(F), z27(A), z28(B) Battery ECU Assembly










LG LG





M86(J), z11(K), z13(C), z14(D), z15(E), z16(F), z20(H), z21(I), z27(A), z28(B), z29(G) HV Supply Battery Assembly Service Plug O-W IB0 IB1 VIB GIB GR R LG L-W GR BR IGCT M37(A), S3(B), S4(C), z29(G), z30(D) HV Battery Junction Block Assembly 3**(**F) 15 **(**F 23 **(**F) 11 **(**F) 24 **(**F) 12 **(**F) 16 **(**E**)** 9 **(**E) 14 (J) 7 (J) 8 (J) GD0 CD0 IB0 IB1 VIB IGCT CA2L CA2H GR ≥ SB z13(C), z14(D), z15(E), z16(F), z27(A), z28(B) Battery ECU Assembly SB LG W



















































90980-12A39

















- 27 -

